

# ***ADwin-Pro***

## **System and hardware description**



**For any questions, please don't hesitate to contact us:**

Hotline: +49 6251 96320  
Fax: +49 6251 568 19  
E-Mail: [info@ADwin.de](mailto:info@ADwin.de)  
Internet: [www.ADwin.de](http://www.ADwin.de)



Jäger Com-  
putergesteuerte  
Messtechnik GmbH  
Rheinstraße 2-4  
D-64653 Lorsch  
Germany

## Table of contents

Table of contents .....	III
Typographical Conventions .....	IV
1 The <b>ADwin-Pro</b> system .....	1
2 How to Install an <b>ADwin-Pro</b> System .....	2
3 Operating Environment .....	3
4 Enclosures for the <b>ADwin-Pro</b> System .....	4
4.1 <b>ADwin-Pro</b> .....	4
4.2 <b>ADwin-Pro-DC</b> .....	5
4.3 <b>ADwin-Pro-BM</b> .....	7
4.4 <b>ADwin-Pro-light</b> .....	8
4.5 <b>ADwin-Pro-mini</b> .....	8
5 <b>ADwin-Pro</b> Modules .....	10
5.1 Setting the module's addresses .....	10
5.2 Processor modules .....	12
5.3 Pro I: Analog Input Modules .....	19
5.4 Pro I: Analog Output Modules .....	62
5.5 Pro I: Analog Input and Output Modules .....	75
5.6 Pro I: Digital-I/O- and Counter Modules .....	79
5.7 Pro I: Signal Conditioning and Interface Modules .....	145
6 Calibration .....	180
6.1 General information .....	180
6.2 Calculation basis .....	181
6.3 Calibrating a module .....	183
6.4 Calibration with <b>ADbasic</b> Programs .....	186
6.5 Programs for calibration .....	188
7 Accessories .....	192
7.1 LEMO Cable Sets for <b>ADwin-Pro</b> Systems .....	192
7.2 LEMO Adapter sets .....	192
7.3 Reference addresses .....	192
Annex .....	A-1
A.1 CAN bus Baud rates .....	A-1
A.2 Alphabetic List of Modules .....	A-3

## Typographical Conventions



"Warning" stands for information, which indicate damages of hardware or software, test setup or injury to persons caused by incorrect handling.



You find a "note" next to

- information, which absolutely have to be considered in order to guarantee an error free operation.
- advice for efficient operation.



"Information" refers to further information in this documentation or to other sources such as manuals, data sheets, literature, etc.

<C:\ADwin\ ...>

File names and paths are placed in <angle brackets> and characterized in the font *Courier New*.

Program text

Program instructions and user inputs are characterized by the font *Courier New*.

Var\_1

ADbasic source code elements such as instructions, variables, comments and other text are characterized by the font *Courier New* and are printed in color (see also the editor of the *ADbasic* development environment).

Bits in data (here: 16 bit) are referred to as follows:

Bit No.	15	14	13	...	01	00
Bit value	$2^{15}$	$2^{14}$	$2^{13}$	...	$2^1=2$	$2^0=1$
Synonym	MSB	-	-	-	-	LSB

### 1 The ADwin-Pro system

The *ADwin-Pro* system is an external processing system with modular expansion options. Depending on applications, the different enclosures can be equipped with *ADwin-Pro* modules.

Since middle of 2005 there are 2 versions of *ADwin-Pro*:

- *ADwin-Pro I*: The classic *ADwin-Pro* system for approved Pro I modules and the processors T9 and T10.
- *ADwin-Pro II*: The new *ADwin-Pro* system for existing Pro I modules, new Pro II modules and the processor T11.

When the *ADwin-Pro* system was developed great attention was paid to the electromagnetic compatibility. The *ADwin-Pro* system and all available input and output modules have the CE sign and can therefore be configured differently later if necessary.

Each *ADwin-Pro* system needs a processor module. It communicates via Ethernet or USB with the PC or notebook; previous versions used a serial link connection.

In order to meet the various requirements for measurement and control tasks the system can be equipped with the following modules:

- analog input modules and analog output modules
- digital input modules and digital output modules
- counters
- filters, isolation amplifiers
- amplifiers for thermocouples and PT100 resistors
- serial communication interfaces (CAN, RSxxx, Fieldbus)
- storage / read module for PCMCIA storage media

Since middle of 2002 all modules have a revision identifier written on the module front, e.g. Rev. A2, Rev. B3, Rev. C3. Earlier delivered modules have no identifier; they are to be considered as revision "Rev. A".

Different revision characters mean different module properties and are described separately.

The revision identifier is followed by a minor counting number, which is mainly used for internal purposes of Jaeger Computergesteuerte Messtechnik GmbH.

#### Applicable modules

#### Revision Identifier

## 2 How to Install an ADwin-Pro System

Please keep strictly to the following order:

1. Start with the manual "ADwin installation":
  - Installation of software and interface drivers from the ADwin-CDROM.
  - Initialization of data connection from PC to ADwin system as well as operational test.
2. First steps with the ADbasic Tutorial .
3. Programming in ADbasic.

The ADbasic manual describes the real-time development environment, the structure of an ADbasic program and gives hints for optimizations. You also find all this information in the ADbasic online help.

The ADbasic instructions are described in these documents:

- |                              |  |
|------------------------------|--|
| • ADbasic manual:            | Basic instructions for calculation, program structure and process control. |
| • ADwin-Pro software manual: | Instructions and hints for accessing the Pro modules.                      |
| • Online help:               | Instructions from both ADbasic manual and ADwin-Pro software manual.       |

For operation, please pay attention to the notes in this manual concerning the respective modules.

### Please note:

For ADwin systems to function correctly, adhere strictly to the information provided in this documentation and in other mentioned manuals.

Programming, start-up and operation, as well as the modification of program parameters must be performed only by appropriately qualified personnel.

*Qualified personnel are persons who, due to their education, experience and training as well as their knowledge of applicable technical standards, guidelines, accident prevention regulations and operating conditions, have been authorized by a quality assurance representative at the site to perform the necessary activities, while recognizing and avoiding any possible dangers.*

*(Definition of qualified personnel as per VDE 105 and ICE 364).*

This product documentation and all documents referred to, have always to be available and to be strictly observed. For damages caused by disregarding the information in this documentation or in all other additional documentations, no liability is assumed by the company *Jäger Computergesteuerte Messtechnik GmbH*, Lorsch, Germany.

This documentation, including all pictures is protected by copyright. Reproduction, translation as well as electronical and photographic archiving and modification require a written permission by the company *Jäger Computergesteuerte Messtechnik GmbH*, Lorsch, Germany.

OEM products are mentioned without referring to possible patent rights, the existence of which, may not be excluded.

Hotline address: see inner side of cover page.

**Qualified personnel**

**Availability of the documents**



**Legal information**

**Subject to change.**

### 3 Operating Environment

The *ADwin-Pro* device must be earth-protected, in order to

- build a ground reference point for the electronic
- conduct interferences to earth.

Connect the GND clamp / plug via a short low-impedance solid-type cable to the central earth connection point of the controlled system. The GND plug is internally connected with ground and the enclosure.

In the Ethernet cable the data lines are galvanically isolated, but the ground potentials are connected, because the shielding of the Ethernet connector (RJ-45) is connected to GND.

Transient currents, which are conducted via the aluminum enclosure or the shielding, have an influence on the measurement signal.

Please, make sure that the shielding is not reduced, for instance by taking measures for bleeding off interferences, such as connecting the shielding to the enclosure just before entering it. The more frequently you earth the shielding on its way to the controlled system the better the shielding will be.

Use cables with shielding on both ends for signal lines. Here too, you should reduce the bleeding off of interferences via the enclosure by using screen clips.

Operate the device with the defined and fitting supply voltage. For operation with an external power supply, the instructions of the manufacturer apply. Close the device for operation, use cover plates to cover gaps between built-in modules.

*ADwin-Pro* is designed for operation in dry rooms with an ambient temperature of +5°C ... +50°C and a relative humidity of 0 ... 80% (no condensation). The device may be operated in a control cabinet or mobile (e.g. in a car).

The temperature of the chassis (surface) must not exceed +60°C, even under extreme operating conditions – e.g. in a control cabinet or if the system is exposed to the sun for a longer period of time. You risk damages at the device or not-defined data (values) are output which can cause damages at your measurement device under unfavorable circumstances.

For use in a control cabinet, please note:

- The device shall not be placed above strong heat sources, e.g. a high power transformer.
- Ventilation inside the control cabinet towards and from the *ADwin-Pro* device must be provided.  
Especially, the ventilation slots of the device must be kept free, so that the device can lead off its generated heat completely.

#### Earth protection



#### Galvanic connection

#### Excluding transient currents



#### Supply voltage

#### Ambient atmosphere

#### Chassis temperature



## 4 Enclosures for the ADwin-Pro System

The different sizes for the enclosures depend on the number of slots and the kind of power supply.

Enclosure	Number of Slots	Power supply	
ADwin-Pro	16	100V...240V	AC
ADwin-Pro-DC	16	10V...35V	DC
ADwin-Pro-BM	15	100V...240V	AC
ADwin-Pro-light	7	100V...240V	AC
ADwin-Pro-light-DC	7	10V...35V	DC
ADwin-Pro-mini	5	5V 10V...18V 20V...36V	DC

For the slot area (including power supply slot) the following dimensions apply:

$$1 \text{ HP} = 1/5 \text{ inch} = 5.08 \text{ mm}$$

$$1 \text{ U} = 5/3 \text{ inch} = 42.3 \text{ mm}$$

The slots mostly have a width of 5 HP = 1 inch.

### Plug-in a module



You plug-in a module into the enclosure like this:

- Switch off the *ADwin* device! A module may sustain damage if you plug it in or out with the power supply switched on.
- Remove one or more cover plates at the wanted position, until the bearings be seen at the left edge: one upper and one lower bearing.
- Insert the board carefully into both bearings, plug ahead. If positioned correctly the module cannot be skewed.
- Push the module into the enclosure. At the end the push gets harder while the module plug slides into the female connector of the back plane.

The module's front panel should butt against the enclosure.

- Fix the module with the screws at top and bottom of the front panel.
- If there are, close the gaps between plugged-in modules using the cover plates. There are plates with 2, 3 or 5 HP width.

### 4.1 ADwin-Pro

The standard enclosure for the *ADwin-Pro* systems. The backplane of the enclosure connects the processor module with the *ADwin-Pro* modules.

The system fuse is located in a slot in the power supply unit above the female connector for the power supply cable (rear of the enclosure).

Number of Slots	16
Main dimensions (l x w x h)	336mm x 447.5mm x 146mm
Slot area (w x h)	84 HP x 3 U
Power supply unit	min. 70W, 100V...240VAC at 50/60Hz switching power supply
Fuse	5A, delayed-action fuse

Fig. 1 – Enclosure *ADwin-Pro*: Specification

At the rear of the enclosure, above the power supply connector you will find a label with the revision number:



Revision	Release	Previous versions
A	1997	First version with linear power supply.
B1	Sep. 1999	Prototype (internal use only, not delivered to customers)
B2	Jun. 2003	Internal structure modified, function unchanged.
B3	Jun. 2004	New power supply (switching power supply) with automatical voltage adaptation.

The processor module can be plugged-in at any position.




Fig. 2 – Enclosure *ADwin-Pro I*

## 4.2 ADwin-Pro-DC

The *ADwin-Pro-DC* enclosure is similar to the standard enclosure *ADwin-Pro*, but is equipped with a DC power supply.

If a current-limited power supply unit is used, it should be able to supply a multiple of the idle current during power-up to maintain proper performance of the system.




Fig. 3 – Enclosure *ADwin-Pro-DC*:  
Detailed view of the pin assignment

Number of Slots	16
Main dimensions (l x w x h)	336mm x 447.5mm x 146mm
Slot area (w x h)	84 HP x 3 U
Power supply unit	min. 80W, DC-DC converter 10V...35V

Fig. 4 – Enclosure *ADwin-Pro-DC*: Specification

**Pro-DC  
with 16 slots**



At the rear of the enclosure, above the power supply connector you will find a label with the revision number:

Revision	Release	Änderung zur Vorgänger-Version
A	1997	First version with linear power supply.
B1	Sep. 1999	Prototype (internal use only, not delivered to customers)
B2	Jun. 2003	Internal structure modified, function unchanged.
B3	Nov. 2003	Various improvements

### 4.3 ADwin-Pro-BM

In the version "backmounted" of the standard enclosure, the modules are plugged-in at the rear of the enclosure.




Fig. 5 – Enclosure of *ADwin-Pro I-BM* (rear panel)

The system fuse is located in a slot in the power supply unit above the female connector for the power supply cable (rear of the enclosure).

Number of Slots	16
Main dimensions (l x w x h)	336mm x 447.5mm x 146mm
Slot area (w x h)	84 HP x 3 U
Power supply unit	min. 70W, 100V...240VAC at 50/60Hz switching power supply
Fuse	5A, delayed-action fuse

Fig. 6 – Enclosure of the *ADwin-Pro-BM*: Specification


At the rear of the enclosure, above the power supply connector you will find a label with the revision number:

Revision	Release	Previous versions
A	1997	First version with linear power supply.
B1	Sep. 1999	Prototype (internal use only, not delivered to customers)
B2	Jun. 2003	Internal structure modified, function unchanged.
B3	Nov. 2003	New power supply (switching power supply) with automatical voltage adaptation.

**Pro "backmounted" with  
15 slots**

## Pro-light with 7 slots

## 4.4 ADwin-Pro-light



Enclosure ADwin-Pro I-light

The backplane of the enclosure connects the processor module with the ADwin-Pro modules.

Number of Slots	7
Main dimensions (l x w x h)	336mm x 234mm x 146mm
Slot area (w x h)	42 HP x 3 U
Power supply unit	min. 40W, 100...240VAC at 50/60Hz switching power supply
Fuse	2A, delayed-action fuse

Fig. 7 – Enclosure ADwin-Pro-light: Specification

At the rear of the enclosure, above the power supply connector you will find a label with the revision number:

Revision	Release	Previous versions
A1	1997	First version with linear power supply.
A2	Jun. 2004	New power supply (switching power supply) with automatical voltage adaptation. Internal structure modified.
A3	Aug. 2004	Various improvements

## 4.5 ADwin-Pro-mini

## Pro-mini with 5 slots

The smallest ADwin-Pro-mini enclosure has 5 slots and requires an external power supply unit.

The power supply connector be found at the rear of the enclosure.

Number of Slots	5
Main dimensions (l x w x h)	253mm x 147.3mm x 146mm
Slot area (w x h)	20 HP x 3 U
External power supply unit	external power supply unit required
Pro I mini	5V DC, >20W
Pro I mini-2	10V...18V DC
Pro I mini-3	20V...36V DC

Fig. 8 – Enclosure ADwin-Pro-mini Specification




Fig. 9 – Enclosure *ADwin-Pro-mini*  
and power supply connector

At the rear of the enclosure you will find a label with the revision number:

Revision	Release	Previous versions
A	1998	First version

## 5 ADwin-Pro Modules

An *ADwin-Pro* module needs one slot (5 HP) in an *ADwin-Pro* system, some modules need 2 slots.

All technical data of the module refer to a device which is powered-up.

For pluggin-in a module into the enclosure please note the description on page 4, especially with *ADwin-Pro II* enclosures.

*ADwin-Pro II* modules can only be used in a *ADwin-Pro II* enclosure.

### 5.1 Setting the module's addresses

Any *ADwin-Pro* module (except CPU modules) is addressed in an *ADbasic* program via its module address. The module address is free selectable.

#### Selecting a module's address

Note the following rules for selecting a module's address:

- A module address must be unique inside its module group.

Each module is member of a module group:

- Pro I modules, functional group CPU: processor modules.
- Pro I modules, functional group ADC: analog input modules.
- Pro I modules, functional group DAC: analog output modules.
- Pro I modules, functional group DIO: digital input/output modules, relays and counter modules.
- Pro I modules, functional group EXT: special modules of all kind.

- A module address must be within the following limits:

- Pro I modules: 1 ... 255.


There are special limits for RSxxx- and fieldbus modules (see below)

It is true that you can select the same module address for modules of different groups. Nevertheless we recommend to use unique addresses in order to prevent a mix-up.

#### Setting the module's address

With Pro I modules you set the module address manually via DIP-switches. The on-board block of DIP-switches is located right to the bottom.

With 8 DIP switches the address is selectable between 1 and 255 (see fig. 10). Each module of the same group needs to have a different address.



Module no.	Settings of DIP switches							
	1	2	3	4	5	6	7	8
1	1	0	0	0	0	0	0	0
2	0	1	0	0	0	0	0	0
3	1	1	0	0	0	0	0	0
4	0	0	1	0	0	0	0	0
5	1	0	1	0	0	0	0	0
6	0	1	1	0	0	0	0	0
7	1	1	1	0	0	0	0	0
8	0	0	0	1	0	0	0	0
...	...							
254	0	1	1	1	1	1	1	1
255	1	1	1	1	1	1	1	1

Fig. 10 – Address settings of the *ADwin-Pro* modules with DIP switches

Please note:

- A RSxxx module with 4 serial interfaces uses 2 addresses (group EXT): the set address and the following address.
- A fieldbus module uses 32 addresses (group EXT); the address allocation is shown in fig. 11.

Set module address	Addit. allocated addresses	Settings of DIP switches							
		1	2	3	4	5	6	7	8
1	160...191	1	0	0	0	0	0	0	0
2	192...223	0	1	0	0	0	0	0	0
3	224...255	1	1	0	0	0	0	0	0
4	128...159	0	0	1	0	0	0	0	0

Fig. 11 – Address settings of fieldbus modules with DIP switches



## Overview CPU modules

## Ethernet: Mode of Operation

## Input Event In

## 5.2 Processor modules

For each *ADwin-Pro* system one processor module is required. This processor module is the center of a Pro system and performs the following tasks:

- Communication with PC or laptop.

The data connection is established via USB or Ethernet; former version used a serial link connection.

- Communication with other *ADwin-Pro* modules via internal Pro bus.
- Start and run the user defined processes.

The processor module provides the memory for data and programs, divided into a fast internal memory (SRAM) and an external memory (DRAM).

The processor modules differ mainly in computing power (clock rate):

Module	Pro-CPU-T9	Pro-CPU-T9-ENET / -USB	Pro-CPU-T10-ENET
System	Pro I	Pro I	Pro I
Processor	ADSP 21062	ADSP 21062	ADSP 21162
Clock rate	40MHz	40MHz	80MHz
Data connection	Link	Ethernet, USB	Ethernet, USB
Internal memory	256KiB opt. 512KiB	256KiB opt. 512KiB	512KiB
External memory	4MiB opt. 16/32MiB	16MiB opt. 64MiB	128MiB
Inputs	Event In	Event In opt. Digin 0	Event In Digin 0

Fig. 12 – Overview Pro CPU modules

Modules with an Ethernet interface show their mode of operation by LEDs. The meaning of the LEDs is described in manual *ADwin Installation*, chapter 10.3.

The external trigger input (`Event In`) enables the processor module to recognize an external signal as trigger for an event and trigger a process, that is processed immediately and completely (see *ADbasic* manual, chapter: Structure of the *ADbasic* program).

The event signal has to be present for 50ns to be recognized (specified value for CPU-T9 in basic version; 25ns are typical).

Alternatively, the event input of an other module may be used. All event signals arrive at the same signal line of the processor module as the input `Event In` does.



## 5.2.1 Pro-CPU-T9




Fig. 13 – Pro-CPU-T9: Block diagram

To be used for Pro system	Pro I
Processor	ADSP 21062
Clock rate	40MHz
Data connection	Link
Internal memory	256KiB, optional 512KiB
External memory	4MiB, optional 16 oder 32MiB
TTL-signal inputs	Event In

Fig. 14 – Pro-CPU-T9: Spezifikation




Fig. 15 – Pro-CPU-T9: Pin assignment




Fig. 16 – Pro-CPU-T9: Board and front panel

### 5.2.2 Pro-CPU-T9-ENET / -USB

The processor module is available with data connection Ethernet or USB.




Fig. 17 – Pro-CPU-T9-ENET / -USB: Block diagram

To be used for Pro system	Pro I
Processor	ADSP 21062
Clock rate	40MHz
Data connection	Ethernet or USB
Internal memory	256KiB, optional 512KiB
External memory	16MiB, optional 64MiB
TTL-signal inputs	Event In DigIn 0 (optional)

Fig. 18 – Pro-CPU-T9-ENET / -USB: Spezifikation




Fig. 19 – Pro-CPU-T9-ENET: Board and front panel




Fig. 20 – Pro-CPU-T9-USB: Board and front panel



## 5.2.4 Pro-Boot

With Pro-Boot you have a boot loader expansion which can

- boot an *ADwin-Pro* system.
- load up to 10 processes.
- start process 10 automatically (if present).
- save data.

Pro-Boot is an ordering option for processor modules with Ethernet interface. An upgrade is not possible.

The bootloader unit (including Flash EEPROM) is placed on an additional board:

- Pro-CPU-T9-ENET, Pro-CPU-T10-ENET

The bootloader is integrated on the Ethernet board. The module needs 1 slot in the Pro system.

The bootloader is programmed with the program *ADethflash*. (windows start menu under *Programs\ADwin*). *ADethflash* contains on-line notes for use.

- Pro-CPU-T9 (link interface)

The boot loader unit is placed on a separate board which is located between the SDRAM memory and the interface circuit board. The module's width is 10HP and needs 2 slots in the Pro system.




Fig. 24 – Example: Module Pro-CPU-T9 with Pro-Boot

The help file *ADBOOTLOAD.HLP* shows how to program of the boot-loader (see folder *<C:\ADwin\Tools\ADbootload\...>*). Please open the help file and continue according to the listed description.

By installation of the *ADbasic* and the *ADwin* drivers from the CDROM (version 3.0.22a6 or higher), all files/programs necessary for the boot loader option have already been copied to the hard disk.

If you use the boot loader, an application, which you have written with a program for visualization of measurement data, must not reboot the *ADwin* system.

## Hardware

## Software



### 5.2.5 The Watchdog

You can monitor your processor module with a watchdog. The watchdog generates a reset, when a signal, generated by a program code, does unexpectedly not arrive (see also "ADwin-Pro System Specifications - Programming in ADbasic"). This reset sets the digital and analog outputs to those values, which correspond to the configuration after power-up, normally digital 0 or 0 Volt.

Notes in relation to the Pro-Flash-Boot:

- Please pay attention to the fact that the watchdog has to be reset every 1.6s, since a longer time interval between two impulses will be interpreted as an error.
- The watchdog can also be used with the boot loader Pro-Flash-Boot, but does not automatically load and start the software.
- Test your programs always with the watchdog switched off. Activate it only when your programs work appropriately!



### 5.3 Pro I: Analog Input Modules

This section describes **ADwin-Pro I** modules.

Module name	Aln 8/12	Aln 8/12	Aln 8/14	Aln 32/12	Aln 16/14C	Aln 32/14	Aln 8/16	Aln 8/16	Aln 8/16	Aln 32/16	Aln 32/16	Aln 32/16	Aln F-4/12	Aln F-8/12	Aln F-4/14	Aln F-8/14	Aln F-4/16	Aln F-8/16
Revision	A	B	A	A	A	A	A	B	C	B	C	C	A	A	B	B	A	A
Number ADC	1	1	1	1	1	1	1	1	1	1	1	1	4	8	4	8	4	8
Resolution [Bit]	12	12	14	12	14	14	16	16	16	16	16	16	12	12	14	14	16	16
Conv. time [μs]	8.5	0.75	0.5	8.5	0.5	0.5	10	8	5	8	5	5	0.75	0.75	0.4	0.4	8	8
max. sampl. rate [ksample/s]	117 <sup>a</sup>	1250 <sup>a</sup>	2000	117 <sup>a</sup>	2000	2000	100 <sup>a</sup>	100 <sup>a</sup>	200	100 <sup>a</sup>	200	200	1250 <sup>b</sup>	1250 <sup>b</sup>	2200 <sup>b</sup>	2200 <sup>b</sup>	100	100
Channels diff.	8	8	8	16	16	16	8	8	8	16	16	16	4	8	4	8	4	8
Channels sg. end.	–	–	–	32	–	32	–	–	–	32	–	–	–	–	–	–	–	–
Voltage ±5V	x	–	–	x	–	–	x	x	x	x	x	x	x	x	x	x	x	x
±10V	x	x	x	x	–	–	x	–	–	–	–	–	–	–	–	–	–	–
0...10V	x	x	–	x	–	–	–	–	–	–	–	–	–	–	–	–	–	–
±20mA (opt.)	–	–	x	–	x	–	–	–	–	–	–	–	–	–	–	–	–	–
Gain	1, 2, 4, 8	1, 2, 4, 8	1, 2, 4, 8	1, 2, 4, 8	1, 2, 4, 8	1, 2, 4, 8	1, 2, 4, 8	1, 2, 4, 8	1, 2, 4, 8	1, 2, 4, 8	1, 2, 4, 8	1, 2, 4, 8	1	1	1, 2, 4, 8	1, 2, 4, 8	1	1
Calibration <sup>c</sup>	TR	TR	SW	TR	SW	SW	TR	SW	SW	SW	SW	SW	TR	TR	SW	SW	TR	TR
Page	21	24	26	28	31	36	36	38	41	43	45	47	49	51	54	56	58	60

a. To be achieved under favorable conditions: 1 input channel, time-optimized program

b. per ADC

c. SW: via software, TR: with trimmers; see chapter 6.3.



**Note for open-ended inputs**

Open-ended inputs can cause errors - above all in an environment where interferences may occur. You can avoid open-ended inputs this way:

- Separate unused inputs from open-ended lines.
- Apply a specified level (for instance GND) to unused inputs. Make the connection as close to the female connector as possible.



## 5.3.1 Pro-Aln-8/12 Rev. A

To this module you find an improved successor module Pro-Aln-8/14 Rev. A (see page 26).

The analog input module Pro-Aln-8/12 Rev. A has a 12 bit ADC and 8 differential inputs. A programmable amplifier (PGA) and a multiplexer (MUX) are connected before the ADC.

The inputs are available with the following connectors:

- Pro-Aln-8/12: shielded LEMO female connectors, CAMAC European norm.
- Pro-Aln-8/12-D: D-Sub female connector 37-pin.

The module can be combined with amplifiers, filters, thermocouples and PTC modules.

The input voltage range can be selected by jumpers (see page 22).




Fig. 25 – Pro-Aln-8/12 Rev. A: Block diagram

Input channels	8 differential via multiplexer
Resolution	12 bit
Conversion time	max. 8.5µs
Sampling rate	max. 117ksps
Measurement ranges	0...10V, ±5V, ±10V
Gain	software selectable: 1, 2, 4, 8
Accuracy	INL max. ±1 LSB
	DNL max. ±1 LSB
Input resistance	100kΩ, ±2%
Input over-voltage	±35V
Offset error	adjustable
Offset drift	±30 ppm/°C of full scale range
Connector	8 LEMO female connectors optional: 37-pin D-Sub female connector

Fig. 26 – Pro-Aln-8/12 Rev. A: Specification





Fig. 27 – Pro-AIn-8/12-D Rev. A: Pin assignment

Setting the Input Voltage Range

The input module Pro-AIn-8/12 Rev. A is equipped with an ADC whose input voltage range is adjustable by 2 jumpers. As a default setting, the ADC is set to the voltage range of  $\pm 10\text{V}$ . The settings for other voltage ranges can be found in fig. 29.



Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat



### 5.3.2 Pro-Aln-8/12 Rev. B

To this module you find an improved successor module Pro-Aln-8/14 Rev. A (see page 26).

The analog input module Pro-Aln-8/12 Rev. B has a 12 bit ADC and 8 differential inputs. A programmable amplifier (PGA) and a multiplexer (MUX) are connected before the ADC.

The inputs are available with the following connectors:

- Pro-Aln-8/12: shielded LEMO female connectors, CAMAC European norm.
- Pro-Aln-8/12-D: D-Sub female connector 37-pin.

The module can be combined with amplifiers, filters, Pro-TC and Pro-PT modules.

The input voltage range of the ADC can be set by DIL switches (see page 25).

The module Pro-Aln-8/12 Rev. B is an advanced development of the module Pro-Aln-8/12 Rev. A with an input voltage range of  $\pm 10\text{V}$  or  $0\dots 10\text{V}$  and a gain, programmable by software of 1, 2, 4 or 8. The adjustment of gain and offset is made by software (see chapter 6.3.1 "Calibration per Software", page 183).




Fig. 31 – Pro-Aln-8/12 Rev. B: Block diagram

Input channels	8 differential via multiplexer
Resolution	12 bit
Conversion time	max. 0.75μs
Sampling rate	max. 1250ksps
Multiplexer settling time	3μs
Measurement ranges	0...10V, $\pm 10\text{V}$
Gain	1, 2, 4, 8 software selectable
Accuracy	INL typ. $\pm 0.3$ LSB, max. $\pm 1$ LSB
	DNL typ. $\pm 0.3$ LSB, max. $\pm 1$ LSB
Input resistance	330kΩ, $\pm 2\%$
Input over-voltage	$\pm 17\text{V}$
Offset error	adjustable
Offset drift	$\pm 30$ ppm/°C
Connector	8 LEMO female connectors optional: 37-pin D-Sub female connector

Fig. 32 – Pro-Aln-8/12 Rev. B: Specification





Fig. 33 – Pro-AIn-8/12-D Rev. B: Pin assignment

## Setting the Input Voltage Range

The input module Pro-AIn-8/12 Rev. B is equipped with an ADC whose input voltage range is adjustable by 2 DIL switches. As a default setting, the ADC is set to the voltage range of  $\pm 10V$ . The settings for other voltage ranges can be found in fig. 34.



After every jumper setting you have to recalibrate the ADC, in order to assure correct measurement results. The adjustment of gain and offset is made by software. The individual steps are described in the chapter 6.3.1 "Calibration per Software", page 183.

Voltage range	DIL1	DIL2
$\pm 10V$ bipolar (default)	BIP	BIP
0...10V unipolar	UNI	UNI
not allowed	BIP	UNI
not allowed	UNI	BIP

Fig. 34 – Pro-AIn-8/12: DIL switch settings for the input voltage range

The following instructions are used to program the module:

Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

### 5.3.3 Pro-Aln-8/14 Rev. A

The analog input module Pro-Aln-8/14 Rev. A has a 14 bit ADC and 8 single ended inputs. A programmable amplifier (PGA) and a multiplexer (MUX) are connected before the ADC. The module can be combined with Pro-TC and Pro-PT modules.

The inputs are available with the following connectors:

- Pro-Aln-8/12: shielded LEMO female connectors, CAMAC European norm.
- Pro-Aln-8/12-D: D-Sub female connector 37-pin.

The module Pro-Aln-8/14 Rev. A is an advanced development of the module Pro-Aln-8/12 Rev. B with an input voltage range of  $\pm 10V$  and a gain, programmable by software of 1, 2, 4 or 8. The adjustment of gain and offset is made by software (see chapter 6.3.1 "Calibration per Software").

The module includes a programmable sequence control, which can read the measurement values of the specified input channel sequentially.




Fig. 35 – Pro-Aln-8/14 Rev. A: Block diagram

Input channels		8 differential via multiplexer
Resolution		14 bit
Conversion time		max. 0.5 $\mu$ s
Sampling rate		max. 2000ksps
Multiplexer settling time		3 $\mu$ s
Measurement ranges		$\pm 10V$ , optional: $\pm 20mA$ / 8 channels
Gain		1, 2, 4, 8 software selectable
Accuracy	INL	typ. $\pm 0.6$ LSB, max. $\pm 2$ LSB
	DNL	typ. $\pm 0.3$ LSB, max. $\pm 1$ LSB
	With the option $\pm 20mA$ there is an additional inaccuracy of 0.05% of the measured voltage (by the 500 $\Omega$ shunt).	
Input resistance		330k $\Omega$ , $\pm 2\%$
Input over-voltage		$\pm 35V$
Offset error		adjustable
Offset drift		$\pm 30$ ppm/ $^{\circ}C$
Connector		8 LEMO female connectors optional: 37-pin D-Sub female connector

Fig. 36 – Pro-Aln-8/14 Rev. A: Specification




Fig. 37 – Pro-AIn-8/14-D Rev. A: Pin assignment




Fig. 38 – Pro-AIn-8/14 Rev. A: Board and front panel

The following instructions are used to program the module:

Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Use sequence control	Seq_Mode, Seq_Read, Seq_Read32, Seq_Read_One, Seq_Read_Packed, Seq_Read_Two, Seq_Select, Seq_Set_Delay, Seq_Status
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

5.3.4 Pro-Aln-32/12 Rev. A

To this module you find an improved successor module Pro-Aln-32/14 Rev. A (see page 36).

The analog input module Pro-Aln-32/12 Rev. A is equipped with a 12-bit ADC and a programmable amplifier. It has 32 single-ended or 16 differential inputs (software-selectable). The inputs are connected to a 37-pin D-Sub female connector. The Pro-Aln-32/12 module offers options for combination with thermocouples and PTC-modules. The input voltage range of the ADC can be adjusted by jumpers (see page 29).




Fig. 39 – Pro-Aln-32/12 Rev. A: Block diagram



After power up the module Pro-Aln-32/12 is set to 16 differential inputs.

The figures 41 and 42 show the pin assignment of the module. Please consider the different pin assignment for differential and single-ended inputs.

Input channels		32 single-ended oder 16 differential
Resolution		12 bit
Conversion time		max. 8.5µs
Sampling rate		max. 117 ksps
Measurement ranges		0...10V, ±5V, ±10V optional 0-20mA / 16 channels
Gain		1, 2, 4, 8 software selectable
Accuracy	INL	max. ±1 LSB
	DNL	max. ±1 LSB
Input resistance		100kΩ, ±2%
Input over-voltage		±25V (peak ±35V)
Offset error		adjustable
Offset drift		±30 ppm/°C of full scale range
Connector		37-pin D-Sub female connector

Fig. 40 – Pro-Aln-32/12 Rev. A: Specification






Fig. 41 – Pro-Aln-32/12 Rev. A: Pin assignment single-ended




Fig. 42 – Pro-Aln-32/12 Rev. A: Pin assignment differential

## Setting the Input Voltage Range

The input module Pro-Aln-32/12 Rev. A is equipped with an ADC whose input voltage range is adjustable by 2 jumpers. As a default setting, the ADC is set to the voltage range of  $\pm 10V$ . The settings for other voltage ranges can be found in fig. 44.




Fig. 43 – Pro-Aln-32/12 Rev. A: Board and front panel

After every jumper setting you have to recalibrate the ADC, in order to assure correct measurement results. The individual steps are described in the chapter 6 "Calibration".

If you have a board with the imprint "19AD774" (in the upright corner) the jumpers are arranged in positions different to this description. Please ask our support to get the correct jumper positions.

For the accurate adjustment of offset and gain the potentiometers UPO (uni-polar) or BPO (bipolar) as well as GAIN are available (fig. 45).



## Programming

Voltage range	J1	J2
±5V bipolar	BIP	10V
±10V bipolar (default)	BIP	20V
0...10V unipolar	UNI	10V
not allowed (0...20V)	UNI	20V

Fig. 44 – Pro-AIn-32/12 Rev. A:  
Jumper positions

Potentiometer	Adjustment of
Gain	Gain factor
BPO	Offset (bipolar setting)
UPO	Offset (unipolar setting)

Fig. 45 – Pro-AIn-32/12 Rev. A: Function of the potentiometers

The following instructions are used to program the module:

Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Select input mode	SE_Diff
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## 5.3.5 Pro-Aln-32/12 Rev. B

To this module you find an improved successor module Pro-Aln-32/14 Rev. A (see page 36).

The analog input module Pro-Aln-32/12 Rev. B has a 12 bit ADC and a programmable gain (PGA). It is equipped with 32 single-ended inputs and 16 differential inputs (software-selectable). The inputs are connected on a 37-pin D-Sub female connector. The module can be combined with Pro-TC and Pro-PT modules. The input voltage range of the ADC can be set by jumpers (see page 32).

The module Pro-Aln-32/12 Rev. B is an advanced development of the module Pro-Aln-32/12 with an input voltage range of  $\pm 10V$  or  $0-10V$  and a gain, programmable by software of 1, 2, 4 or 8. The adjustment of gain and offset is made by software (see chapter 6.3.1 "Calibration per Software").




Fig. 46 – Pro-Aln-32/12 Rev. B: Block diagram

After power-up the module is set to 16 differential inputs.

Figures 48 and 49 show the pin assignment of the module. Please consider the different pin assignment for differential and single-ended inputs.



Input channels	32 single-ended oder 16 differential	
Resolution	12 bit	
Conversion time	max. 0.75µs	
Sampling rate	max. 1250ksps	
Multiplexer settling time	3µs	
Measurement ranges	0...10V, ±10V optional 0...20mA / 16 channels	
Gain	1, 2, 4, 8 software selectable	
Accuracy	INL	typ. ±0.3 LSB, max. ±1 LSB
	DNL	typ. ±0.3 LSB, max. ±1 LSB
Input resistance	330kΩ, ±2%	
Input over-voltage	±17V	
Offset error	adjustable	
Offset drift	±30 ppm/°C	
Connector	37-pin D-Sub female connector	

Fig. 47 – Pro-Aln-32/12 Rev. B: Specification




Fig. 48 – Pro-AIn-32/12 Rev. B: Pin assignment single-ended




Fig. 49 – Pro-AIn-32/12 Rev. B: Pin assignment differential

### Setting the Input Voltage Range

The input module Pro-AIn-32/12 Rev. B is equipped with an ADC whose input voltage range is adjustable by 2 DIL switches. As a default setting, the ADC is set to the voltage range of  $\pm 10V$ . The settings for other voltage ranges can be found in fig. 51.




Fig. 50 – Pro-AIn-32/12 Rev. B: Board and front panel



After every jumper setting you have to recalibrate the ADC, in order to assure correct measurement results. The adjustment of gain and offset is made by software. The individual steps are described in the chapter 6.3.1 "Calibration per Software", page 183.

Voltage range	DIL1	DIL2
$\pm 10V$ bipolar (default)	BIP	BIP
0...10V unipolar	UNI	UNI
not allowed	BIP	UNI
not allowed	UNI	BIP

Fig. 51 – Pro-AIn-32/12 Rev. B: DIL switch settings for the input voltage range

The following instructions are used to program the module:

Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Select input mode	SE_Diff
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

### 5.3.6 Pro-Aln-16/14-C Rev. A

The analog input module Pro-Aln-16/14-C Rev. A has a 14 bit ADC and a programmable gain (PGA). It is equipped with 16 differential current inputs (numbers 1...8 and 17...24). The inputs are connected to a 37-pin D-Sub female connector.

The module version with voltage inputs Pro-Aln-32/14 Rev. A is described on page 36.

The module Pro-Aln-16/14-C Rev. A has an input range of  $\pm 20\text{mA}$  and a gain, programmable by software of 1, 2, 4 or 8. The adjustment of gain and offset is made by software (see chapter 6.3.1 "Calibration per Software").

The module includes a programmable sequence control, which can read the measurement values of the specified input channel sequentially.




Fig. 52 – Pro-Aln-16/14-C Rev. A: Block diagram

Input channels	16 differential
Resolution	14 bit
Conversion time	max. $0.5\mu\text{s}$
Sampling rate	max. 2000ksp/s
Multiplexer settling time	$3\mu\text{s}$
Measurement ranges	$\pm 20\text{mA}$
Gain	1, 2, 4, 8 software selectable
Accuracy	INL typ. $\pm 0.6$ LSB, max. $\pm 1$ LSB +0.05% of measured voltage by input resistance
	DNL typ. $\pm 0.3$ LSB, max. $\pm 1$ LSB +0.05% of measured voltage by input resistance
Input resistance	$500\text{k}\Omega$ , $\pm 2\%$
Input over-voltage	$\pm 15\text{V}$
Offset error	adjustable
Offset drift	$\pm 30$ ppm/ $^{\circ}\text{C}$
Connector	37-pin D-Sub female connector

Fig. 53 – Pro-Aln-16/14-C Rev. A: Specification

ANALOG IN 1 (-)	● 19	ANALOG IN 1 (+)
ANALOG IN 2 (-)	● 18	ANALOG IN 2 (+)
ANALOG IN 3 (-)	● 17	ANALOG IN 3 (+)
ANALOG IN 4 (-)	● 16	ANALOG IN 4 (+)
ANALOG IN 5 (-)	● 15	ANALOG IN 5 (+)
ANALOG IN 6 (-)	● 14	ANALOG IN 6 (+)
ANALOG IN 7 (-)	● 13	ANALOG IN 7 (+)
ANALOG IN 8 (-)	● 12	ANALOG IN 8 (+)
ANALOG IN 17 (-)	● 11	ANALOG IN 17 (+)
ANALOG IN 18 (-)	● 10	ANALOG IN 18 (+)
ANALOG IN 19 (-)	● 9	ANALOG IN 19 (+)
ANALOG IN 20 (-)	● 8	ANALOG IN 20 (+)
ANALOG IN 21 (-)	● 7	ANALOG IN 21 (+)
ANALOG IN 22 (-)	● 6	ANALOG IN 22 (+)
ANALOG IN 23 (-)	● 5	ANALOG IN 23 (+)
ANALOG IN 24 (-)	● 4	ANALOG IN 24 (+)
AGND	● 3	AGND
EVENT IN	● 2	RESERVED
	● 1	DGND

Fig. 54 – Pro-Aln-16/14-C Rev. A:  
Pin assignment differential




Fig. 55 – Pro-Aln-16/14-C Rev. A: Board and front panel

The following instructions are used to program the module:

Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Use sequence control	Seq_Mode, Seq_Read, Seq_Read32, Seq_Read_One, Seq_Read_Packed, Seq_Read_Two, Seq_Select, Seq_Set_Delay, Seq_Status
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

### 5.3.7 Pro-Aln-32/14 Rev. A

The analog input module Pro-Aln-32/14 Rev. A has a 14 bit ADC and a programmable gain (PGA). It is equipped with 32 single-ended inputs or 16 differential inputs (software-selectable). The inputs are connected to a 37-pin D-Sub female connector. The module can be combined with Pro-TC and Pro-PT modules.

The module version with current inputs Pro-Aln-16/14-C Rev. A is described on page 34.

The module Pro-Aln-32/14 Rev. A is an advanced development of the module Pro-Aln-32/12 Rev. B. It has an input voltage range of  $\pm 10\text{V}$  and a gain, programmable by software of 1, 2, 4 or 8. The adjustment of gain and offset is made by software (see chapter 6.3.1 "Calibration per Software").

The module includes a programmable sequence control, which can read the measurement values of the specified input channel sequentially.




Fig. 56 – Pro-Aln-32/14 Rev. A: Block diagram



After power-up the module is set to 16 differential inputs.

Figures 58 and 59 show the pin assignment of the module. Please consider the different pin assignment for differential and single-ended inputs.

Input channels		32 single-ended oder 16 differential
Resolution		14 bit
Conversion time		max. $0.5\mu\text{s}$
Sampling rate		max. 2000ksp/s
Multiplexer settling time		$3\mu\text{s}$
Measurement ranges		$\pm 10\text{V}$ ; optional $0\dots 20\text{mA}$ / 16 channels
Gain		1, 2, 4, 8 software selectable
Accuracy	INL	typ. $\pm 0.6$ LSB, max. $\pm 1$ LSB
	DNL	typ. $\pm 0.3$ LSB, max. $\pm 1$ LSB
	With the option $\pm 20\text{mA}$ there is an additional inaccuracy of 0.05% of the measured voltage (by the $500\Omega$ shunt).	
Input resistance		$330\text{k}\Omega$ , $\pm 2\%$
Input over-voltage		$\pm 35\text{V}$
Offset error		adjustable
Offset drift		$\pm 30$ ppm/ $^{\circ}\text{C}$
Connector		37-pin D-Sub female connector

Fig. 57 – Pro-Aln-32/14 Rev. A: Specification






Fig. 58 – Pro-Aln-32/14 Rev. A:  
Pin assignment single-ended




Fig. 59 – Pro-Aln-32/14 Rev. A:  
Pin assignment differential




Fig. 60 – Pro-Aln-32/14 Rev. A: Board and front panel

The following instructions are used to program the module:

Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Select input mode	SE_Diff
Use sequence control	Seq_Mode, Seq_Read, Seq_Read32, Seq_Read_One, Seq_Read_Packed, Seq_Read_Two, Seq_Select, Seq_Set_Delay, Seq_Status
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

### Programming

### 5.3.8 Pro-Aln-8/16 Rev. A

To this module you find an improved successor module Pro-Aln-8/16 Rev. C (see page 43).

Analog input module Pro-Aln-8/16 Rev. A with a 16-bit ADC and 8 differential inputs. The module Pro-Aln-8/16 Rev. A has options for combination with thermocouples, filters and PTC-modules.

The inputs are available with the following connectors:

- Pro-Aln-8/16: shielded LEMO female connectors, CAMAC European norm.
- Pro-Aln-8/16-D: D-Sub female connector 37-pin.

The input voltage range of the ADC can be adjusted by jumpers (see below).




Fig. 61 – Pro-Aln-8/16 Rev. A: Block diagram

Input channels	8 differential via multiplexer	
Resolution	16 bit	
Conversion time	max. 10µs	
Sampling rate	1 channel continuously	max. 100ksps
	channels multiplexed	max. 66ksps
	discontinuously	max. 50ksps
Measurement ranges	0...10V, ±5V, ±10V	
Accuracy	INL	max. ±3 LSB
	DNL	max. +3, -2 LSB
Input resistance	100kΩ, ±2%	
Input over-voltage	±35V	
Offset error	adjustable	
Offset drift	±30 ppm/°C of full scale range	
Connector	8 LEMO female connectors optional: 37-pin D-Sub female connector	

Fig. 62 – Pro-Aln-8/16 Rev. A: Specification




Fig. 63 – Pro-AIn-8/16-D Rev. A: Pin assignment

Setting the Input Voltage Range

The input module Pro-AIn-8/16 Rev. A is equipped with an ADC whose input voltage range is adjustable by 3jumpers. As a default setting, the ADC is set to the voltage range of  $\pm 10\text{V}$ . The settings for other voltage ranges can be found in fig. 65.




Fig. 64 – Pro-AIn-8/16 Rev. A: Board and front panel

After every jumper setting you have to recalibrate the ADC, in order to assure correct measurement results. The individual steps are described in the chapter 6 "Calibration".

For the accurate adjustment of offset and gain the potentiometers UO (unipolar) or BO (bipolar) as well as GAIN are available (fig. 66).

Voltage range	J1	J2	J3
$\pm 5\text{V}$ bipolar	10V	20V	BIP
$\pm 10\text{V}$ bipolar (default)	10V	20V	BIP
0...10V unipolar	10V	10V	UNI
not allowed (0...20V)	20V	20V	UNI

Fig. 65 – Pro-AIn-8/16 Rev. A:  
Jumper settings for the input voltage range

Potentiometer	Adjustment of
Gain	Gain factor
BPO	Offset (bipolar setting)
UPO	Offset (unipolar setting)

Fig. 66 – Pro-AIn-8/16 Rev. A:  
Function of the potentiometers

**Programming**

The following instructions are used to program the module:

Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## 5.3.9 Pro-Aln-8/16 Rev. B

To this module you find an improved successor module Pro-Aln-8/16 Rev. C (see page 43).

The analog input module Pro-Aln-8/16 Rev. B has a 16-bit ADC, 8 differential inputs and a programmable gain (PGA). The module can be combined with amplifiers, filters, Pro-TC and Pro-PT modules.

The inputs are available with the following connectors:

- Pro-Aln-8/16: shielded LEMO female connectors, CAMAC European norm.
- Pro-Aln-8/16-D: D-Sub female connector 37-pin.

The module Pro-Aln-8/16 Rev. B is an advanced development of the module Pro-Aln-8/16 with an input voltage range of  $\pm 10V$  and a gain, programmable by software of 1, 2, 4 or 8. The adjustment of gain and offset is made by software (see chapter 6.3.1 "Calibration per Software").




Fig. 67 – Pro-Aln-8/16 Rev. B: Block diagram

Input channels	8 differential via multiplexer
Resolution	16 bit
Conversion time	max. 8μs
Sampling rate	max. 100ksps
Multiplexer settling time	14μs
Measurement ranges	$\pm 10V$
Gain	1, 2, 4, 8 software selectable
Accuracy	INL
	DNL
	$\pm 3$ LSB typical
	max. $\pm 1$ LSB
Input resistance	330kΩ, $\pm 2\%$
Input over-voltage	$\pm 17V$
Offset error	adjustable
Offset drift	$\pm 20$ ppm/°C
Connector	8 LEMO female connectors optional: 37-pin D-Sub female connector

Fig. 68 – Pro-Aln-8/16 Rev. B: Specification




Fig. 69 – Pro-Aln-8/16-D Rev. B: Pin assignment differential




Fig. 70 – Pro-Aln-8/16 Rev. B: Board and front panel

Programming

The following instructions are used to program the module:

Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## 5.3.10 Pro-Aln-8/16 Rev. C

The analog input module Pro-Aln-8/16 Rev. C has a 16-bit ADC, 8 differential inputs and a programmable gain (PGA). The module can be combined with amplifiers, filters, Pro-TC and Pro-PT modules.

The inputs are available with the following connectors:

- Pro-Aln-8/16: shielded LEMO female connectors, CAMAC European norm.
- Pro-Aln-8/16-D: D-Sub female connector 37-pin.

The module Pro-Aln-8/16 Rev. C is an advanced development of the Pro-Aln-8/16 Rev. B with an input voltage range of  $\pm 10V$  and a gain, programmable by software of 1, 2, 4 or 8. The adjustment of gain and offset is made by software (see chapter 6.3.1 "Calibration per Software").

The module includes a programmable sequence control, which can read the measurement values of the specified input channel sequentially.




Fig. 71 – Pro-Aln-8/16 Rev. C: Block diagram

Input channels	8 differential via multiplexer
Resolution	16 bit
Conversion time	max. 5 $\mu$ s
Sampling rate	max. 200ksps
Multiplexer settling time	6 $\mu$ s
Measurement ranges	$\pm 10V$
Gain	1, 2, 4, 8 software selectable
Accuracy	INL $\pm 2$ LSB typical
	DNL max. $\pm 1$ LSB
Input resistance	330k $\Omega$ , $\pm 2\%$
Input over-voltage	$\pm 35V$
Offset error	adjustable
Offset drift	$\pm 30$ ppm/ $^{\circ}C$
Connector	8 LEMO female connectors optional: 37-pin D-Sub female connector

Fig. 72 – Pro-Aln-8/16 Rev. C: Specification




Fig. 73 – Pro-Aln-8/16-D Rev. C: Pin assignment differential




Fig. 74 – Pro-Aln-8/16 Rev. C: Board and front panel

Programming

The following instructions are used to program the module:

Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Use sequence control	Seq_Mode, Seq_Read, Seq_Read32, Seq_Read_One, Seq_Read_Packed, Seq_Read_Two, Seq_Select, Seq_Set_Delay, Seq_Status
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat



## 5.3.11 Pro-Aln-32/16 Rev. B

To this module you find an improved successor module Pro-Aln-32/16 Rev. C (see page 47).

The analog input module Pro-Aln-32/16RB has a 16-bit ADC and a programmable gain amplifier (PGA). It has 32 single-ended or 16 differential inputs (software selectable). The inputs are connected on a 37-pin D-Sub female connector. The module can be combined with Pro-TC and Pro-PT modules.

The module Pro-Aln-32/16RB is equipped with an input voltage range of  $\pm 10V$  and a gain amplifier, programmable by software to 1, 2, 4 or 8. The adjustment of gain and offset is made by software (see chapter 6.3.1 "Calibration per Software").




Fig. 75 – Pro-Aln-32/16 Rev. B: Block diagram

On Startup the module is set to 16 differential inputs.

Figures 77 and 78 show the pin assignments of the module. Please consider the different pin assignment for differential and single-ended inputs.



Input channels:	32 single-ended oder 16 differetial; via multiplexer
Resolution:	16 bit
Conversion time:	max. 8 $\mu$ s
Sampling rate:	max. 100ksp/s
Multiplexer settling time:	14 $\mu$ s
Measurement ranges:	$\pm 10V$
Gain:	1, 2, 4, 8 software selectable
Accuracy	INL
	DNL
	max. $\pm 3$ LSB
	max. +3, -2 LSB
Input resistance:	330k $\Omega$ , $\pm 2\%$
Input over-voltage:	$\pm 17V$
Offset error:	adjustable
Offset drift:	$\pm 20$ ppm/ $^{\circ}C$
Connector:	37-pin D-Sub female connector

Fig. 76 – Pro-Aln-32/16 Rev. B: Specification




Fig. 77 – Pro-Aln-32/16 Rev. B: Pin assignment single-ended




Fig. 78 – Pro-Aln-32/16 Rev. B: Pin assignment differential




Fig. 79 – Pro-Aln-32/16 Rev. B: Board and front panel

Programming

The following instructions are used to program the module:

Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Select input mode	SE_Diff
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## 5.3.12 Pro-Aln-32/16 Rev. C

The analog input module Pro-Aln-32/16 Rev. C has a 16-bit ADC and a programmable gain amplifier (PGA). It has 32 single-ended or 16 differential inputs (software selectable). The inputs are connected to a 37-pin D-Sub female connector. The module can be combined with amplifiers, filters, Pro-TC and Pro-PT modules.

The module Pro-Aln-32/16 Rev. C is equipped with an input voltage range of  $\pm 10V$  and a gain amplifier, programmable by software to 1, 2, 4 or 8. The adjustment of gain and offset is made by software (see chapter 6.3.1 "Calibration per Software").

The module includes a programmable sequence control, which can read the measurement values of the specified input channel sequentially.




Fig. 80 – Pro-Aln-32/16 Rev. C: Block diagram

On Startup the module is set to 16 differential inputs.

Figures 82 and 83 show the pin assignments of the module. Please consider the different pin assignment for differential and single-ended inputs.



Input channels:	32 single-ended oder 16 differential; via multiplexer	
Resolution:	16 bit	
Conversion time:	max. 5 $\mu s$	
Sampling rate:	max. 200 ksp/s	
Multiplexer settling time:	6 $\mu s$	
Measurement ranges:	$\pm 10V$	
Gain:	1, 2, 4, 8 software selectable	
Accuracy	INL	max. $\pm 2$ LSB
	DNL	max. $\pm 1$ LSB
Input resistance:	330 k $\Omega$ , $\pm 2\%$	
Input over-voltage:	$\pm 35V$	
Offset error:	adjustable	
Offset drift:	$\pm 30$ ppm/ $^{\circ}C$	
Connector:	37-pin D-Sub female connector	

Fig. 81 – Pro-Aln-32/16 Rev. C: Specification




Fig. 82 – Pro-Aln-32/16 Rev. C: Pin assignment single-ended




Fig. 83 – Pro-Aln-32/16 Rev. C: Pin assignment differential




Fig. 84 – Pro-Aln-32/16 Rev. C: Board and front panel

## Programming

The following instructions are used to program the module:

Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Select input mode	SE_Diff
Use sequence control	Seq_Mode, Seq_Read, Seq_Read32, Seq_Read_One, Seq_Read_Packed, Seq_Read_Two, Seq_Select, Seq_Set_Delay, Seq_Status
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## 5.3.13 Pro-Aln-F-4/12 Rev. A

Analog input module Pro-Aln-F-4/12 Rev. A with 4 ADC (12 bit) and 4 differential inputs.

The inputs are equipped with shielded LEMO female connectors (CAMAC European norm).

For the accurate adjustment of offset and gain the potentiometers Ox and Gx are available (fig. 88); you find information about the accurate adjustment on page 52. The "x" of the potentiometer's names are place holders for the number of the corresponding ADC. The potentiometer names are imprinted on the board.




Fig. 85 – Pro-Aln-F-4/12 Rev. A: Block diagram

Input channels	4 differential	
Resolution	12 bit	
Conversion time	max. 0.75μs (per ADC)	
Sampling rate	max. 1250ksps (per ADC)	
Measurement ranges	±10V	
Accuracy	INL	typ. ±0.3 LSB, max. ±1 LSB
	DNL	typ. ±0.3 LSB, max. ±1 LSB
Input resistance	100kΩ, ±2%	
Input over-voltage	±35V	
Offset error	adjustable	
Offset drift	±30 ppm/°C of full scale range	
Connector	4 LEMO female connectors optional: 37-pin D-Sub female connector	

Fig. 86 – Pro-Aln-F-4/12 Rev. A: Specification




Fig. 87 – Pro-AIn-F-4/12-D Rev. A: Pin assignment differential




Fig. 88 – Pro-AIn-F-4/12 Rev. A: Board and front panel

Programming

The following instructions are used to program the module:

Convert and read input	ADCF, Start_ConvF, Wait_EOCF, ReadADCF, ReadADCF_32, Read_ADCF4, Read_ADCF4_Packed, ReadADCF_SConv, ReadADCF_SConv_32
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## 5.3.14 Pro-Aln-F-8/12 Rev. A

Analog input module Pro-Aln-F-8/12 Rev. A with 8 ADC (12 bit) and 8 differential inputs.

The inputs are equipped with shielded LEMO female connectors (CAMAC European norm).

For the accurate adjustment of offset and gain the potentiometers Ox and Gx are available (fig. 92); you find information about the accurate adjustment on page 52.




Fig. 89 – Pro-Aln-F-8/12 Rev. A: Block diagram

Input channels	8 differential	
Resolution	12 bit	
Conversion time	max. 0.75μs (per ADC)	
Sampling rate	max. 1250ksps (per ADC)	
Measurement ranges	±10V	
Accuracy	INL	typ. ±0.3 LSB, max. ±1 LSB
	DNL	typ. ±0.3 LSB, max. ±1 LSB
Input resistance	100kΩ, ±2%	
Input over-voltage	±35V	
Offset error	adjustable	
Offset drift	±30 ppm/°C of full scale range	
Connector	8 LEMO female connectors optional: 37-pin D-Sub female connector	

Fig. 90 – Pro-Aln-F-8/12 Rev. A: Specification




Fig. 91 – Pro-Aln-F-8/12-D Rev. A: Pin assignment differential




Fig. 92 – Pro-Aln-F-8/12 Rev. A: Board and front panel

Setting Offset and Gain factor

The analog input modules Pro-Aln-F-4/12 Rev. A and Pro-Aln-F-4/16 Rev. A are equipped with each 4 ADC, the modules Pro-Aln-F-8/12 Rev. A and Pro-Aln-F-8/16 Rev. A with each 8 ADC. The ADC 1 to 4 are on the base PCB and the ADC 5 to 8 are on an additional PCB which will be plugged into the base PCB. The input voltage of the ADC is fixed to  $\pm 10V$ .

The potentiometers Ox and Gx are used for an accurate adjustment of gain and offset (fig. 93). The "x" in the potentiometer's names stands for the number of the corresponding ADC. The potentiometer names are printed on the boards.

When testing the modules, the potentiometers have been optimally adjusted. Therefore we ask you to avoid adjusting the potentiometers if not necessary, because this may result in inaccuracy. The calibration of the ADC is described in the chapter 6 "Calibration".

Potentiometer	Adjustment of
Gx	Gain factor
Ox	Offset

Fig. 93 – Pro-Aln-F-8/12 Rev. A: Function of the potentiometers



The following instructions are used to program the module:

Convert and read input	ADCF, Start_ConvF, Wait_EOCF, ReadADCF, ReadADCF_32, Read_ADCF4, Read_ADCF4_Packed, Read_ADCF8, Read_ADCF8_Packed, ReadADCF_SConv, ReadADCF_SConv_32
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

### 5.3.15 Pro-Aln-F-4/14 Rev. B

Analog input module Pro-Aln-F-4/14 Rev. B with 4 fast-ADC (14 bit) and 4 differential inputs.

The inputs are available with the following connectors:

- Aln-4/14: shielded LEMO female connectors, CAMAC European norm.
- Aln-4/14-D: D-Sub female connector 37-pin.

The module has 2 operating modes, which you can use optionally for each of the channels:

- Standard individual measurement: Upon each process call an individual measurement can be executed by starting the conversion (waiting for its end), by reading out the measurement values and if necessary by processing them.
- Start of a burst measurement sequence: Upon each process call a complete measurement sequence, which consists of a large number of individual measurements, is started. The module executes the measurement sequence alone, independent of the **ADwin** system.

The measurement values—number and measurement frequency be defined in the program—are stored in a special burst memory of the module, enabling measurement frequencies of up to 2MHz. The size of burst memory limits the number of measurement values or the total time of the measurement.

Only after end of the measurement sequence will you be able to read out the stored measurement values from the burst memory and process them.

During an individual measurement the processor of the **ADwin-Pro** system is checking the sequence of each individual measurement, whereas during a burst measurement it is the module which is checking the measurement sequence.




Fig. 94 – Pro-Aln-F-4/14 Rev. B: Block diagram

Input channels	4 differential
Resolution	14 bit
Conversion time	max. 0.4µs (per ADC)
Sampling rate	max. 2200ksps (per ADC)
Memory size	$2^{20}-1 = 1048575$ measurement values total
Measurement ranges	±10V
Accuracy INL	max. ±2 LSB (>1000ksps ±3 LSB, >1500ksps ±4 LSB)
DNL	±2 LSB typical
Input resistance	100kΩ, ±2%

Fig. 95 – Pro-Aln-F-4/14 Rev. B: Specification

Input over-voltage	±35 V
Offset error	adjustable
Offset drift	±30 ppm/°C of full scale range
Connector	4 LEMO female connectors optional: 37-pin D-Sub female connector

Fig. 95 – Pro-AIn-F-4/14 Rev. B: Specification




Fig. 96 – Pro-AIn-F-4/14-D Rev. B: Pin assignment differential




Fig. 97 – Pro-AIn-F-4/14 Rev. B: Board and front panel

The following instructions are used to program the module:

Convert and read input	ADCF, Start_ConvF, Wait_EOCF, ReadADCF, ReadADCF_32, Read_ADCF4, Read_ADCF4_Packed, Read_ADCF8, Read_ADCF8_Packed, ReadADCF_SConv, ReadADCF_SConv_32
Use burst measurement	Burst_Abort, Burst_CRead, Burst_CStart, Burst_Init, Burst_Read, Burst_Read_Packed, Burst_Start, Burst_Status
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

### 5.3.16 Pro-Aln-F-8/14 Rev. B

Analog input module Pro-Aln-F-8/14 Rev. B with 8 fast-ADC (14 bit) and 8 differential inputs.

The inputs are available with the following connectors:

- Aln-4/14: shielded LEMO female connectors, CAMAC European norm.
- Aln-4/14-D: D-Sub female connector 37-pin.

The module has 2 operating modes, which you can use optionally for each of the channels:

- Standard single measurement: Upon each process call a single measurement can be executed by starting the conversion (waiting for its end), by reading out the measurement values and if necessary by processing them.
- Start of a burst measurement sequence: Upon each process call a complete measurement sequence, which consists of a large number of individual measurements, is started. The module executes the measurement sequence alone, independent of the **ADwin** system.

The measurement values—number and measurement frequency be defined in the program—are stored in a special burst memory of the module, enabling measurement frequencies of up to 2MHz. The size of burst memory limits the number of measurement values or the total time of the measurement.

Only after end of the measurement sequence will you be able to read out the stored measurement values from the burst memory and process them.

During a single measurement the processor of the **ADwin-Pro** system is checking the sequence of each individual measurement, whereas during a burst measurement it is the input module which is checking the measurement sequence.




Fig. 98 – Pro-Aln-F-8/14 Rev. B: Block diagram

Input channels	8 differential
Resolution	14 bit
Conversion time	max. 0.4μs (per ADC)
Sampling rate	max. 2200ksps (per ACDC)
Memory size	2 <sup>20</sup> -1 = 1048575 meas. values total
Measurement ranges	±10V
Accuracy	INL
	DNL
	max. ±2 LSB (>1000ksps ±3 LSB, >1500ksps ±4 LSB)
	±2 LSB typical
Input resistance	100kΩ, ±2%

Fig. 99 – Pro-Aln-F-8/14 Rev. B: Specification

Input over-voltage	±35 V
Offset error	adjustable
Offset drift	±30 ppm/°C of full scale range
Connector	8 LEMO female connectors optional: 37-pin D-Sub female connector

Fig. 99 – Pro-AIn-F-8/14 Rev. B: Specification




Fig. 100 – Pro-AIn-F-8/14-D Rev. B: Pin assignment differential




Fig. 101 – Pro-AIn-F-8/14 Rev. B: Board and front panel

The following instructions are used to program the module:

Convert and read input	ADCF, Start_ConvF, Wait_EOCF, ReadADCF, ReadADCF_32, Read_ADCF4, Read_ADCF4_Packed, Read_ADCF8, Read_ADCF8_Packed, ReadADCF_SConv, ReadADCF_SConv_32
Use burst measurement	Burst_Abort, Burst_CRead, Burst_CStart, Burst_Init, Burst_Read, Burst_Read_Packed, Burst_Start, Burst_Status
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

### 5.3.17 Pro-AIn-F-4/16 Rev. A

Analog input module Pro-AIn-F-4/16 Rev. A with 4 ADC (16 bit) and 4 differential inputs.

The inputs are available with the following connectors:

- Pro-AIn-4/16: shielded LEMO female connectors, CAMAC European norm.
- Pro-AIn-4/16-D: D-Sub female connector 37-pin.

For the accurate adjustment of offset and gain the potentiometers Ox and Gx are available (fig. 105); you find information about the accurate adjustment on page 52. The "x" of the potentiometer's names are place holders for the number of the corresponding ADC. The potentiometer names are imprinted on the board.




Fig. 102 – Pro-AIn-F-4/16 Rev. A: Block diagram

Input channels	4 differential
Resolution	16 bit
Conversion time	max. 8μs (per ADC)
Sampling rate	max. 100ksps (per ADC)
Measurement ranges	±10V
Accuracy	INL ±3 LSB typical
	DNL max. ±1 LSB
Input resistance	100kΩ, ±2%
Input over-voltage	±35V
Offset error	adjustable
Offset drift	±30 ppm/°C of full scale range
Connector	4 LEMO female connectors optional: 37-pin D-Sub female connector

Fig. 103 – Pro-AIn-F-4/16 Rev. A: Specification




Fig. 104 – Pro-AIn-F-4/16-D Rev. A: Pin assignment differential




Fig. 105 – Pro-AIn-F-4/16 Rev. A: Board and front panel

The following instructions are used to program the module:

Convert and read input	ADCF, Start_ConvF, Wait_EOCF, ReadADCF, ReadADCF_32, Read_ADCF4, Read_ADCF4_Packed, ReadADCF_SConv, ReadADCF_SConv_32
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

Programming

### 5.3.18 Pro-AIn-F-8/16 Rev. A

Analog input module Pro-AIn-F-8/16 Rev. A with 8 ADC (16 bit) and 8 differential inputs.

The inputs are available with the following connectors:

- Pro-AIn-8/16: shielded LEMO female connectors, CAMAC European norm.
- Pro-AIn-8/16-D: D-Sub female connector 37-pin.

For the accurate adjustment of offset and gain the potentiometers Ox and Gx are available (fig. 109); you find information about the accurate adjustment on page 52. The "x" of the potentiometer's names are place holders for the number of the corresponding ADC. The potentiometer names are imprinted on the board.




Fig. 106 – Pro-AIn-F-8/16 Rev. A: Block diagram

Input channels	8 differential
Resolution	16 bit
Conversion time	max. 8μs (per ADC)
Sampling rate	max. 100ksps (per ADC)
Measurement ranges	±10V
Accuracy	INL
	DNL
	±3 LSB typical
	max. ±1 LSB
Input resistance	100kΩ, ±2%
Input over-voltage	±35V
Offset error	adjustable
Offset drift	±30 ppm/°C of full scale range
Connector	8 LEMO female connectors optional: 37-pin D-Sub female connector

Fig. 107 – Pro-AIn-F-8/16 Rev. A: Specification






Fig. 108 – Pro-AIn-F-8/16-D Rev. A: Pin assignment differential




Fig. 109 – Pro-AIn-F-8/16 Rev. A: Board and front panel

The following instructions are used to program the module:

Convert and read input	ADCF, Start_ConvF, Wait_EOCF, ReadADCF, ReadADCF_32, Read_ADCF4, Read_ADCF4_Packed, Read_ADCF8, Read_ADCF8_Packed, ReadADCF_SConv, ReadADCF_SConv_32
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

Programming

## 5.4 Pro I: Analog Output Modules

Module name	AOut 4/16	AOut 4/16	AOut 4/16	AOut 4/16-M2	AOut 8/16	AOut 8/16	AOut 8/16
Rev.	A	B	C		A	B	C
No. ADC	4	4	4		8	8	8
Resolution [bit]	16	16	16		16	16	16
max. settling time [μs]	20 + 3	< 3	< 3		20 + 3	< 3	< 3
Channels sng. end.	4	4	4		8	8	8
Voltage range	±5V	x	x	—	x	x	—
	±10V	x	x	x	x	x	x
	0...5V	x	x	—	x	x	—
	0...10V	x	x	—	x	x	—
add. memory (option)	—	—	—	2MiB	—	—	—
Calibration <sup>a</sup>	TR	TR	SW		TR	TR	SW
page	63	68	71		65	68	73

a. SW: per software, TR: with trimmers

## 5.4.1 Pro-AOut-4/16 Rev. A

The analog output module Pro-AOut-4/16 Rev. A has 4 DAC (16 bit) with fixed 1<sup>st</sup> order low-pass filters ( $f_c = 100\text{kHz}$ ) to cut off glitches. The DAC are serial, causing an output delay of  $3\mu\text{s}$ .

Please note that the module is only usable in a Pro I system, the module is not supported in a Pro II system.

The outputs are available with the following connectors:

- Pro-AOut-4/16: shielded LEMO female connectors, CAMAC European norm.
- Pro-AOut-4/16-D: D-Sub female connector 37-pin.

Jumpers are used to set the output voltage range of the DAC (see page 66).




Fig. 110 – Pro-AOut-4/16 Rev. A: Block diagram

Output channels	4 single-ended
Resolution	16 bit
Settling time to 0.01% FSR	$20\mu\text{s} + 3\mu\text{s}$ output delay, for full scale step
Output voltage	$0 \dots 10\text{V}$ , $\pm 5\text{V}$ , $\pm 10\text{V}$
Output current max.	$\pm 5\text{mA}$ per channel
Accuracy	INL max. $\pm 4$ LSB
	DNL max. $\pm 4$ LSB
Offset error	adjustable
Gain error	adjustable
Offset drift	$\pm 10\mu\text{V}/^\circ\text{C}$
Connector	4 LEMO female connectors optional: 37-pin D-Sub female connector

Fig. 111 – Pro-AOut-4/16 Rev. A: Specification




Fig. 112 – Pro-AOut-4/16-D Rev. A: Pin assignment differential




Fig. 113 – Pro-AOut-4/16 Rev. A: Board and front panel

## Programming

The following instructions are used to program the module:

Output a value	DAC, Start_DAC, Write_DAC
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## 5.4.2 Pro-AOut-8/16 Rev. A

The analog output module Pro-AOut-8/16 Rev. A has 8 DAC (16 bit) with fixed 1<sup>st</sup> order low-pass filters ( $f_c = 100\text{kHz}$ ) to cut off glitches. The DAC are serial, causing an output delay of  $3\mu\text{s}$ .

Please note that the module is only usable in a Pro I system, the module is not supported in a Pro II system.

The outputs are available with the following connectors:

- Pro-AOut-4/16: shielded LEMO female connectors, CAMAC European norm.
- Pro-AOut-4/16-D: D-Sub female connector 37-pin.

Jumpers are used to set the output voltage range of the DAC (see page 66).






Fig. 114 – Pro-AOut-8/16 Rev. A: Block diagram

Output channels	8 single-ended
Resolution	16 bit
Settling time to 0.01% FSR	$20\mu\text{s} + 3\mu\text{s}$ output delay, for full scale step
Output voltage	$0 \dots 10\text{V}$ , $\pm 5\text{V}$ , $\pm 10\text{V}$
Output current max.	$\pm 5\text{mA}$ per channel
Accuracy	INL max. $\pm 4$ LSB
	DNL max. $\pm 2$ LSB
Offset error	adjustable
Gain error	adjustable
Offset drift	$\pm 10\mu\text{V}/^\circ\text{C}$
Connector	8 LEMO female connectors optional: 37-pin D-Sub female connector

Fig. 115 – Pro-AOut-8/16 Rev. A: Specification



## Setting the Output Voltage Range

The module Pro-AOut-4/16 Rev. A is equipped with 4 DAC, the module Pro-AOut-8/16 Rev. A with 8 DAC. The DAC 1 to 4 are on the base PCB and the DAC 5 to 8 are mounted on an additional PCB which will be plugged into the base PCB.

The output voltage of the DAC can be set by two jumpers. As a default setting all DAC are set to the voltage range of  $\pm 10V$ . If you want to adjust the DAC 1 to 4 on the base PCB of the output module Pro-AOut-8/16 you have to remove the additional PCB which is fixed by two screws.

In fig. 118 all possibilities to adjust the jumpers are listed. The "x" in the potentiometer title stands for the number of the corresponding DAC (see PCB imprint near to the potentiometers).

The potentiometers U0x, Bx and Gainx are used for an accurate adjustment of gain and offset (fig. 119).

Voltage range	Jx1	Jx2
±5V bipolar	BIP	10V
±10V bipolar (default)	BIP	20V
0...10V unipolar	UNI	10V
not allowed (0...20V)	UNI	20V

Fig. 118 – Pro-AOut-8/16 Rev. A:  
Jumper positions for the output  
voltage range

Potenti-ometer	Adjustment of
Gain	Gain factor
BPO	Offset (bipolar setting)
UPO	Offset (unipolar setting)

Fig. 119 – Pro-AOut-8/16 Rev. A:  
Function of the potentiometers

The following instructions are used to program the module:

Output a value	DAC, Start_DAC, Write_DAC
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

### 5.4.3 Pro-AOut-4/16 Rev. B, Pro-AOut-8/16 Rev. B

The analog output module Pro-AOut-4/16 Rev. B (before: Version 2) has 4 DAC (16 bit). The module Pro-AOut-8/16 Rev. B (before: Version 2) has 8 DAC (16 bit).

The outputs are available with the following connectors:

- Pro-AOut-4/16, Pro-AOut-8/16: shielded LEMO female connectors, CAMAC European norm.
- Pro-AOut-4/16-D, Pro-AOut-8/16-D: D-Sub female connector 37-pin.

Both modules have a fixed 1<sup>st</sup> order low-pass filter ( $f_c = 890\text{kHz}$ ) in order to avoid interferences. The outputs are equipped with shielded LEMO female connectors (CAMAC European norm). The output voltage range of the DAC can be set by two DIL switches (see page 69). The adjustment of gain and off-set is made by software (see chapter 6.3.1 "Calibration per Software").




Fig. 120 – Pro-AOut-4/16 Rev. B, Pro-AOut-8/16 Rev. B: Block diagram



Output channels	4 bzw. 8 single-ended
Resolution	16 bit
Settling time to 0.01% FSR	< 3µs
Output voltage	0...10V, 0...5V, ±5V, ±10V
Output current max.	±5mA per channel
Accuracy	INL ±2 LSB typical
	DNL ±1 LSB typical
Offset error	adjustable
Gain error	adjustable
Offset drift	±10µV/°C
Connector	4 or 8 LEMO female connectors optional: 37-pin D-Sub female connector

Fig. 121 – Pro-AOut-4/16 Rev. B, Pro-AOut-8/16 Rev. B: Specification




Fig. 122 – Pro-AOut-4/16 Rev. B: Pin assignment




Fig. 123 – Pro-AOut-8/16 Rev. B: Pin assignment

## Setting the Output Voltage Range

The output voltage range of every DAC can be set by 2 DIL switches. The default setting of the DAC is the voltage range ±10V.




Fig. 124 – Pro-AOut-4/16 Rev. B: Board and front panel




Fig. 125 – Pro-AOut-8/16 Rev. B: Board and front panel

Figure 126 illustrates all possible DIL switch positions. The "x" in the DIL switch title stands for the number of the corresponding DAC (see fig. 124/125). The adjustment of gain and offset is made by software (see chapter 6.3.1 "Calibration per Software").

If nothing else has been specified upon ordering the module, the voltage range is set to  $\pm 10\text{V}$ . Each time you change the DIL switch settings you have to recalibrate the ADC, in order to assure good measurement results.

Voltage range	DILx1	DILx2
$\pm 5\text{V}$ bipolar	5V	BIP
$\pm 10\text{V}$ bipolar (default)	10V	BIP
0...5V unipolar	5V	UNI
0...10V unipolar	10V	UNI

Fig. 126 – Pro-AOut-4/16 Rev. B, Pro-AOut-8/16 Rev. B: DIL switch settings for the output voltage range

Programming

The following instructions are used to program the module:

Output a value	DAC, Start_DAC, Write_DAC
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## 5.4.4 Pro-AOut-4/16 Rev. C

The analog output module Pro-AOut-4/16 Rev. C has four 16-bit DACs and has in its basic version the same functions as the previous version (Rev. B).

The output voltage range of the DACs is set to  $\pm 10V$  bipolar and can't be changed. Offset and gain are adjusted by software (see chapter 6.3.1 "Calibration per Software").

The outputs are available with the following connectors:

- Pro-AOut-4/16, Pro-AOut-4/16-M2: shielded LEMO female connectors, CAMAC European norm.
- Pro-AOut-4/16-D, Pro-AOut-4/16-M2-D: D-Sub fem. connector 37-pin

In the version ...-M2 the module has an additional internal memory (SRAM) of 2MB for a function generator.

In the memory data any wave forms are stored, which the function generator outputs with a specified output frequency. For each output channel wave form data, output frequency, output start and end can be set individually.

The output frequency may be set in the range 0.15Hz...1.0MHz.




Fig. 127 – Pro-AOut-4/16 Rev. C: Block diagram

Output channels	4 single ended
Resolution	16-bit
Settling time to 0.01% FSR	< 3 $\mu$ s
Output voltage	$\pm 10V$
Output current max.	$\pm 5mA$ per channel for optimal function $\pm 35mA$ technically possible, short-circuit-proof
Accuracy	INL $\pm 2$ LSB typical
	DNL $\pm 1$ LSB typical
Offset error	adjustable
Gain error	adjustable
Offset drift	$\pm 10 \mu V/^{\circ}C$
Addition memory for the function generator (optional)	2MiB
Connectors	4 LEMO female connectors optional: 37-pin D-SUB female connector

Fig. 128 – Pro-AOut-4/16 Rev. C: Specification

function generator




Fig. 129 – Pro-AOut-4/16-D Rev. C: Pin assignment




Fig. 130 – Pro-AOut-4/16 Rev. C: Printed circuit board (detail) and front panels

## Programming

The following instructions are used to program the module:

Output a value	DAC, Start_DAC, Write_DAC
Use function generator (AOut-4/16-M2)	FG_Control, FG_Def, FG_Delay, FG_Mode, FG_Read_Index, FG_Status, FG_Write
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## 5.4.5 Pro-AOut-8/16 Rev. C

The analog output module Pro-AOut-8/16 Rev. C has eight 16-bit DACs and the same functions as the previous module (Rev. B).

The output voltage range of the DACs is set to  $\pm 10V$  bipolar and can't be changed. Offset and gain are adjusted by software (see chapter 6.3.1 "Calibration per Software").

The outputs are available with the following connectors:

- Pro-AOut-8/16: shielded LEMO female connectors, CAMAC European norm.
- Pro-AOut-8/16-D: D-Sub female connector 37-pin.




Fig. 131 – Pro-AOut-8/16 Rev. C: Block diagram

Output channels	8 single ended	
Resolution	16-bit	
Settling time to 0.01% FSR	< 3 $\mu$ s	
Output voltage	$\pm 10V$	
Output current max.	$\pm 5mA$ per channel for optimal function $\pm 35mA$ technically possible, short-circuit-proof	
Accuracy	INL	$\pm 2$ LSB typical
	DNL	$\pm 1$ LSB typical
Offset error	adjustable	
Gain error	adjustable	
Offset drift	$\pm 10 \mu V/^{\circ}C$	
Connectors	8 LEMO female connectors optional: 37-pin D-SUB female connector	

Fig. 132 – Pro-AOut-8/16 Rev. C: Specification




Fig. 133 – Pro-AOut-8/16-D Rev. C: Pin assignment




Fig. 134 – Pro-AOut-8/16 Rev. C: Printed circuit board (detail) and front panels

Programming

The following instructions are used to program the module:

Output a value	DAC, Start_DAC, Write_DAC
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## 5.5 Pro I: Analog Input and Output Modules

### 5.5.1 Pro-AO-16/8-12 Rev. A

The analog input/output module Pro-AO-16/8-12 Rev. A includes a ADC (12 bit) with 16 multiplexed channels and 8 DAC (12 bit). The outputs are equipped with a fixed 1<sup>st</sup> order low-pass filter ( $f_c=100\text{kHz}$ ) to cut off glitches.

Please note that the module is only usable in a Pro I system, the module is not supported in a Pro II system.

The 16 inputs and 8 outputs are connected with a 37-pin D-Sub connector.

The voltage ranges of the ADC and DAC can be set by 3 jumpers and adjusted by potentiometers (see page 76).

This module has an address in the group of the analog input modules as well as in the group of the analog output modules.




Fig. 135 – Pro-AO-16/8-12 Rev. A: Block diagram




Fig. 136 – Pro-AO-16/8-12 Rev. A: Pin assignment

ADC		
Input channels		16 single-ended via multiplexer
Resolution		12 bit
Conversion time		7.5 $\mu$ s
Measurement ranges		0...10V, $\pm$ 5V, $\pm$ 10V; optional 0...20mA
Gain		1, 2, 4, 8 software selectable
Accuracy	INL	max. $\pm$ 1 LSB
	DNL	max. $\pm$ 1 LSB
Input resistance		100k $\Omega$ , $\pm$ 2%
Input over-voltage		$\pm$ 35V
Offset error		adjustable
Offset drift		$\pm$ 30 ppm/ $^{\circ}$ C of full scale range
DAC		
Output channels		8 single-ended
Resolution		12 bit
Settling time to 0.01%		10 $\mu$ s for a full scale step
Output voltage		0...10V, $\pm$ 5V, $\pm$ 10V
Output current max.		5mA per channel
Accuracy	INL	max. $\pm$ 1 LSB
	DNL	max. $\pm$ 1 LSB
Offset error		adjustable
Gain error		adjustable
Offset drift		$\pm$ 10 $\mu$ v/ $^{\circ}$ C
Common		
Connector		37-pin D-Sub female connector

Fig. 137 – Pro-AO-16/8-12 Rev. A: Specification

### Setting the Input and Output Voltage Range

The 12 bit input/output module Pro-AO-16/8-12 Rev. A is equipped with 1 ADC and 8 DAC. The input voltage range of the ADC and the output voltage range of the DAC can be set by 3 jumpers each. The default settings of the ADC as well as of the DAC is the voltage range  $\pm$ 10V.




Fig. 138 – Pro-AO-16/8-12 Rev. A: Board and front panel



In figure 139 all (allowed) possibilities to adjust the jumpers for setting the input voltage range are listed.

The potentiometers UPO, B and G are used for an accurate adjustment of gain and offset (fig. 140). The jumpers as well as the potentiometers for setting the input voltage range can be found on the lower part of the module.

If nothing else has been said on ordering the module, the voltage range is set to  $\pm 10V$ . After every jumper setting you have to recalibrate the ADC, in order to assure correct measurement results. The individual steps are described in chapter 6 "Calibration".

Voltage range	Jumper settings
$\pm 5V$ bipolar	UNI BIP
$\pm 10V$ (default)	UNI BIP
0...10V	UNI BIP

Fig. 139 – Pro-AO-16/8-12  
Rev. A: Jumper settings for the  
input voltage range

Potenti-ometer	Adjustment of
Gain	Gain factor
BPO	Offset (bipolar setting)
UPO	Offset (unipolar setting)

Fig. 140 – Pro-AO-16/8-12 Rev. A:  
Function of the potentiometers  
for the inputs

In fig. 141 all possible jumper settings for the output voltage range are listed.

The potentiometers O1–4 for the outputs 1...4 and O5–8 for the outputs 5...8 or respectively, G1–4 and G5–8 (fig. 142) are used for an accurate adjustment of gain and offset.

The jumpers as well as the potentiometers for setting the output voltage range can be found on the lower part of the module.

If nothing else has been said on ordering the module, the voltage range is set to  $\pm 10V$ . After every jumper setting you have to recalibrate the DAC, in order to assure correct measurement results. The individual steps are described in chapter 6.3.1 "Calibration per Software".

Voltage range	Jumper settings
$\pm 5V$ bipolar	
$\pm 10V$ (default)	
0...10V	

Fig. 141 – Pro-AO-16/8-12  
Rev. A: Jumper settings for the  
output voltage range

Potenti-ometer	Adjustment of
G1-4 G5-8	Gain factor
O1-4 O5-8	Offset

Fig. 142 – Pro-AO-16/8-12 Rev. A:  
Function of the potentiometers  
for the outputs

### Input voltage range



### Output voltage range



## Programming

The following instructions are used to program the module:

Convert and read input	ADC, Set_Mux, Start_Conv, Wait_EOC, ReadADC, ReadADC_SConv
Output a value	DAC, Start_DAC, Write_DAC
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

### 5.6 Pro I: Digital-I/O- and Counter Modules

#### Digital I/O Modules

Module	Rev.	Type	Channels	Input Voltage U <sub>In</sub> [V]		High Level [mA]	Isolation [V]	Page
DIO-32	A	TTL input / output	32	5	TTL	–	–	80
DIO-32	B	TTL input / output	32	5	TTL	–	–	82
OPT-16	A, B	Optocouple input	16	5, 12, 24	DC	–	42	84
REL-16	A, B	Relay output	16	max. 30	AC / DC	500	42	86
TRA-16	A	Transistor output	16	5...30	DC	200	42	88
TRA-16	B	Transistor output	16	5...30	DC	200	42	
Comp-16	A	comparator input, switching thresholds separately adjustable	16 s.e.	-2 ... +8,23	DC	–	–	126
Storage	A	Module to read / write a transportable mass media (PCMCIA card, Compact Flash card, hard disk) from <b>ADbasic</b> . With integrated real time clock.						128

#### Counter Modules

Module	Rev.	Channels	Counter			Input voltage. U <sub>In</sub>		Isolation [V]	Page
			No.	Type <sup>a</sup>	Resol. [Bit]	[V]	Type		
CNT-VR4 CNT-VR4-L	A	4	1	UD	32	5	TTL	–	90
CNT-VR4-I CNT-VR4-L-I	A	4	1	UD	32	5, 12, 24	DC	42	93
CNT-8/32	A	8	1	I	32	5	TTL	–	96
CNT-8/32-I	A	8	1	I	32	5, 12, 24	DC	42	98
CNT-16/16	A	16	1	I	16	5	TTL	–	100
CNT-16/16-I	A	16	1	I	16	5, 12, 24	DC	42	102
CNT-16/32	A	16	1	I	32	5	TTL	–	104
CNT-16/32-I	A	16	1	I	32	5, 12, 24	DC	42	106
CNT-VR2PW2	A	4	2	I, UD	32	5	TTL	–	108
CNT-VR2-PW2-I	A	4	2	I, UD	32	5, 12, 24	DC	42	108
CNT-PW4	A	4	1	PWM	32	5	TTL	–	109
CNT-PW4-I	A	4	1	PWM	32	5, 12, 24	DC	42	111
CO4-T	A	4	1	U	32	5	TTL	–	113
CO4-I	A	4	1	U	32	5, 12, 24	DC	42	116
CO4-D	A	4 + 2 SSI	1	U	32	5 diff.	RS422/ RS485	–	118
PWM-4	A	4	1	PWM	16	5	TTL	–	122
PWM-4-I	A	4	1	PWM	16	5...30	DC	42	124

a. UD: Up / Down counter; I = Incremental counter; PWM: PWM analysis;  
U: Universal counter = UD + I + PWM

### 5.6.1 Pro-DIO-32 Rev. A

To this module you find an improved successor module Pro-DIO-32 Rev. B (see page 82).

The digital input/output module Pro-DIO-32 Rev. A provides 32 programmable digital input and output channels at TTL levels. The channels can individually be configured as inputs or outputs by **ADbasic** instructions. The channels are configured as inputs after power up.




Fig. 143 – Pro-DIO-32 Rev. A: Block diagram




Fig. 144 – Pro-DIO-32 Rev. A: Pin assignment




Fig. 145 – Pro-DIO-32 Rev. A: Board and front panel

Input / output channels	32, each configurable via software as input or output
Digital inputs	TTL logic
Pull-Down Resistor	10k $\Omega$
V <sub>IH</sub>	min. 2.4V
V <sub>IL</sub>	max. 0.8V
I <sub>IH</sub>	max. 0.55mA
I <sub>IL</sub>	max. 0.01 mA
Voltage range	-0.5V ... +5.5V
Output current	max. 6mA per channel (outputs are short-circuit proof)
Event input	TTL logic
Power up status	All channels as inputs
Connector	37-pin D-Sub female connector

Fig. 146 – Pro-DIO-32 Rev. A: Specification

The following instructions are used to program the module:

Configure	DigProg1, DigProg2
Read inputs	Digin_Word1, Digin_Word2 Dig_ReadLatch1, Dig_ReadLatch2 Dig_Latch
Set outputs	Digout, Digout_Word1, Digout_Word2, Dig_WriteLatch1, Dig_WriteLatch2, Dig_WriteLatch32 Get_Digout_Long, Get_Digout_Word1, Get_Digout_Word2 Dig_Latch
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

### 5.6.2 Pro-DIO-32 Rev. B

The digital input/output module Pro-DIO-32 Rev. B provides 32 programmable digital input and output channels at TTL levels. The channels can be configured as blocks of 8 bits as inputs or outputs by **ADbasic** instructions (not individually as previous model). The channels are configured as inputs after power up.

With the command **Digout\_F** the setting or resetting of single outputs is realized quicker and needs much less program memory than with the command **Digout**.




Fig. 147 – Pro-DIO-32 Rev. B: Block diagram




Fig. 148 – Pro-DIO-32 Rev. B: Pin assignment




Fig. 149 – Pro-DIO-32 Rev. B: Board and front panel

Input/output channels	32; programmable via software as inputs/outputs in blocks of 8
Digital inputs	TTL logic
Pull down resistor	10k $\Omega$
V <sub>IH</sub>	min. 2V
V <sub>IL</sub>	max. 0.8V
I <sub>IH</sub>	max. 1 $\mu$ A
I <sub>IL</sub>	max. 0.01 mA
Voltage range	-0.5V ... +5.5V
Output current	max. $\pm$ 35mA per channel, max. $\pm$ 70mA per block (8 channels) via V <sub>CC</sub> or GND
Event input	TTL logic
Power up status	All channels as inputs
Connector	37-pin D-Sub female connector

Fig. 150 – Pro-DIO-32 Rev. B: Specification

The following instructions are used to program the module:

Configure	DigProg1, DigProg2
Read inputs	Digin_Word1, Digin_Word2, Digin_Long_F Dig_ReadLatch1, Dig_ReadLatch2 Dig_Latch
Set outputs	Digout, Digout_Bits_F, Digout_F, Digout_Long_F, Digout_Word1, Digout_Word2, Dig_WriteLatch1, Dig_WriteLatch2, Dig_WriteLatch32 Get_Digout_Word1, Get_Digout_Word2 Dig_Latch
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

### Programming

### 5.6.3 Pro-OPT-16 Rev. A

The input module Pro-OPT-16 Rev. A provides 16 channels of optically isolated digital inputs. The input voltage range can be set by jumpers (5V, 12V, 24V). The default setting of the input voltage range is 24V. The switching time of only 200ns allows the sampling of high-speed digital inputs.

Each channel is optically isolated from the system circuitry and from the other inputs. The event-input is optically isolated from the system as well.




Fig. 151 – Pro-OPT-16 Rev. A: Block diagram




Fig. 152 – Pro-OPT-16 Rev. A: Pin assignment






Fig. 153 – Pro-OPT-16 Rev. A: Board and front panel

Input channels	16		
Event inputs	1		
Input current	typ. 7mA / max. 15mA		
Input voltage range (selectable via jumpers)	0...5V	0...12V	0...24V
Switching threshold for 0-low	0...0.8V	0...1.6V	0...3.2V
Switching threshold for 1-high	4.5...5V	10...12V	20...24V
Input over-voltage	-5V ... 8V	-5V ... 16V	-5V ... 30V
Switching time	200ns		
Isolation	42V channel-channel / channel-GND		
Connector	37-pin D-Sub female connector		

Fig. 154 – Pro-OPT-16 Rev. A: Specification

The following instructions are used to program the module:

Read inputs	Digin_Word1, Dig_ReadLatch1, Dig_Latch
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

### Programming

#### 5.6.4 Pro-REL-16 Rev. A, Rev. B

The Pro-REL-16 Rev. A, Rev. B output module provides 16 isolated relay outputs. Each channel is isolated from system circuitry and other output channels. The event-output is optically isolated from the system circuitry.

The module is equipped with normally open contacts, as an option also normally closed contacts are available.




Fig. 155 – Pro-REL-16 Rev. A, Rev. B: Block diagram

RELAY 0 A	37	●	19	RELAY 0 B
RELAY 1 A	36	●	18	RELAY 1 B
RELAY 2 A	35	●	17	RELAY 2 B
RELAY 3 A	34	●	16	RELAY 3 B
RELAY 4 A	33	●	15	RELAY 4 B
RELAY 5 A	32	●	14	RELAY 5 B
RELAY 6 A	31	●	13	RELAY 6 B
RELAY 7 A	30	●	12	RELAY 7 B
RELAY 8 A	29	●	11	RELAY 8 B
RELAY 9 A	28	●	10	RELAY 9 B
RELAY 10 A	27	●	9	RELAY 10 B
RELAY 11 A	26	●	8	RELAY 11 B
RELAY 12 A	25	●	7	RELAY 12 B
RELAY 13 A	24	●	6	RELAY 13 B
RELAY 14 A	23	●	5	RELAY 14 B
RELAY 15 A	22	●	4	RELAY 15 B
DGND	21	●	3	DGND
EVENT IN (+)	20	●	2	RESERVED
			1	EVENT IN (-)

Fig. 156 – Pro-REL-16 Rev. A, Rev. B: Pin assignment




Fig. 157 – Pro-REL-16 Rev. A, Rev. B: Board and front panel

Output channels	16
Switch voltage	30V AC/DC Maximum
Switch current	max. 500mA per channel
Contact	1 per channel, normally open (optional: normally closed)
Operate time	4ms
Release time	3ms
Bounce time	2ms
Event inputs	1
Isolation	42V channel-channel / channel-GND
Event input voltage	5V, 12V, 24V (selectable via jumpers)
Power up status	low (normally open contact: open / normally closed contact: closed)
Connector	37-pin D-Sub female connector

Fig. 158 – Pro-REL-16 Rev. A, Rev. B: Specification

The following instructions are used to program the module:

Set outputs	Digout, Digout_Word1, Dig_WriteLatch1 Get_Digout_Word1, Dig_Latch
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

### 5.6.5 Pro-TRA-16 Rev. A, Rev. B

The output module Pro-TRA-16 Rev. A, Rev. B provides 16 channels of isolated transistor outputs. The supply voltage  $V_{CC}$  has to be provided by an external power supply. The channels are isolated from system circuitry. The event-input is optically isolated from system circuitry.




Fig. 159 – Pro-TRA-16 Rev. A, Rev. B: Block diagram




Fig. 160 – Pro-TRA-16 Rev. A, Rev. B: Pin assignment




Fig. 161 – Pro-TRA-16 Rev. A, Rev. B: Board and front panel

Output channels	16
Switching voltage	5...30V DC with external power supply
Switching current	200mA max. per channel
Voltage drop	0.5V
Switching time	10µs
Event input	1
Isolation	42V channel-channel / channel-GND
Event input voltage	5V, 12V, 24V (selectable via jumpers)
Power up status	low (GND external)
Connector	37-pin D-Sub female connector

Fig. 162 – Pro-TRA-16 Rev. A, Rev. B: Specification

The following instructions are used to program the module:

Set outputs	Digout, Digout_Word1, Dig_WriteLatch1 Get_Digout_Word1, Dig_Latch
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

### 5.6.6 Pro-CNT-VR4 (-L) Rev. A

To this module you find an improved successor module Pro-CO4-T Rev. A (see page 113).

The Pro-CNT-VR4 Rev. A counter module has 4 up/down counters (32 bit), an edge evaluation circuit, and a register (latch) for read out during the count process. All counter values can be loaded (latched) into the register simultaneously with instruction **Cnt\_Latch**. It is also possible to latch the counters individually.

Each counter has 2 inputs which are decoded internally by an edge evaluation logic (quadruple evaluation). The maximum frequency is 1.25MHz at each input A and B (maximum internal count rate: 5MHz). Optionally the counters can be used with one clock input and a direction input at a maximum count rate of 10MHz. The operating mode is selectable by software, for each counter individually.

According to the mode of operation, either the inputs A/B are active or the inputs CLK/DIR.




Fig. 163 – Pro-CNT-VR4 Rev. A: Block diagram

The module Pro-CNT-VR4 Rev. A is also available as Pro-CNT-VR4-L Rev. A version. With this version each counter is equipped with a LATCH-input instead of a CLR-input. The LATCH-inputs must be enabled before use with the instruction **ExtLch\_Enable**. (see also example program <Pro-CNT-VR4-L-I.BAS>).




Fig. 164 – Pro-CNT-VR4-L Rev. A: Block diagram

The modules Pro-CNT-VR4 Rev. A and Pro-CNT-VR4-L Rev. A are equipped with 4 times the components shown in the block diagram; exception: the event input and the control register, which can only be found once on the modules.






Fig. 165 – Pro-CNT-VR4 Rev. A: Pin assignment




Fig. 166 – Pro-CNT-VR4-L Rev. A: Pin assignment




Fig. 167 – Pro-CNT-VR4 (-L) Rev. A: Board and front panel

Counter	4 up/down counters	
Counter resolution	32 bit	
Input clock rate	edge evaluation	1.25MHz max. per channel A,B
	clock, direction	10MHz max.
Signal pulse width	edge evaluation	min. 800ns per channel A,B
	clock, direction	min. 50ns
Inputs	TTL	
Trigger Input	pos. TTL	
Pull down resistor	10kΩ	
V <sub>IH</sub>	min. 2.4V	
V <sub>IL</sub>	max. 0.8V	
I <sub>IH</sub>	max. 0.55mA	
I <sub>IL</sub>	max. 0.01mA	
Voltage range, absolute	-0.3V ... 7V	
Connector	37-pin D-Sub female connector	
Isolation	No (see page 93)	

Fig. 168 – Pro-CNT-VR4 (-L) Rev. A: Specification

**Programming**

The following instructions are used to program the module:

Configure counter	Cnt_Enable, Cnt_SetMode, ExtLch_Enable
Use counter	Cnt_Clear, Cnt_Latch, Cnt_Read32, Cnt_ReadLatch32
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat



## 5.6.7 Pro-CNT-VR4(-L)-I Rev. A

To this module you find an improved successor module Pro-CO4-I Rev. A (see page 116).

The counter module Pro-CNT-VR4(-L)-I Rev. A has 4 up/down counters (32 bits), an edge evaluation circuit, and a register (latch) for read out during the count process. All count rates can be loaded (latched) simultaneously into the register with the instruction **Cnt\_Latch**. It is also possible to latch the counters individually.

Each counter has 2 inputs which are decoded internally by an edge evaluation logic (quadruple evaluation). The maximum throughput rate is 1.25MHz at each input A and B (maximum internal count rate: 5MHz). Optionally the counters can be used with a clock input (CLK) and a direction input (DIR) at a maximum count rate of 10MHz. The operating mode is selectable per software, for each counter individually.

According to the mode of operation, either the inputs A/B are active or the inputs CLK/DIR.

The voltage range of the counter and event inputs can be selected by jumpers. The default setting of the input voltage range is 24V. The counter inputs are optically isolated from the system circuitry as well as from other inputs. The event input is also isolated from the system circuitry.




Fig. 169 – Pro-CNT-VR4-I Rev. A: Block diagram

On the module version Pro-CNT-VR4-L-I Rev. A each counter is equipped with a LATCH-input instead of a CLR-input. The LATCH-inputs must be enabled before use with the instruction **ExtLch\_Enable** (see also example program <Pro-CNT-VR4-L-I.BAS>).




Fig. 170 – Pro-CNT-VR4-L-I Rev. A: Block diagram

The modules Pro-CNT-VR4-I and Pro-CNT-VR4-L-I are equipped with 4 times the components shown in the block diagram; exception: the event input and the control register, which can only be found once on the modules.



RESERVED  
CNTR 1 (A / CLK) (-)  
CNTR 1 (B / DIR) (-)  
CNTR 1 CLR (-)  
RESERVED  
CNTR 2 (A / CLK) (-)  
CNTR 2 (B / DIR) (-)  
CNTR 2 CLR (-)  
RESERVED  
CNTR 3 (A / CLK) (-)  
CNTR 3 (B / DIR) (-)  
CNTR 3 CLR (-)  
RESERVED  
CNTR 4 (A / CLK) (-)  
CNTR 4 (B / DIR) (-)  
CNTR 4 CLR (-)  
RESERVED  
EVENT IN (+)

37  
36  
35  
34  
33  
32  
31  
30  
29  
28  
27  
26  
25  
24  
23  
22  
21  
20

RESERVED  
CNTR 1 (A / CLK) (+)  
CNTR 1 (B / DIR) (+)  
CNTR 1 CLR (+)  
RESERVED  
CNTR 2 (A / CLK) (+)  
CNTR 2 (B / DIR) (+)  
CNTR 2 CLR (+)  
RESERVED  
CNTR 3 (A / CLK) (+)  
CNTR 3 (B / DIR) (+)  
CNTR 3 CLR (+)  
RESERVED  
CNTR 4 (A / CLK) (+)  
CNTR 4 (B / DIR) (+)  
CNTR 4 CLR (+)  
RESERVED  
EVENT IN (-)

19  
18  
17  
16  
15  
14  
13  
12  
11  
10  
9  
8  
7  
6  
5  
4  
3  
2  
1

RESERVED  
CNTR 1, A (-)  
CNTR 1, B (-)  
CNTR 1, LATCH (-)  
RESERVED  
CNTR 2, A (-)  
CNTR 2, B (-)  
CNTR 2, LATCH (-)  
RESERVED  
CNTR 3, A (-)  
CNTR 3, B (-)  
CNTR 3, LATCH (-)  
RESERVED  
CNTR 4, A (-)  
CNTR 4, B (-)  
CNTR 4, LATCH (-)  
RESERVED  
EVENT IN (+)

37  
36  
35  
34  
33  
32  
31  
30  
29  
28  
27  
26  
25  
24  
23  
22  
21  
20

RESERVED  
CNTR 1, A (+)  
CNTR 1, B (+)  
CNTR 1, LATCH (+)  
RESERVED  
CNTR 2, A (+)  
CNTR 2, B (+)  
CNTR 2, LATCH (+)  
RESERVED  
CNTR 3, A (+)  
CNTR 3, B (+)  
CNTR 3, LATCH (+)  
RESERVED  
CNTR 4, A (+)  
CNTR 4, B (+)  
CNTR 4, LATCH (+)  
RESERVED  
EVENT IN (-)

Fig. 171 – Pro-CNT-VR4-I Rev. A:  
Pin assignment

Fig. 172 – Pro-CNT-VR4-L-I Rev. A:  
Pin assignment




Fig. 173 – Pro-CNT-VR4(-L)-I Rev. A: Board and front panel

Counter	4 up/down counters		
Counter resolution	32 bit		
Input clock rate	edge evaluation	1.25MHz max. per channelA,B	
	clock, direction	10MHz max.	
Signal pulse width	edge evaluation	min. 800ns per channelA,B	
	clock, direction	min. 50ns	
Event inputs	1		
Input current	typ. 7 mA / max. 15mA		
input voltage range (selectable via jumpers)	0...5V	0 ... 12V	0...24V
Switching threshold for 0-low	0...0.8V	0...1.6V	0...3.2V
Switching threshold for 1-high	4.5...5V	10...12V	20...24V
Input resistance	560 Ω	2 kΩ	4.3 kΩ
Input over-voltage	-5V ... 8V	-5V ... 16V	-5V ... 30V
Switching time	200ns		
Connector	37-pin D-Sub female connector		
Isolation	42V channel-channel / channel-GND		


Fig. 174 – Pro-CNT-VR4(-L)-I Rev. A: Specification

The following instructions are used to program the module:

Configure counter	Cnt_Enable, Cnt_SetMode, ExtLch_Enable
Use counter	Cnt_Clear, Cnt_Latch, Cnt_Read32, Cnt_ReadLatch32
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

The counter module Pro-CNT-8/32 Rev. A has 8 counters (32 bit). All count rates can be loaded into the register with a single **ADbasic** command so that all counter values can be latched simultaneously. It is also possible to latch the counters individually. With a rising edge of a TTL pulse the 32-bit counter increments by one. The counter can be cleared by software command. The count rate can be determined by the difference between two successive register values. Since the register access is discrete-time, the frequency can be calculated online.



Pin Number	Function
19	RESERVED
18	CNTR 1 CLK
17	CNTR 5 CLK
16	RESERVED
15	RESERVED
14	CNTR 2 CLK
13	CNTR 6 CLK
12	RESERVED
11	RESERVED
10	CNTR 3 CLK
9	CNTR 7 CLK
8	RESERVED
7	RESERVED
6	CNTR 4 CLK
5	CNTR 8 CLK
4	RESERVED
3	DGND
2	+5V, <100mA (unfused)
1	DGND

ADwin-Pro Hardware, manual version 2.14, December 2010




Fig. 177 – Pro-CNT-8/32 Rev. A: Board and front panel

Counter	8 up counters
Counter resolution	32 bit
Input clock rate	10MHz max.
Signal pulse width	min. 50ns
Inputs	TTL
Trigger Input	pos. TTL
Pull down resistor	10kΩ
V <sub>IH</sub>	min. 2.4V
V <sub>IL</sub>	max. 0.8V
I <sub>IH</sub>	max. 0.55mA
I <sub>IL</sub>	max. 0.01 mA
Voltage range, absolute	-0.3V ... 7V
Connector	37-pin D-Sub female connector
Isolation	No (see page 98)

Fig. 178 – Pro-CNT-8/32 Rev. A: Specification

The following instructions are used to program the module:

Configure counter	Cnt_Enable, Cnt_SetMode
Use counter	Cnt_Clear, Cnt_Latch, Cnt_Read32, Cnt_ReadLatch32
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

### Programming

### 5.6.9 Pro-CNT-8/32-I Rev. A

To this module you find an improved successor module Pro-CNT-16/32-I Rev. A (see page 106).

The counter module Pro-CNT-8/32-I Rev. A has 8 counters (32 bit). All count rates can be loaded into the register with a single **ADbasic** command so that all counter values can be latched simultaneously. It is also possible to latch the counters individually. With a rising edge of a TTL pulse the 32-bit counter increments by one. The counter can be cleared by software command. The count rate can be determined by the difference between two successive register values. Since the register access is discrete-time, the frequency can be calculated online.

The counter inputs are optically isolated from the system circuitry as well as from other inputs. The event input is also isolated from the system circuitry. The input voltage range can be selected by three jumpers. The default setting of the input voltage range is 24 V.




Fig. 179 – Pro-CNT-8/32-I Rev. A: Block diagram



The module Pro-CNT-8/32-I is equipped with 8 times the components shown in the block diagram; exception: the event input and the control register.




Fig. 180 – Pro-CNT-8/32-I Rev. A: Pin assignment




Fig. 181 – Pro-CNT-8/32-I Rev. A: Board and front panel

Counter	8 up counters		
Counter resolution	32 bit		
Event input	1		
Input current	typ. 7mA / max. 15mA		
input voltage range (selectable via jumpers)	0...5V	0 ... 12V	0...24V
Switching threshold for 0-low	0...0.8V	0...1.6V	0...3.2V
Switching threshold for 1-high	4.5...5V	10...12V	20...24V
Input resistance	560 $\Omega$	2 k $\Omega$	4.3 k $\Omega$
Input over-voltage	-5V ... 8V	-5V ... 16V	-5V ... 30V
Switching time	200ns		
Connector	37-pin D-Sub female connector		
Isolation	42V channel-channel / channel-GND		

Fig. 182 – Pro-CNT-8/32-I Rev. A: Specification

The following instructions are used to program the module:

Configure counter	Cnt_Enable, Cnt_SetMode
Use counter	Cnt_Clear, Cnt_Latch, Cnt_Read32, Cnt_ReadLatch32
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

### Programming

### 5.6.10 Pro-CNT-16/16 Rev. A

To this module you find an improved successor module Pro-CNT-16/32 Rev. A (see page 104).

The counter module Pro-CNT-16/16 Rev. A has 16 counters (16 bit). All count rates can be loaded into the register with a single **ADbasic** command so that all counter values can be latched simultaneously. It is also possible to latch the counters individually. With a rising edge of a TTL pulse the 16-bit counter increments by one. The counter can be cleared by software command.

The count rate can be derived from the difference of two successive readings of the latch.




Fig. 183 – Pro-CNT-16/16 Rev. A: Block diagram



The module Pro-CNT-16/16 Rev. A is equipped with 16 times the components shown in the block diagram; exception: the event input and the control register.




Fig. 184 – Pro-CNT-16/16 Rev. A: Pin assignment






Fig. 185 – Pro-CNT-16/16 Rev. A: Board and front panel

Counter	16 up counters
Counter resolution	16 bit
Input clock rate	10MHz max.
Signal pulse width	min. 50ns
Inputs	TTL
Trigger Input	pos. TTL
Pull down resistor	10kΩ
V <sub>IH</sub>	min. 2.4V
V <sub>IL</sub>	max. 0.8V
I <sub>IH</sub>	max. 1 mA
I <sub>IL</sub>	max. 0.2mA
Voltage range, absolute	-0.3V ... 7V
Connector	37-pin D-Sub female connector
Isolation	No (see page 102)

Fig. 186 – Pro-CNT-16/16 Rev. A: Specification

The following instructions are used to program the module:

Configure counter	Cnt_Enable
Use counter	Cnt_Clear, Cnt_Latch, Cnt_Read16, Cnt_ReadLatch16
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

### 5.6.11 Pro-CNT-16/16-I Rev. A

To this module you find an improved successor module Pro-CNT-16/32-I Rev. A (see page 106).

The counter module Pro-CNT-16/16-I Rev. A has 16 counters (16 bit). All counter values can be loaded into the register with a single **ADbasic** command so that all counter values can be latched simultaneously. It is also possible to latch the counters individually. With a rising edge of a TTL pulse the 16-bit counter increments by one. The counter can be cleared by software command. The count rate can be derived by the difference between two successive readings of the latch. Since the register access is discrete-time, the frequency can be calculated online.

The counter inputs are optically isolated from the system circuitry as well as from other inputs. The event input is also isolated from the system circuitry. The input voltage range can be selected by jumpers. The default setting of the input voltage range is 24V.




Fig. 187 – Pro-CNT-16/16-I Rev. A: Block diagram



The module Pro-CNT-16/16-I Rev. A is equipped with 16 times the components shown in the block diagram; exception: the event input and the control register.




Fig. 188 – Pro-CNT-16/16-I Rev. A: Pin assignment




Fig. 189 – Pro-CNT-16/16-I Rev. A: Board and front panel

Counter	16 up counters		
Counter resolution	16 bit		
Event input	1		
Input current	typ. 7mA / max. 15mA		
input voltage range (selectable via jumpers)	0...5V	0 ... 12V	0...24V
Switching threshold for 0-low	0...0.8V	0...1.6V	0...3.2V
Switching threshold for 1-high	4.5...5V	10...12V	20...24V
Input resistance	560 Ω	2 kΩ	4.3 kΩ
Input over-voltage	-5V ... 8V	-5V ... 16V	-5V ... 30V
Switching time	200ns		
Connector	37-pin D-Sub female connector		
Isolation	42V channel-channel / channel-GND		

Fig. 190 – Pro-CNT-16/16-I Rev. A: Specification

The following instructions are used to program the module:

Configure counter	Cnt_Enable
Use counter	Cnt_Clear, Cnt_Latch, Cnt_Read16, Cnt_ReadLatch16
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

5.6.12 Pro-CNT-16/32 Rev. A

The counter module Pro-CNT-16/32 Rev. A has 16 counters (32 bit). All counter values can be loaded into the register with a single **ADbasic** command so that all counter values can be latched simultaneously. It is also possible to latch the counters individually. With a rising edge of a TTL pulse the 32-bit counter increments by one. The counter can be cleared by software command. The count rate can be derived by the difference between two successive readings of the latch. Since the register access is discrete-time, the frequency can be calculated online.




Fig. 191 – Pro-CNT-16/32 Rev. A: Block diagram



The module Pro-CNT-16/32 Rev. A is equipped with 16 times the components shown in the block diagram, exception: the event input and the control register.




Fig. 192 – Pro-CNT-16/32 Rev. A: Pin assignment




Fig. 193 – Pro-CNT-16/32 Rev. A: Board and front panel

Counter	16 up counters
Counter resolution	32 bit
Input clock rate	20MHz max.
Signal pulse width	min. 25ns
Inputs	TTL
Trigger Input	pos. TTL
Pull down resistor	10kΩ
V <sub>IH</sub>	min. 2.4V
V <sub>IL</sub>	max. 0.8V
I <sub>IH</sub>	max.1 mA
I <sub>IL</sub>	max. 0.2mA
Voltage range, absolute	-0.3V ... 7V
Connector	37-pin D-Sub female connector
Isolation	No (see page 106)

Fig. 194 – Pro-CNT-16/32 Rev. A: Specification

The following instructions are used to program the module:

Configure counter	Cnt_Enable
Use counter	Cnt_Clear, Cnt_Latch, CO4_Read, CO4_ReadLatch
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

### Programming

The counter inputs are optically isolated from the system circuitry as well as from other inputs. The event input is also isolated from the system circuitry. The input voltage range can be selected by jumpers. The default setting of the input voltage range is 24 V.




Fig. 195 – Pro-CNT-16/32-I Rev. A: Block diagram

The module Pro-CNT-16/32-I Rev. A is equipped with 16 times the components shown in the block diagram, exception: the event input and the control register.




Fig. 196 – Pro-CNT-16/32-I Rev. A: Pin assignment




Fig. 197 – Pro-CNT-16/32-I Rev. A: Board and front panel

Counter	16 up counters		
Counter resolution	32 bit		
Event input	1		
Input current	typ. 7mA / max. 15mA		
input voltage range (selectable via jumpers)	0...5V	0 ... 12V	0...24V
Switching threshold for 0-low	0...0.8V	0...1.6V	0...3.2V
Switching threshold for 1-high	4.5...5V	10...12V	20...24V
Input resistance	510 Ω	1.51 kΩ	3.2 kΩ
Input over-voltage	-5V ... 8V	-5V ... 16V	-5V ... 30V
Switching time	200ns		
Connector	37-pin D-Sub female connector		
Isolation	42V channel-channel / channel-GND		

Fig. 198 – Pro-CNT-16/32-I Rev. A: Specification

The following instructions are used to program the module:

Configure counter	Cnt_Enable
Use counter	Cnt_Clear, Cnt_Latch, CO4_Read, CO4_ReadLatch
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

#### 5.6.14 Pro-CNT-VR2PW2(-I) Rev. A

To this module you find an improved successor module Pro-CO4-T Rev. A and Pro-CO4-I Rev. A (see page 113 / page 116).




Fig. 199 – Pro-CNT-VR2PW2 Rev. A: Pin assignment




Fig. 200 – Pro-CNT-VR2PW2-I Rev. A: Pin assignment

### Programming

The module Pro-CNT-VR2PW2(-I) Rev. A has 2 up/down-counters (UD) and 2 impulse width counters (IW). It is a combination of the modules Pro-CNT-VR4(-I) (4 UD) and Pro-CNT-PW4(-I) (4 IW), so you can use the same instructions as for these modules.

The 1<sup>st</sup> and 2<sup>nd</sup> UD-counter is related to the 1<sup>st</sup> and 2<sup>nd</sup> counter of the module CNT-VR4 and the 1<sup>st</sup> and 2<sup>nd</sup> PW-counter is related to the 3<sup>rd</sup> and 4<sup>th</sup> counter of the module CNT-PW4.

The following instructions are used to program the module:

Configure counter	Cnt_Enable, Cnt_SetMode
Use counter	Cnt_Clear, Cnt_Latch, Cnt_Read32, Cnt_ReadLatch32
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat



### 5.6.15 Pro-CNT-PW4 Rev. A

To this module you find an improved successor module Pro-CO4-T Rev. A (see page 113).

The digital counter module Pro-CNT-PW4 Rev. A has four inputs for pulse width modulated signal acquisition. With this module you are able to determine the positive and negative pulse widths, the duty cycle, period time, and frequency. The 4 counters (32 bit) are clocked with a fixed 5MHz clock signal. At the rising and falling edges of the PW-input signal, the counter value will be stored in two separate latches.

Please, make sure that the delay of the event (via internal or external timer) is shorter than the period width of the highest input frequency to be measured.

Example: The signal whose positive and negative pulse widths you want to know has a frequency of 3.3kHz. The event has to arrive in a time interval of less than  $303\mu\text{s}$  ( $= 1/3.3\text{kHz}$ ).




Fig. 201 – Pro-CNT-PW4 Rev. A: Block diagram

The module Pro-CNT-PW4 Rev. A is equipped with 4 times the components shown in the block diagram, exception: the event input and the control register which can only be found once on the modules.




Fig. 202 – Pro-CNT-PW4 Rev. A: Pin assignment



	falling edge	rising edge
Input PW1	Latch 1	Latch 5
Input PW2	Latch 2	Latch 6
Input PW3	Latch 3	Latch 7
Input PW4	Latch 4	Latch 8

Fig. 203 – Pro-CNT-PW4 Rev. A: Allocation of the latches




Fig. 204 – Pro-CNT-PW4 Rev. A: Board and front panel

Counter	4 impulse counters
Counter resolution	32 bit
Reference clock	5MHz
Inputs	4 TTL
$V_{IH}$	min. 2.4V
$V_{IL}$	max. 0.8V
$I_{IH}$	max. 20 $\mu$ A
$I_{IL}$	max. -50 $\mu$ A
Voltage range	-0.3V ... 7V
Event input	1
Input resistance	10k $\Omega$
Connector	37-pin D-Sub female connector
Isolation	No (see page 111)
Power consumption	approx. 120mA

Fig. 205 – Pro-CNT-PW4 Rev. A: Specification

## Programming

The following instructions are used to program the module:

Configure counter	Cnt_Enable
Use counter	Cnt_Clear, Cnt_Latch, Cnt_Read32, Cnt_ReadLatch32
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## 5.6.16 Pro-CNT-PW4-I Rev. A

To this module you find an improved successor module Pro-CO4-I Rev. A (see page 116).

The digital counter module Pro-CNT-PW4-I Rev. A has four inputs for pulse width modulated signal acquisition. The inputs are optically isolated from each other as well as from the system circuit. The switching time of only 200ns permits the reading of fast digital signals. The event input is isolated from the system, too. The input voltage range of the counter inputs can be selected by jumpers. The default setting of the input voltage range is 24V.

With this module you are able to determine the positive and negative pulse widths of up to four signals and to calculate the duty cycle, period time and frequency. The 4 counters (32 bit) are clocked with a fixed 5MHz clock signal. At the rising and falling edges of the PW-input signal, the counter value will be stored in two separate latches.

Please, make sure that the delay of the event (via internal or external timer) is smaller than the period width of the highest input frequency. to be measured.

Example: The signal whose positive and negative pulse widths you want to know has a frequency of 3.3kHz. The event has to arrive in a time interval of less than  $303\mu s (= 1/3.3kHz)$ .




Fig. 206 – Pro-CNT-PW4-I Rev. A: Block diagram




Fig. 207 – Pro-CNT-PW4-I Rev. A: Pin assignment

The module Pro-CNT-PW4-I is equipped with 4 times the components shown in the block diagram; exception: the event input and the control register which can only be found once on the modules.

	falling edge	rising edge
Input PW1	Latch 1	Latch 5
Input PW2	Latch 2	Latch 6
Input PW3	Latch 3	Latch 7
Input PW4	Latch 4	Latch 8

Fig. 208 – Pro-CNT-PW4-I Rev. A: Allocation of the latches




Fig. 209 – Pro-CNT-PW4-I Rev. A: Board and front panel

Counter	4 impulse counter		
Counter resolution	32 bit		
Event inputs	1		
Reference clock	5MHz		
Input current	typ. 7 mA / max. 15mA		
input voltage range (selectable via jumpers)	0...5V	0 ... 12V	0...24V
Switching threshold 0 (low)	0 ... 0.8V	0 ... 1.6V	0 ... 3.2V
Switching threshold 1 (high)	4.5 ... 5V	10 ... 12V	20 ... 24V
Series resistor	560 Ω	2kΩ	4.3kΩ
Input over-voltage	8V	16V	30V
Negative voltage	-5V for all ranges		
Switching time	200ns		
Isolation	42V channel-channel / channel-GND		
Connector	37-pin D-Sub female connector		

Fig. 210 – Pro-CNT-PW4-I Rev. A: Specification

## Programming

The following instructions are used to program the module:

Configure counter	Cnt_Enable
Use counter	Cnt_Clear, Cnt_Latch, Cnt_Read32, Cnt_ReadLatch32
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## 5.6.17 Pro-CO4-T Rev. A

The module Pro-CO4-T Rev. A is a configurable multi-purpose counter which provides 4 up/down counters as well as the analysis of up to 4 PWM signals. The counter inputs are designed for TTL logic. The functionality of the counter inputs and of the counters themselves can individually be selected via registers.

You may set different operating modes for the counters: Up/down counter, PWM analysis or four edge evaluation. After power-up of the Pro system the default setting of the counters is four edge evaluation with CLR input (the CLR input is not yet released).




Fig. 211 – Pro-CO4-T Rev. A: Block diagram

A negative edge at the CLK input is the counting impulse for the 32-bit counter. The DIR signal sets the counting direction, TTL high means a count-up, TTL low means a count-down.

You can latch the counter values program-controlled or you can influence the counter by an external CLR/LATCH signal.

Depending on the programming the CLR/LATCH signal has either the effect that the counter values are cleared (CLR) or that the counter values are latched (LATCH). This function will only be effective when it is released by the instructions **CO4\_ClearEnable** or **CO4\_LatchEnable**.

The counter is cleared or latched with a rising edge at input CLR/LATCH. During the latch process the frequency of the measurement can be determined by getting the difference of two read latch values, because this difference defines the number of pulses between the two reading processes.

With the PWM analysis the signal, which is to be measured, goes directly to the trigger inputs of the latches. For instance, the counter value in counter 1 is latched into latch 1 at a rising edge, at a falling edge it is latched into latch 5.

The **ADbasic** process is responsible for evaluating from the latch contents the high and low times, the duty cycle, period duration or frequency of the PWM signal.

The four edge evaluation changes the signals (which should be 90° phase-shifted) of a connected incremental encoder at the inputs a and B to CLK and DIR signals. For this you have to program the inputs correspondingly (see "**ADwin-Pro** System Description, Programming in **ADbasic**").

Since every edge of the a and B signals generates a count impulse, the resolution is increased by factor 4. If the encoder has a reference signal, it can be used to clear or latch the counter (after release of the CLR or LATCH input). The counter is cleared when the signals A, B and CLR are on logic "1" (software-selectable: clear, when only the CLR signal is on logic "1").

**Up/down counter (CLK and DIR signals)**

**PWM analysis**

**Four edge evaluation of incremental encoders (A- and B-signals)**

Event input

This input, as far as it has been released, can start an externally triggered **ADbasic** process.




Fig. 212 – Pro-CO4-T Rev. A: Board and front panel




Fig. 213 – Pro-CO4-T Rev. A: Pin assignment Pro-CO4-T

Counter	4 multi-purpose counters
Counter resolution	32 bit
Input / output level	TTL logic
Event input	TTL logic
Reference clock	40MHz (100 ppm)
Clock frequency four edge evaluation	5MHz max. (at 90° phase-shift of the signals)
Clock frequency up/down counter	20MHz max.
Reference frequency PWM analysis	40MHz
Connector	37-pin D-Sub female connector
Power consumption	approx. 150mA
Isolation	No (see page 116)

Fig. 214 – Pro-CO4-T Rev. A: Specification

The following instructions are used to program the module:

Configure counter	Cnt_Enable, CO4_ClearEnable, CO4_LatchEnable, CO4_ResetStatus, CO4_SetMode, CO4_Set_LatchMode
Use counter	Cnt_Clear, Cnt_Latch, CO4_GetStatus, CO4_Read, CO4_ReadLatch
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

## Programming

5.6.18 Pro-CO4-I Rev. A

The basic functions of the module Pro-CO4-I Rev. A are similar to those of the module Pro-CO4-T Rev. A (see page 113).

What is different is the fact that the counter inputs of the module Pro-CO4-I are optically isolated from the system circuit. The event input, too, is optically isolated from the system circuit.

The input voltage range of the counter and event inputs can be set by jumpers to 0...5V, 0...12V or 0...24V. The default setting is 0...24V.




Fig. 215 – Pro-CO4-I Rev. A: Block diagram




Fig. 216 – Pro-CO4-I Rev. A: Pin assignment

Programming

The following instructions are used to program the module:

Configure counter	Cnt_Enable, CO4_ClearEnable, CO4_LatchEnable, CO4_ResetStatus, CO4_SetMode, CO4_Set_LatchMode
Use counter	Cnt_Clear, Cnt_Latch, CO4_GetStatus, CO4_Read, CO4_ReadLatch
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat






Fig. 217 – Pro-CO4-I Rev. A: Board and front panel

Counter	4 multi purpose counters		
Counter resolution	32 bit		
Event inputs	1		
Reference clock	40MHz (100ppm)		
Clock frequency four edge evaluation	5MHz max. (at 90° phase shift of the signals)		
Clock frequency up/down counter	10MHz max.		
Reference frequency PWM analysis	40MHz		
Input current	typ. 7mA / max. 15mA		
input voltage range (selectable via jumpers)	0...5V	0 ... 12V	0...24V
reliable switching threshold <sup>1</sup> for 0 (low)	0...0.8V	0...1.6V	0...3.2V
reliable switching threshold <sup>1</sup> for 1 (high)	4.5...5V	10...12V	20...24V
Series resistor	510 Ω	1.51kΩ	3.02kΩ
Input over-voltage	8V	16V	30V
Negative voltage	-5V for all ranges		
Switching time	100ns		
Isolation	42V channel-channel / channel-GND		
Connector	37-pin D-Sub female connector		
Power consumption	approx. 200mA		

Fig. 218 – Pro-CO4-I Rev. A: Specification

1. A low/high signal will reliably be recognized in the indicated voltage ranges. But the switching process can also be effected outside these voltage ranges.

### 5.6.19 Pro-CO4-D Rev. A

The basic functions of the module Pro-CO4-D Rev. A are similar to those of the module Pro-CO4-I Rev. A (see page 116).

In addition, the module Pro-CO4-D Rev. A is equipped with 2 decoders for the connection of incremental encoders with SSI interface. All inputs are differential and can be used for RS422/485 levels (5V). Finally, the signals A, B and CLR are checked if they show short circuits or a cable break; you can obtain this information with the instruction **CO4\_GetStatus**.

It is possible to operate the EVENT input in differential mode as well as in single-ended mode. If only a single-ended signal is available, it is to be set at EVENT. The negative EVENT input is not set.




Fig. 219 – Pro-CO4-D Rev. A: Block diagram

### SSI decoder

An incremental encoder with SSI interface can be connected to one of the two decoders. The signals are differential, too, and have RS422/485 levels.

The clock rates as well as the resolution of the encoder (up to 32 bits) are programmable via pre-scaler (of approx. 40kHz to 1MHz). A conversion from gray into binary code is made by a routine to be programmed in the **ADbasic** process (see below).

```
'PAR_1 = gray-value to be converted
'PAR_9 = result of the gray to binary conversion
```

```
DIM m, n AS LONG
```

```
EVENT:
```

```
IF (par_2=1) THEN      'start of conversion
    m=0                'clear values of previous conv.
    PAR_9=0            ' "-"
    FOR n=1 TO 32      'go through all 32 bits
        m=(SHIFT_RIGHT(PAR_1,(32-n)) AND 1) XOR m
        PAR_9=(SHIFT_LEFT(m,(32-n))) OR PAR_9
    NEXT n
    PAR_2=0            'enable next conversion
ENDIF
```

Fig. 220 – Listing: Conversion from gray code into binary code

## DIP switch on the module (component side, middle)

You can determine slow and fast input signals with high measurement rate without switching, by connecting 1 counter input with 2 counters. For this you have to change the DIP switch positions on the module:

- Switch counter 3 (additionally to counter 1) to counter input 1:  
Push the switches of the *upper* double DIP switches upwards.
- Switch counter 4 (additionally to counter 2) to counter input 2:  
Push the switches of the *lower* double-DIP switches upwards.




Fig. 221 – Pro-CO4-D Rev. A: Board and front panel

The figure below illustrates the DIP switch positions and the resulting input-counter-connections.

Program one of the two counters with CLK and DIR signal inputs (up/down counter), the other with PWM-input (PWM analysis). In a corresponding **ADbasic** process you can now determine the frequency or period duration of the signal in a wide frequency range.

DIP switch position	Input counter# A/CLK/PWM	Counter			
		CNTR-#1	CNTR-#2	CNTR-#3	CNTR-#4
	1	✓	-	-	-
	2	-	✓	-	-
	3	-	-	✓	-
	4	-	-	-	✓
	1	✓	-	✓	-
	2	-	✓	-	-
	3	-	-	-	-
	4	-	-	-	✓
	1	✓	-	-	-
	2	-	✓	-	✓
	3	-	-	✓	-
	4	-	-	-	-
	1	✓	-	-	-
	2	-	✓	-	✓
	3	-	-	✓	-
	4	-	-	-	-

Fig. 222 – Pro-CO4-D Rev. A: Allocation of Input to Counter with DIP switches





DIP switch position	Input counter# A/CLK/PWM	Counter			
		CNTR-#1	CNTR-#2	CNTR-#3	CNTR-#4
 	1	✓	-	✓	-
	2	-	✓	-	✓
 	3	-	-	-	-
	4	-	-	-	-

Fig. 222 – Pro-CO4-D Rev. A: Allocation of Input to Counter with DIP switches




Fig. 223 – Pro-CO4-D Rev. A: Pin assignment

Counter	4 multi purpose counters + 2 SSI decoders
Counter resolution	32 bit
Input/output levels	RS422/485 compatible (5V differential, 120 Ω bus terminating resistor, see also block diagram)
Event input	1 differential (single-ended operation possible)
Reference clock	40MHz (100 ppm)
Clock frequency four edge evaluation	5MHz max. (at 90° phase shift of the signals)
Clock frequency up/down counter	20MHz max.
Reference frequency PWM analysis	40MHz
Clock frequency SSI decoder (CLK)	1 MHz max.
Connector	37-pin D-Sub female connector
Power consumption	approx. 200mA

Fig. 224 – Pro-CO4-D Rev. A: Specification

## Programming


The following instructions are used to program the module:

Configure counter	Cnt_Enable, CO4_ClearEnable, CO4_LatchEnable, CO4_ResetStatus, CO4_SetMode, CO4_Set_LatchMode
Use counter	Cnt_Clear, Cnt_Latch, CO4_GetStatus, CO4_Read, CO4_ReadLatch
Use SSI decoder	SSI_Mode, SSI_Read, SSI_Set_Bits, SSI_Set_Clock, SSI_Start, SSI_Status

Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat



The highest output frequency where the duty cycle can be still defined in 1%-steps, is 50kHz.






Fig. 227 – Pro-PWM-4 Rev. A: Board and front panel

Output channels		4 PWM channels
Outputs		TTL
Counter-/register width		16 bit
f <sub>clk</sub> after Prescaler	Div. by 1 (2 <sup>0</sup> )	200ns (5MHz)
	Div. by 2 (2 <sup>1</sup> )	400ns (2.5MHz)
	Div. by 4 (2 <sup>2</sup> )	800ns (1.25MHz)
	...	
	Div. by 128 (2 <sup>7</sup> )	25.6μs (≈ 39kHz)
V <sub>OH</sub>		2.4V min.
V <sub>OL</sub>		0.8V max.
Output current		5mA per channel max.
Event input		Positive TTL
Connector		37-pin D-Sub female connector
Isolation		No (see page 124)

Fig. 228 – Pro-PWM-4 Rev. A: Specification

Information about programming and programming examples can be found after the description of the module Pro-PWM-4-I Rev. A.

### 5.6.21 Pro-PWM-4-I Rev. A

The module Pro-PWM-4-I Rev. A generates pulse width modulated signals (PWM signals) at four outputs. Each (PWM-) signal can be configured individually via software, that means they can be configured separately.

The function of the module is significantly characterized by its 4 counters (16 bit) and 8 registers (16 bit), 4 for the duration of the low voltage level and 4 for the high voltage level.

The counters are clocked by a crystal oscillator with a frequency of 5MHz. By defining a (scale) register the frequency can be roughly prescaled in  $2^n$  steps ( $0 < n < 7$ ,  $n \in \mathbb{N}$ ). By presetting the duration of the high- and low-pulses, the output frequency of the PWM signals is defined.

The output of the PWM signals is attained by evaluating the register values and the count rate via an RS-flip-flop.

The inputs are optically isolated from the system circuitry and from other inputs. The event-input is isolated from the system circuitry as well. The input voltage range of the counter inputs can be selected by jumpers. The default setting of the input voltage range is 24V.

By setting a register, the counters can be enabled or disabled. But do not confuse this with enabling or disabling the PWM output (putting it into a "static" mode). This can only be made by the command **PWM\_Out**, which sets the output to a defined status, when the counter is enabled.

The lowest output frequency at a still definable duty cycle of approx. 0...100% is about 0.6Hz.

The highest output frequency where the duty cycle can be still defined in 1%-steps, is 50kHz.




Fig. 229 – Pro-PWM-4-I Rev. A: Block diagram

The module Pro-PWM-4-I Rev. A is equipped with 4 times the components shown in the block diagram; exception: the event input and the 5MHz reference oscillator, which can only be found once on each module.






Fig. 230 – Pro-PWM-4-I Rev. A: Pin assignment




Fig. 231 – Pro-PWM-4-I Rev. A: Board and front panel

Output channels		4
Counter-/register width		16 bit
f <sub>clk</sub> after Prescaler	Div. by 1 (2 <sup>0</sup> )	200ns (5MHz)
	Div. by 2 (2 <sup>1</sup> )	400ns (2.5MHz)
	Div. by 4 (2 <sup>2</sup> )	800ns (1.25MHz)
	...	
	Div. by 128 (2 <sup>7</sup> )	25.6μs (≈ 39kHz)
Output voltage		5...30V DC with an external power supply
Output current		100mA max. per channel
Event inputs		Pos. TTL
Voltage drop		0.5V max.
Switching time		10μs
Event input		1
Event input voltage		5V, 12V, 24V (selectable via jumpers)
Connector		37-pin D-Sub female connector
Isolation		42V channel-channel / channel-GND

Fig. 232 – Pro-PWM-4-I Rev. A: Specification

### 5.6.22 Programming the Module Pro-PWM-4(-I)

Programming the four PWM outputs on the **ADwin-Pro** module PWM-4 is made by using the PWM commands which are available when the file <ADWPDIO.INC> has been included into the **ADbasic** source code.

The following instructions are used to program the module:

Use PWM outputs	PWM_Enable, PWM_Out, PWM_Set
Enable event input	EventEnable
Use LED	CheckLED, SetLED
Synchronize	SyncAll, SyncEnable, SyncStat

The equation shows the formula for calculating the output frequency of the PWM signal.

$$f_{\text{out}} = \left( \frac{5\text{MHz}}{\text{presc}} \right) \cdot \left( \frac{1}{t_{\text{s}_{\text{per}}}} \right) = \left( \frac{5\text{MHz}}{\text{presc}} \right) \cdot \left( \frac{1}{t_{\text{s}_{\text{low}}} + t_{\text{s}_{\text{high}}}} \right)$$

Legend for the equation:

$t_{\text{s}_{\text{low}}}$  = duration of the low level

$t_{\text{s}_{\text{high}}}$  = duration of the high level

$t_{\text{s}_{\text{per}}}$  = period duration

presc = prescaler factor

$f_{\text{out}}$  = output frequency

### Instructions for the PWM modules

#### PWM\_SET

**PWM\_SET** does the settings of the defined module for the prescaler and the duration of the high- and low-pulses of the PWM output channel.

**PWM\_SET**(module, channel, prescale, low, high)

#### Parameters

		LONG	FLOAT	VAR	CONST
<b>module</b>	defined module address	✓	-	✓	✓
<b>channel</b>	PWM output channel (1...4)	✓	-	✓	✓
<b>prescale</b>	pre-scaler value 0...7, corresponds to a division by $2^0 \dots 2^7$	✓	-	✓	✓
<b>low</b>	number of cycles for the low-time, after the prescaler.	✓	-	✓	✓
<b>high</b>	number of cycles for the high-time, after the prescaler	✓	-	✓	✓

#### Description

The values of the parameters **low** und **high** represent the number of cycles after the prescaler, which have to be achieved by the counter to change the logic level.

The prescaler is clocked with a frequency of 5MHz.

**PWM\_ENABLE** enables or stops the counters corresponding to the specified PWM outputs.

**PWM\_ENABLE**(module, pattern)

### Parameters

		LONG	FLOAT	VAR	CONST
<b>module</b>	defined module address	✓	-	✓	✓
<b>pattern</b>	Bit pattern for the PWM outputs. Bits 0-3 correspond to outputs 1-4: bit=0: enable counter bit=1: stop counter	✓	-	✓	✓

### Description

This instruction does not affect the PWM outputs, only the counters corresponding to the outputs. It should be used only in combination with the instruction **PWM\_OUT**.

**PWM\_out** sets the specified PWM output channel to high or low level.

**PWM\_OUT**(module, channel, level)

### Parameters

		LONG	FLOAT	VAR	CONST
<b>module</b>	defined module address	✓	-	✓	✓
<b>channel</b>	PWM output channel (1...4)	✓	-	✓	✓
<b>level</b>	Output value to be set 0: $U_{out}$ = logical "0" 1: $U_{out}$ = logical "1" (or $V_{EE}$ at PWM-4-I)	✓	-	✓	✓

### Description

This instruction does only work, when the counters corresponding to the PWM outputs are enabled with **PWM\_ENABLE**.

### Programming Example / Program Description

The program <Pro\_PWM\_4.bas> provided on the **ADwin** CDROM in the folder <C:\ADwin\ADbasic3\Samples\_ADwin\_Pro> generates identical PWM signals at the outputs 1...4 with a frequency of 1 kHz.

With the parameters **PAR\_1...PAR\_14** you will be able to change in **ADbasic** the following values in the parameter window:

- The high-level duration of the PWM signals: **PAR\_1**, **PAR\_3**, **PAR\_5**, **PAR\_7**.
- The low-level duration of the PWM signal: **PAR\_2**, **PAR\_4**, **PAR\_6**, **PAR\_8**.
- The division factor (prescaler) for the frequency of 5 MHz, which will be generated by the crystal oscillator on the **ADwin-Pro** module PWM-4: **PAR\_9 ... PAR\_12**.
- The enabling of the 16-bit counters (only the internal counter and not the PWM outputs!) : **PAR\_13**.
- The module address: **PAR\_14**.

## PWM\_ENABLE

## PWM\_OUT

### 5.6.23 Pro-Comp-16 Rev. A

The input module Pro-Comp-16 Rev. A provides 16 input channels with a comparator each. The analog signals are acquired parallel and converted with a 10-bit resolution. Depending on switching thresholds, which are separately adjustable by software for each channel, digital signals are generated from these measurement values (1/0).




Fig. 233 – Pro-Comp-16 Rev. A: Block Diagram

The input voltage range of the module is between -2V...+8.23V, other voltage ranges on request. The signals are acquired with 20MHz per channel.

Information about the acquired signals is available per software:

- The digital signals (1/0) of all input channels
- The current converted measurement values
- The maximum and minimum of the acquired measurement values
- The last 1024 measurement values of 2 selected channels
- The digital signals (1/0) of measurement differences

After all measurement values have been acquired they are evaluated quasi-differential, which means that for all 8 channel pairs (1/2, 3/4, ..., 15/16) the differences of the measurement values is calculated. Depending on the switching thresholds, digital signals (1/0) are generated from these differences, which can be selected via software.




Fig. 234 – Pro-Comp-16 Rev. A: Pin assignment

### Providing information




Fig. 235 – Pro-Comp-16 Rev. A: Printed circuit board and front panel

Input/output channels	16 single-ended inputs with a comparator each Comparators with individually selectable switching thresholds
Input resistor	10kΩ
Input voltage range	-2V ... +8.23V
Sampling rate	typ. 20Msps
Resolution	10-bit
Accuracy	±4 digits
Connectors	37-pin D-SUB female connector

Fig. 236 – Pro-Comp-16 Rev. A: Specification

The following instructions are used to program the module:

Use comparator inputs	Comp_Digin_Word_Diff, Comp_Fifo_Read, Comp_Fifo_Select, Comp_Read, Comp_Reset, Comp_Set
Use LED	CheckLED, SetLED

### Technical data

### Programming

## Storage media

### 5.6.24 Pro-Storage Rev. A

The module Pro-Storage writes (or reads out) large quantities of data from an *ADbasic* process to an (exchangeable) storage medium. Therefore data can be stored during stand-alone operation of the *ADwin* system at long-term measurements. On the module there is a battery-buffered real-time clock to date-stamp the data.

The Pro-Storage module supports PCMCIA memory cards, Compact-Flash-cards in combination with an adapter card as well as 1" and 1.8" hard disks.

Basically the storage media can be used with a reading device of a PC to read out the data or write the data to the media. In any case, the medium must be initialized by the program `<Pro-Storage.exe>` before using it.

The user must program writing to (or reading) the medium during operation in a low-priority process. The process is running additionally to the already running open-loop, closed-loop or measurement processes; data is exchanged via a global memory (FIFO). A standard example for such a low-priority process is included in delivery, illustrating how to write data to the storage medium.

The further module description is into the following sections:

- Module Design page 131
- Select the Storage Medium page 133
- Installing the Storage Medium page 134
- Transfer data between PC and storage medium page 138
- Set the real-time clock page 139
- Use the storage medium page 140
- Standard saving process (SP) page 140
- Individual data process page 144

### General Operating Information

In any case, before using the storage medium it should be initialized with the program `<Pro-Storage.exe>`.



Do not remove the storage medium as long as data are accessed (left, lower LED is blinking). As a consequence, the data exchange would be interrupted.

If data of the Pro-Storage module is processed differently than with the program `Pro-Storage.exe`, for instance using a read access device, the following items are to be considered:

1. The size of the files must not be changed.
2. The files must not be deleted or generated.
3. During the writing process the file end must not be exceeded.
4. The data has to absolutely remain in its physical position.

If the rules are not kept, the data will be overwritten or destroyed.

### Module Design




Fig. 237 – Pro-Storage: Block Diagram

The glue-logic of the Pro-Storage module has an internal buffer, which can receive 12 sectors with 128 data words à 32-bits. The glue-logic buffers all data, which is read from or written into the storage medium. Data is exchanged with the storage medium sector by sector.

The real-time clock works independently of all other components and is battery-backed. It provides date and time.




Fig. 238 – Pro-Storage: Printed circuit board and front panel

The module has a width of 1 HP and requires one slot.

On the front panel there are 3 two-colored LEDs.

The lower left LED displays the status of the storage medium:

- Green: The storage medium is correctly inserted or Read access to the storage medium
- Red: Storage medium is removed or Write access to the storage medium

The top and lower right LEDs are individually programmable. (see *ADbasic* instruction **SetLed**).

### The Real-Time Clock

The module is equipped with a real-time clock from Epson RTC-4553AA. With simple *ADbasic* instructions, date and time are set and read out, so that a specified time can be assigned to measurements. Time and glue-logic work autonomously.

### LED function

The time must be specified by a valid date and time of day; it has a resolution of one second. Leap years are considered.

The clock is battery-backed and can remain up to 2 years without any external power supply (when the Pro-system is turned off). Replace the buffer battery after 2 years by a 3V Lithium cell, type CR1632.



## Select the Storage Medium

For selecting the storage medium type there are the following criteria (as of middle 2003); the difference in memory size is not essential.

Medium	Re-writable	Mechan. Strain	Access Time <sup>a</sup>
PCMCIA memory card (type II)	o <sup>b</sup>	+	+
Compact-Flash card, also with adapter card	o <sup>b</sup>	+	+
1"- und 1.8" hard disks	++	–	–

a. After a communication break

b. approx. 1 million times

We recommend that PCMCIA cards of the manufacturer SanDisk are used as industrial grade version (memory sizes of up to 16 GB). PCMCIA cards, which are identical in construction, but in a more rugged enclosure (also IP54 and IP68) are also available from the manufacturer Altec.

The reading and writing rates depend on the storage medium and on the writing and reading processes. Depending on the type and manufacturer there are great differences between the storage media.

For the PCMCIA cards mentioned above, the transfer rates were evaluated with the speed test of the program `Pro-Storage.exe`: about 2000KiB/s for writing and for reading.

The following factors reduce the writing rate:

- Interruption of the (low-priority) writing/reading process
- The small size of the file to be written to (storage medium-specific)
- In user-specific writing/reading processes: low efficiency
- Hard disks: Longer breaks between writing and reading sequences

Hard disks turn into sleep mode after some seconds (for the exact value see the datasheet of the manufacturer); the rotation of the hard disk stops. A new writing process must therefore wait until the hard disk reaches its full rotation speed again (which takes some seconds, see datasheet). Dimension the FIFO array so that it is large enough to buffer all incoming data during the waiting period.

Before a storage medium can be used it must be partitioned and formatted, and initialized by the program `<Pro-Storage.exe>` (see "Installing the Storage Medium" on page 134).

Insert the storage medium in the correct position (the edge connector up front, double guide bar at the top). After the storage medium has been correctly inserted, the lower green LED flashes for a short moment.

To remove the storage medium press the lever under the storage medium up to the stop contact and remove it. After the storage medium has been removed the left, lower red LED flashes for a short moment.

## Select the storage medium



## Insert the storage medium

## Remove the storage medium

## Formatting



## Initializing

## Program is in process

## After program start

### Installing the Storage Medium


Normally storage media are already partitioned and formatted upon delivery. In any case the storage medium should be initialized.

For questions about the partitioning pay attention to the notes of the manufacturer. If necessary, you may format the storage medium yourself:

- Format the partition with the file system FAT16 or FAT32.

FAT16 is necessary for Windows versions up to Win95 SR1 and can be used for storage media of up to 2GB. If the hard disk has more than 504MB FAT32 should be used.

Ensure that the partition table in the Master Boot Record is not overwritten after formatting (using the PC).

- Initialize the storage medium using the program <Pro-Storage.exe> (in the Windows start menu under Programs\ADwin); the program is described in the section  Pro-STORAGE "To initialize / to change initialization".

During initialization up to 10 files are generated on the storage medium, into which the data is written. During initialization the final size of the files is defined. The file information is stored twice, so that the file management accesses the data both under DOS / Windows as well as on the ADwin system.

Writing data to or reading data from the ADwin system is made in a low-priority ADbasic process (section "Use the storage medium"). To keep the data structure as simple as possible, the data are stored in a linery form on the storage medium. All sectors of a file are stored one after the other (= no fragmentation).


In addition to the initialization the program <Pro-Storage.exe> executes the following tasks:

- Transfer data between PC and storage medium (page 138) and
- To set the real-time clock (page 139).

### To initialize / to change initialization

If the program <Pro-Storage.exe> is already running, activate the Read File Structure menu item (at the lower edge of the window). Continue with the section "Read file structure".

After program start this window appears:




- Insert a storage medium into the Pro-Storage module.
- Select the device no. of the ADwin-Pro system and press the button "boot ADwin-System and scan Pro-Storage".

Now the Pro-system boots and several processes for initialization of the storage medium are transferred. One of these processes checks, if there are Pro-Storage modules in the system and displays them in a list under `Choose module`. The modules differ from each other in the specified module address (see "Setting the module's addresses" on page 10).


- Select a Pro-Storage module and confirm with `OK`.

If the storage medium has already been initialized, the existing file structure is displayed, otherwise the following window remains empty:



With `Use` the data structure is accepted, with `Cancel` you accept a standard data structure (a single file, with the size of 1000 KiB) or the previous one. The data structure can be changed in the next window.

## Read file structure



**Pro STORAGE**

Info | advanced Info | Real Time Clock

Storage Medium Type : TOSHIBA MK5002MPL

Cylinders : 10.390

Heads : 15

Sectors per Track : 63

Size : 4.909.275 KB

available Size : 4.898.196 KB    used Size : 1.888.012 KB    free Size : 3.010.184 KB

Nr	File Name	Size [KB]	Size on Disk	First Sector	Sector Count	File Data Exchange
	FILEINFO.DAT	10	12	19.257	20	
1	ADWIN1.DAT	1000000	1.000.000	19.281	2.000.000	
2	ADWIN2.DAT	500000	500.000	2.019.281	1.000.000	
3	ADWIN3.DAT	200000	200.000	3.019.281	400.000	
4	ADWIN4.DAT	100000	100.000	3.419.281	200.000	
5	ADWIN5.DAT	50000	50.000	3.619.281	100.000	
6	ADWIN6.DAT	20000	20.000	3.719.281	40.000	
7	ADWIN7.DAT	10000	10.000	3.759.281	20.000	
8	ADWIN8.DAT	5000	5.000	3.779.281	10.000	
9	ADWIN9.DAT	2000	2.000	3.789.281	4.000	
10	ADWIN10.DAT	1000	1.000	3.793.281	2.000	

Number of Files : 10

Read File Structure    Write File Structure


- Set first in the line Number of Files, how many files (1...10) you would like to use. In the table above the corresponding line number is activated.

- If necessary adapt for each file the name and size (except for FILEINFO.DAT). The file name must correspond to the DOS convention (8+3), and the file size is indicated in KiB (= 1024 byte).

The value Free Size (bottom right, under "Info"), indicates how many kilobytes can still be used on the storage medium.

The column Size on Disk indicates how many kilobytes the file needs on the storage medium. Several sectors (see advanced Info; 1 sector = 512 bytes) make a cluster, therefore the file can have more kilobytes than entered.

- Transfer the specified data structure with Write File Structure to the storage medium.



The storage medium can only be removed after the initialization is completed.

- Now the storage medium is initialized and data can be written to or read from the Pro-Storage module.

## Write file structure














With the initialization of the storage medium information about the glue-logic is saved twice:

1. It is completely stored in the FAT: This file information is used by DOS / Windows.
2. It is stored in the sector 2 and in the file `FILEINFO.DAT`.  
This information is used for the file management on the *ADwin* system.

In sector 2 (absolute) the start and end sectors are saved, in the file `FILEINFO.DAT` the current, relative write and read positions of the generated files.

The initialization does not physically change data on the storage medium. But data can be lost when the file size is changed.

If the contents of the storage medium is displayed by using a reading device (e.g. Explorer), all files are displayed with their file size (this is the information of the FAT).


Name	Size	Type	Modified
 ADWIN1.DAT	1.000.000KB	DAT File	24.04.03 14:17
 ADWIN10.DAT	1.000KB	DAT File	24.04.03 14:17
 ADWIN2.DAT	500.000KB	DAT File	24.04.03 14:17
 ADWIN3.DAT	200.000KB	DAT File	24.04.03 14:17
 ADWIN4.DAT	100.000KB	DAT File	24.04.03 14:17
 ADWIN5.DAT	50.000KB	DAT File	24.04.03 14:17
 ADWIN6.DAT	20.000KB	DAT File	24.04.03 14:17
 ADWIN7.DAT	10.000KB	DAT File	24.04.03 14:17
 ADWIN8.DAT	5.000KB	DAT File	24.04.03 14:17
 ADWIN9.DAT	2.000KB	DAT File	24.04.03 14:17
 FILEINFO.DAT	10KB	DAT File	24.04.03 14:17




## From the PC to the storage medium

### Transfer data between PC and storage medium

With the program <Pro-Storage.exe> data transfer is possible from the PC to the storage medium being inserted in a Pro-Storage module and vice versa.

The data of a storage medium file is stored with the button  (Save Medium File to Disk) on the PC. After pressing the button the following dialog opens:




This dialog determines how many data of the file are copied to the PC.

- **Total Filesize** saves the whole file (including the data sectors where nothing is written into).
- **File data only** saves only the data sector where data has been written into (the file is indicated by a pointer; see also chapter 7.3).
- **Custom Size** determines manually the amount of the bytes to be saved.




If the **Reset file pointer after read** option is activated, the write/read pointer of this file is set to the beginning after data transfer. The standard saving process (see below) works with this pointer.

When clicking the **Copy to Harddisk** menu item, a file saving dialog opens.




Enter a file name and confirm by clicking on **Save**. The data is stored into the selected file.




The bar in the dialog box shows the saving process. After saving the data, the dialog is automatically closed.

If you interrupt the data transfer with **Cancel**, you can restart it with **Save Medium File ...**

With the button  (**Copy Data to Medium File**) data are transferred from a source file into the corresponding file. After pressing the button a "file open"-dialog is opened.

Select the source file in the dialog box, where the data is to be transferred. The amount of data must not be higher than the size of the destination file. Confirm the selection by clicking on **Open**. The dialog box closes and a bar in another window shows the status of the data transfer.




After writing the data, the dialog box is automatically closed. Due to the data transfer, the previous data in the destination file will be overwritten.

If you interrupt the data transfer with **Cancel**, you can restart it by clicking on **Copy Data to Medium ...**

## Set the real-time clock

Select the tag "Real-Time Clock" at the top of the window. If you use the double-headed arrow in the middle, date and time of your PC are transferred to the real-time clock of the Pro-Storage module.



After data is transferred, the real-time clock continues running independently.

**From the storage medium  
to the PC**

## Measurement process + data process

### Use the storage medium

In a measurement process you can use the storage medium in the *ADwin* system as provider of data or as data memory. The measurement process should not, if possible, access the storage medium itself, so that the process can be processed as usual and as fast as before. Therefore you additionally require a low-priority data process, which serves as "data messenger" between the storage medium and the high-priority measurement process.

The additional data process leads you to the following tasks:

- extend the measurement process

Insert into your measurement process (mp) the control of data process (dp) and the data transfer as additional tasks.

Use 2 global fields for information exchange between mp and dp:

- Field 1 for the data transfer
- Field 2 for the control of the data process

- create the data process

We provide a standard process as dp, which writes data to storage media. The text below describes how to adapt the standard saving process to your needs.

Generally, the dp is based on the simple data structure and management, which is already installed on the storage medium.

- adjust the timing of processes

The fact that 2 (or more) processes are running synchronously, requires that you coordinate the timing characteristics of these processes, so that the tasks of the MP and the data flow can run without any interruption. Preferably you will adapt the cycle times (**Processdelay**) of both processes to one another.

If you want develop an own write or read process, please pay attention to the rules of importance on page 144.


## Programming

The following instructions are used to program the module:

Use storage medium	Media_Rd_Blkl_F, Media_Rd_Blkl_L, Media_Rd_Fileinfo, Media_Wr_Blkl_F, Media_Wr_Blkl_L
Use real-time clock	RTC_Get, RTC_Set
Use LED	CheckLED, SetLED

### Standard saving process (SP)

The standard saving process (SP) gets data via a FIFO array (**DATA\_199**) from a high-priority measurement process (MP) and writes it into a specified file of the storage medium. The MP controls functions of the SP using an additional global array (**DATA\_198**), and vice versa receives status messages.



To use the saving process, proceed as follows:



## 1. Determine the basic parameters:

- Number (1...10) of the destination file.  
The SP works only with one of the 10 files. The SP determines the file information of the destination file only once during the start process.
- Write mode "Append" or "New":  
Upon restart the SP may either overwrite the destination file or append the data to the end of file.  
  
The SP writes the number of the saved values (write pointer) into the file `Fileinfo.dat` each time when saving a complete sector is saved. Upon restart the SP reads this write pointer and appends new files.
- Duration of the time-out:  
The time-out is the longest time interval, after which data from the FIFO array are buffered (backup copy).  
  
Normally the SP stores data, if it can write up to 128 values into one or more (12) sectors. But if the time-out is reached earlier, all data in the FIFO are saved immediately.
- Approximate size of the FIFO array for data transfer:  
The array must be large enough to buffer fluctuations of the data flow, e.g. when data arrives irregularly or if there is a delay when the data memory is accessed (for hard disks see page 133).  
A later adaptation of the process cycle times may require to change the array size.
- Data type (FLOAT or LONG) of the data to be saved.  
The SP can only be used for processing one of the two data types.

## 2. Determine, which process is to start first (SP or MP). For both possibilities the pros and cons have to be considered:

### Measurement process starts

- + **Flexible:** If the MP starts the SP, it can re-define the number of the destination file, the time-out and the write mode for the SP upon each restart. Thus the MP saves the data in several files.  
Therefore, if there are changes, the SP does not have to be compiled again.
- **Latency:** The MP must wait with the transfer of data into the FIFO array until the SP reports that it is ready to save the data. Alternatively the FIFO array can be dimensioned as buffer for this latency and already receive data.  
Normally the SP is interrupted by high-priority processes, so that the latency cannot exactly be determined before.
- + **Data loss preventable:** If the MP buffers more data in the FIFO array than the destination file can take, the surplus data must be written into another file, otherwise it is lost. For this the MP must stop the SP and restart it with a new destination file number.

## 1. Determine basic parameters

## 2. Which process starts?

### 3. Adapt the source code

### 4. Test the program

#### Saving process starts

- **Programming effort:** If the number of the destination file, the time-out or the write mode are changed, the SP must be changed and re-compiled.
- **Possible data loss:** If the MP buffers more data in the FIFO array than the destination file can take, those data will be lost.
- + **No delay:** If the SP starts the MP, the MP can pass the data into the FIFO array without any delay. Also possible is to monitor the status of the SP via PC and then start the MP.
- **Start time not determinable:** The time when the SP starts the MP cannot exactly be determined.

We assume that both processes are already on the ADwin system, but have not yet been started. The process started first determines the basic parameters. Either the first process or the PC start the second process.

3. Copy the source code files Pro-Storage\_SP.bas and Pro-Storage\_MP.bas from the directory C:\ADwin\ADbasic\samples\_ADwin\_PRO into the directory of your project. Add the information you have selected according to the items 1 and 2 to your file. In the source code the areas are marked which must be adapted or moved to the MP.

Note that the global arrays have the same size in both processes.

4. Test the programs (compile SP with low-priority!). Note, how the MP uses the 2 global arrays for data transfer and the control of the SP:
  - **DATA\_199 [ ]** or **fb [ ]**: This FIFO array is used for passing the saved data from MP to SP.
  - **DATA\_198 [ ]** or **f\_cmd [ ]**: The elements of this array are used for the control of the saving process and as feedback for the MP.
    - **f\_cmd [ 1 ]**      Number (1...10) of the file
    - **f\_cmd [ 2 ]**      Write mode in the SP:  
0: Write data starting at the beginning of the file ("New" means to overwrite previous data).  
1: Append data at the end of the data ("Append").
    - **f\_cmd [ 3 ]**      Duration of the time-out in the SP:  
≤0: Write data immediately.  
>0: Time interval in 100µs until buffering starts.
    - **f\_cmd [ 4 ]**      Total size of the file in 32-bit values.
    - **f\_cmd [ 5 ]**      Status of the SP: Amount of data values, which have already been written into the file.
    - **f\_cmd [ 6 ]**      Status of the SP: Amount of free elements in the FIFO **DATA\_199 [ ]**.

- `f_cmd[7]` Status or error messages of the SP:
  - 128: Error - storage medium does not respond in a defined time interval (time-out).
  - 64: Error - end of file is reached during writing into the file.
  - 32: Status - SP is stopped as soon as possible (see `f_cmd[9]`)
  - 16: Error - Start sector of the file is larger than the end sector.
  - 8: Error - Write pointer of the file is invalid.
  - 4: Error - File is full (before first saving).
  - 2: Error - File does not exist.
  - 1: Error - No storage medium in the module.
  - 0: Status - End of file not yet reached = data can be saved.
- `f_cmd[8]` Status of the SP:
  - 0: Section **Init**: is finished.
  - 1: Section **Init**: just in progress.
- `f_cmd[9]` Command of the MP to the SP:
  - 0: Sp continues working.
  - 1: Save remaining data and stop SP, for feedback see `f_cmd[7]`.

If the MP setting the parameter `f_cmd[9]` the SP is not stopped at once, but at the moment when there is no data left in the FIFO array. Thus, the SP continues working as long as the MP writes data into the FIFO array.

The SP stops automatically when an error occurs. The cause for the error is reported to the MP using `f_cmd[7]`.

5. Integrate the standard measurement process `Pro-Storage_MP.bas` in your individual measurement process. Sometimes it is necessary to consider security queries regarding a FIFO overflow.

Adapt afterwards the cycle time of the MP to the cycle time of the SP (**Processdelay**). It may be necessary to change the size of the data FIFO `DATA_199[]` additionally to the cycle time, to get the necessary results.

The SP should be configured with a high cycle time, so that a sufficient memory rate is guaranteed. Then the cycle time of the MP (and of other processes) can individually be set to obtain a processor workload less than 100%.

If the cycle time of the SP is short so that calling the SP requires a longer period of time than processing it, an endless loop will be the result.

This standard saving process is now integrated in your measurement program.

## 5. Complete the measurement process



Use the storage medium

## Examples

### Individual data process

The low-priority process described on the pages above is a standard example for fast data storage. Even if this process does not fully meet your requirements we recommend that you first improve your practical knowledge before developing your own individual data process.

For your own application several instructions are available to write or read data sector by sector to/from the storage medium. With an individual process the following tasks can be executed:

- To work simultaneously with several files on one storage medium.
- To save a specified amount of data and to read it again later, e.g. parameters of a test stand for an initialization after restart.
- To save data with a time stamp, that is with date and time of the module-inherent real-time clock.
- To access sectors of the storage medium. In extreme cases data are nevertheless written or read, independent of the initialized data structures. In this case it is not possible to access data via a PC reading device.



Important: Compared to the standard saving process a user-defined process with the instructions described above, is necessarily slower, because the instructions include additional test routines. These instructions are principally used for the non-time-critical exchange of data of a specific length.

If you do prefer a data process with faster access times, call our support hotline.

## Rules of importance



The following rules have to be definitely kept when developing an individual data process for the Pro-Storage module:

- The data process must have low-priority.  
If the instructions are used in high-priority processes errors occur, or even data loss, when working with the storage medium.
- Only one process has access to each Pro-Storage module. Otherwise data will be lost.
- In order to work with files the data structure on the storage medium should not be changed, that is all sectors of a file are located one after the other (= no fragmentation).
- During data transfer the smallest data block has the size of a sector, these are 128 values.
- In a sector only values of the same data type can be used (LONG or FLOAT).
- The information about the data type of a value (or the values in a sector) cannot be saved, and must if necessary be saved separately. In a file different data types could be used in the sectors, but it is not reasonable, as we have described above.
- As long as the write/read process accesses the storage medium, it is not allowed to remove it. Otherwise data of the running process will be lost on the storage medium (by overwriting them).

For data exchange between data process and measurement process as well as for the exchange of control and status information, we recommend that you use a program design similar to the standard saving process.

### 5.7 Pro I: Signal Conditioning and Interface Modules

Please note any signal conditioning module can only be used with an analog input module (Pro-Aln-8/12, Pro-Aln-8/14 or Pro-Aln-8/16).

Module	TC-4	TC-8	TC-16
Revision	A	A	A
Type	thermocouple amplifier		
Type	J: 0°C...750°C K: -200°C...950°C		
Accuracy in bits	12		
Channels	4	8	16

Page 147

Module	PT100-4	PT100-8
Revision	A	A
Type	RTD amplifier	
Version	2, 3 or 4 wires	
Temperature range	-200°C...+266°C	
Accuracy	±0.2°C	
Channels	4	8

Page 152

Module	LPSH-4-FI	LPSH-8-FI
Revision	A	A
Type	Filter isolation amplifier	
Filter	low pass 4 <sup>th</sup> order	
Cut-off frequency	fixed (options on request)	
Channels	4	8

Page 157

Module	MB-8
Revision	A
Function	Passive carrier module for insertion of input modules of the type 5B oder MB.

Page 158

Fig. 239 – Overview signal conditioning modules

**Signal conditioning modules**

## Interface modules

Module	TC-8 ISO
Revision	A
Function	Thermo couple interface
Type	B: 250°C ... 1820°C E: -200°C...1000°C J: -210°C...1250°C K: -200°C ... 1372°C N: -200°C...1300°C R: -50°C ... 1768°C S: -50°C ... 1768°C T: -270°C ... 400°C
Accuracy in °C	±1
Channels	8
Page	150

Module	CAN-1		CANL-1		CAN-2		CANL-2	
Revision	A		A		A		A	
Type	CAN interface							
CAN-Version	High speed		Low speed		High speed		Low speed	
Interfaces	1				2			
Page	160							

Module	PROFI-DP-SL	Inter-SL
Revision	A	A
Type	Fieldbus interface	
Fieldbus version	Profibus	Interbus
Size of DP-RAM	2KiB	
Data exchange rate	9.6kBit/s ... 12MBit/s	500kBit/s
Page	166	

Module	RS-232 -2	RS-422 -2	RS-485 -2	RS-232 -4	RS-422 -4	RS-485 -4
Revision	A	A	A	A	A	A
Type	RSxxx interface					
RSxxx version	RS232	RS422	RS485	RS232	RS422	RS485
Interfaces	2			4		
Data exchange rate [kBaud]	0.035 ... 115.2	0.035 ... 2304	0.035 ... 2304	0.035 ... 115.2	0.035 ... 2304	0.035 ... 2304
Page	176					

Module	LS-2
Revision	A
Function	LS bus interface
Interfaces	2
Bus clock rate	5MHz
Page	179

### 5.7.1 Pro-TC-4 Rev. A, Pro-TC-8 Rev. A, Pro-TC-16 Rev. A

With the modules Pro-TC-xx Rev. A you have purchased thermocouple amplifiers, including cold junction compensation, with 4 (Pro-TC-4), 8 (Pro-TC-8), or 16 (Pro-TC-16) channels.

The amplifier outputs are connected to a LEMO female connector via multiplexer. The output must be connected to an additional analog input module. The multiplexer can be set by an **ADbasic** instruction.




Fig. 240 – Pro-TC-4 Rev. A: Block diagram




Fig. 241 – Pro-TC-4-x-D Rev. A: Pin assignment differential




Fig. 242 – Pro-TC-8 Rev. A: Block diagram




Fig. 243 – Pro-TC-8-x-D Rev. A: Pin assignment differential




Fig. 244 – Pro-TC-16 Rev. A: Block diagram




Fig. 245 – Pro-TC-4-16-D Rev. A: Pin assignment differential

Pro-TC-4

Pro-TC-8

Pro-TC-16

Input channels	Pro-TC-4	4
	Pro-TC-8	8
	Pro-TC-16	16
Multiplexer settling time		50µs
Type, measurement range		J: 0°C...750°C K: -200°C...950°C
Output voltage range		±10V to LEMO female connector A-OUT
Accuracy		±1°C
Connector	Pro-TC-4, Pro-TC-8	Omega subminiature connector, type: SMP-K-F optional: SMTC-37F, 37-pin D-Sub female connector
	Pro-TC-16	Omega subminiature connector, type: SMTC-37F, 37-pin D-Sub female connector

Fig. 246 – Pro-TC-x Rev. A: Specification



A conversion table is available for the conversion of the temperature values into the corresponding integer/float values.

After the installation of the **ADwin**-CDROM you will find the conversion table in the **ADbasic** online help, topic "hardware information".




Fig. 247 – Pro-TC-4-J Rev. A: Board and front panel






Fig. 248 – Pro-TC-8-K Rev. A: Board and front panel




Fig. 249 – Pro-TC-16-K-D Rev. A: Board and front panel

The following instructions are used to program the module:

Use temperature inputs	TC_Select, TCJ_Dig_To_Temp, TCK_Dig_To_Temp
Use LED	CheckLED, SetLED

### Programming

### 5.7.2 Pro-TC-8 ISO Rev. A

The module Pro-TC-8 ISO has 8 inputs for thermocouples and can be operated with thermocouple types E, J, K, N, R, S or T. For each channel the thermoelectric voltage or the temperature may be queried separately via software.

Each channel is equipped with a separate ADC. The module provides a common cold junction compensation for all temperature inputs.

The jumper position (see fig. 252, left side) sets for each channel separately if the channel potentials are separated from each other:

- Position right: The channel potentials are separated from each other (default).
- Position left: The channel's negative input is connected to ground.

Input signals at the ADCs are digitized at a stepwise adjustable sample rate. As soon as a value is queried via software, the module calculates the thermoelectric voltage or the temperature in °Celsius or °Fahrenheit from the last measurement value. All calculation is based upon the norm IEC 584-1.

Calibration of the module is performed by the manufacturer. If needed, please send the module to the address given on the back of the cover page.




Fig. 250 – Pro-TC-8 ISO Rev. A: Block diagram

Input channels	8
Sample rate	7Hz ... 3500Hz
Thermocouple types, measuring range and accuracy	B: 250°C ... 1820°C; $\pm 5^{\circ}\text{C}$ E: -200°C...1000°C; $\pm 1^{\circ}\text{C}$ J: -210°C...1250°C; $\pm 1^{\circ}\text{C}$ K: -200°C ... 1372°C; $\pm 1^{\circ}\text{C}$ N: -200°C...1300°C; $\pm 2^{\circ}\text{C}$ R: -50°C ... 1768°C; $\pm 3^{\circ}\text{C}$ S: -50°C ... 1768°C; $\pm 3^{\circ}\text{C}$ T: -270°C ... 400°C; $\pm 1^{\circ}\text{C}$
Resolution	0.1 °C
Input resistance	10M $\Omega$
Input over-voltage	$\pm 20\text{V}$
Offset drift	$\pm 30\text{ppm}/^{\circ}\text{K}$ of full scale range
Connector	Omega Subminiature Connector, Type SMP

Fig. 251 – Pro-TC-8 ISO Rev. A: Specification




Fig. 252 – Pro-TC-8 ISO Rev. A: Board and front panel

The following instructions are used to program the module:

Use temperature inputs	TC_Read_B, TC_Read_E, TC_Read_J, TC_Read_K TC_Read_N, TC_Read_R, TC_Read_S, TC_Read_T TC_Set_Rate
Use LED	CheckLED, SetLED

Programming

5.7.3 Pro-PT100-4 Rev. A, Pro-PT100-8 Rev. A

The module Pro-PT100 has 4 or 8 inputs for connecting platinum temperature sensors of the type Pt 100. The maximum possible measurement range is -200°C...+266°C, depending on the temperature sensor (see the data sheets of the manufacturers, e.g. Betatherm, Ephy-Mess, Heraeus, Jomo, Omega, Sensycon, etc.).

The amplifier outputs are connected to a LEMO female connector via multiplexer. The output must be connected to an additional analog input module. The multiplexer can be set by an **ADbasic** instruction.

Measurements are done with 2, 3 or 4 wire technique (input circuit see fig. 253). Measuring method, zero point and gain are set via jumpers and trimmers on the circuit board (page 156).

The measuring methods and the wiring between sensor and Pro-PT100 module is described on page 155.




Fig. 253 – Pro-PT100-x Rev. A: Block diagram

Inputs		4 or 8
Amplifier version		2, 3 or 4 wires
Multiplexer settling time		15µs
Max. measurement range		-200°C...+266°C
Accuracy		±0.2°C
Output voltage range		±10 V to LEMO female connector (A-OUT)
$I_1 = I_2$		1 mA
Connector		Omega subminiature connector, type: SMP-K-F optional: 37-pin D-Sub female connector
Module width	Pro-PT100-4	5HP wide / 1 slot
	Pro-PT100-8-D	5HP wide / 1 slot
	Pro-PT100-8	10HP wide / 2 slots

Fig. 254 – Pro-PT100-x: Specification



A conversion table is available for the conversion of the temperature values into the corresponding integer values. You will find the conversion table in the **ADbasic** online help, topic "hardware information".




Fig. 255 – Pro-PT100-8 Rev. A: Board and front panel




Fig. 256 – Pro-PT100-4 Rev. A: Board and front panel




Fig. 257 – Pro-PT100-8-D Rev. A: Board and front panel

### Pro-PT100-8

### Pro-PT100-4

### Pro-PT100-8-D

Pro-PT100-4-D




Fig. 258 – Pro-PT100-4-D Rev. A: Board and front panel

Pin assignments




Fig. 259 – Pro-PT100-x: LEMO female connector




Fig. 260 – Pro-PT100-8-D: Pin assignment




Fig. 261 – Pro-PT100-4-D: Pin assignment

Programming

The following instructions are used to program the module:

Use temperature inputs	TC_Select, PT100_Dig_To_R, PT100_Dig_To_Temp
Use LED	CheckLED, SetLED

## Measurement Method

You can choose one of three Measurement methods: 2 wire measurement, 3 wire measurement or 4 wire measurement.

### – 2 wire measurement

Please pay attention to a very short connection with low impedance between the Pt 100 and the module input, because the voltage drop gets added to the measured voltage.

This is the reason why this measurement method is in general not to be recommended for precise measurements.




Fig. 262 – Pro-PT100-x: 2 wire measurement

For a 2 wire measurement the following connections have to be made:

- LEMO connector: Connect "source+", pin 4 with "sensor+", pin 1.
- LEMO connector: Connect "source -", pin 3 with "sensor -", pin 2.
- Set the jumper on the PCB to the position "2/4L".

### – 3 wire measurement

In order to avoid the disadvantages of the 2 wire measurement, the voltage drop in the measurement lines is here compensated by a second voltage source I2.

To keep the measurement error as small as possible, the resistance value of the three measurement lines from the Pt 100 to the module input should be identical.




Fig. 263 – Pro-PT100-x: 3 wire measurement

For a 3 wire measurement the following connections have to be made:

- LEMO connector: Connect "source +", pin 4 with "sensor +", pin 1.
- Set the jumper on the PCB to the position "3L", in order to activate the second voltage source.

### 2 wire

### 3 wire

## 4 wire

### – 4 wire measurement

The voltage drop at the Pt 100 is directly avoided with high impedance at the PCB by the two "sensor" inputs. The resistance of the measurement lines does not have an effect here any longer and need therefore not be compensated.




Fig. 264 – Pro-PT100-x: 4 wire measurement

For a 4 wire measurement the following connections have to be made:

- LEMO connector: Using this method no connections have to be made here.
- Set the jumper on the PCB to the position "2/4L".

### Setting Zero Point and Gain

The figure 265 below shows the schematic of the printed circuit board and where you can set measuring method, zero point and gain.

With the jumpers 1 to 8 the selected measurement method can be set:

- Upper position "2/4L": 2 or 4 wire measurement
- Lower position "3L": 3 wire measurement

The zero point (at 0°C) is set with the trimmers "OFFSET 1" to "OFFSET 8", the scale factor or gain with "GAIN 1" to "GAIN 8".




Fig. 265 – Pro-PT100-x: Position of jumpers and potentiometers



### 5.7.4 Pro-LPSH-4-FI Rev. A, Pro-LPSH-8-FI Rev. A

The module Pro-LPSH-4-FI Rev. A has 4 low-pass filters of 4th order with Sample & Hold and isolation amplifiers, the module Pro-LPSH-8-FI Rev. A has 8 of these low-pass filters. The filters are Butterworth filters with a fixed cut-off frequency. The frequency has to be indicated when you place an order. The inputs are all optically isolated from system circuitry and from each other.

A low-pass filter module has to be used in combination with an analog input module. (Pro-AIn-8/12 or Pro-AIn-8/16). A low-pass filter module and an analog input module are then forming one unity, which is 2 inches (10 HP) wide and therefore needs two slots.

The switching from sample to hold mode has to be made by the instruction **SH\_SETMODE**(module,mode).




Fig. 266 – Pro-LPSH-8-FI Rev. A in combination with Pro-AIn-8/12 Rev. A

Input channels	4 at Pro-LPSH-4-FI Rev. A, isolated 8 bei Pro-LPSH-8-FI Rev. A, isolated
Input voltage range	±10V
Isolation voltage	1 kV
Offset drift	40 ppm/°C
Non-linearity	0.016%
Input resistance	100kΩ
Filter	Butterworth 4 <sup>th</sup> order
Cut-off frequency	5 kHz, 10 kHz, 20 kHz (other frequencies on request)
Cut-off frequency error	±5%
Sample & Hold drift	1.5 mV/s
Linearity	±1 LSB (12 bit)
Connector	4 / 8 LEMO female connectors (optional: 37-pin D-Sub female connector)

Fig. 267 – Pro-LPSH-4/8-FI Rev. A: Specification

### 5.7.5 Carrier module Pro-MB-8 (-D)





Fig. 268 – Pro-MB-8: Board and front panel

The module Pro-MB-8 is a passive carrier module providing up to 8 slots for insertion of 5B input modules (Analog Devices or Burr Brown) or MB input modules (Keithley).

The power supply of the 5B or MB module (see right: pin 17,  $V_{CC} = +5V$ ; pin 16,  $GND = 0V$ ) is directly connected with the back plane PC bus of the **ADwin-Pro** system. Pin 22 (READ EN) and 23 (WRITE EN) are connected with GND. Therefore the output of the 5B or MB modules is always enabled. Pins 18 and 20 are connected.



The module Pro-MB-8 is available with the following connectors:

- Pro-MB8-DD: Inputs and outputs with D-Sub female connectors.
- Pro-MB8-DD: Inputs D-Sub female connector, outputs LEMO female connectors.
- Pro-MB8-DD: Inputs LEMO female connectors, outputs D-Sub female connector.
- Pro-MB8-DD: Inputs and outputs with LEMO female connectors.





Fig. 269 – Pro-MB-8: Pin assignment input, module and output




Fig. 270 – Pro-MB-8, SubD:  
Pin assignment differential, inputs




Fig. 271 – Pro-MB-8, SubD:  
Pin assignment differential, outputs

### 5.7.6 Pro-CAN Rev. A

The module Pro-CAN has 1 or 2 CAN interfaces, a high speed or a low speed version. The names for the module versions are shown in the table below:

	High speed	Low speed
1 CAN interface	Pro-CAN-1	Pro-CAN-1-LS
2 CAN interfaces	Pro-CAN-2	Pro-CAN-2-LS

#### CAN Controller

The CAN bus interface is equipped with the Intel<sup>®</sup> CAN controller AN82527 which works according to the specification CAN 2.0 parts A and B as well as to ISO 11898. You program the interface with *ADbasic* instructions, which are directly accessing the controller's registers.

#### Message

Messages sent via CAN bus are data telegrams with up to 8 bytes, which are characterized by so-called identifiers. The CAN controller supports identifiers with a length of 11 bit and 29 bit. The communication, that means the management of bus messages, is effected by 15 message objects.



The registers are used for configuration and status display of the CAN controller. Here the bus speed and interrupt handling, etc. are set (see separate documentation "82527 - Serial Communications Controller, Architectural Overview" by Intel<sup>®</sup>)

The CAN bus can be set to frequencies of up to 1 MHz and is usually operated with 1 MHz; with low speed CAN the max. frequency is 125kHz. The CAN bus is galvanically isolated by optocouplers from the *ADwin* system.

An arriving message can trigger an interrupt which instantaneously generates an event at the processor. Therefore an immediate processing of messages is guaranteed.

The manual is divided into the following sections:

- Hardware design
- Message Management
- Setting the bus frequency
- Interrupt / Event
- Module revisions
- Programming

### Hardware design




Fig. 272 – Pro-CAN-1: Block diagram for 1 interface





Fig. 273 – Pro-CAN-2: Block diagram for 2 interfaces



1 CAN interface

2 CAN interfaces




Fig. 274 – Pro-CAN-1/-2: PCB and front panels

The connections of the CAN bus interface are on the 9-pin D-SUB connector; the pin assignment is shown below. On the CAN-1 and CAN-1-LS modules both D-SUB connectors are internally connected with each other.




Fig. 275 – Pro-CAN: Pin assignment




Fig. 276 – Pro-CAN-LS: Pin assignment

**Power supply  
(Low speed only)**

The "low speed" version Pro-CAN-x-LS requires an external power supply of 12V DC to run the CAN controller. The module Pro-CAN-2-LS needs a power supply for each controller separately.

If the CAN module functions as the physical termination of a high-speed CAN bus, it must be terminated with a 120Ω resistor (only the first or the last CAN node). If a termination is necessary, move the DIP switch (Rev. A2, see fig. 274) upward; when using the module revision A1 set the jumper to the left position (ON). CAN nodes, which are not positioned in an end-location, must not be terminated.

### Message Management

The CAN controller identifies messages by an identifier; these are parameters in a defined bit length. The parameters  $0 \dots 2^{11}-1$  or  $0 \dots 2^{29}-1$  result from the bit length.

The controller stores each message (incoming or outgoing) in one out of 15 message objects. The message objects can either be configured to send or to receive messages. Message object 15 can only be used to receive messages. After initializing the CAN controller all message objects are not configured.

Each message object has an identifier, which enables the user to assign a message to a message object.

In *ADbasic* a message is transferred to a message object using the array `can_msg[ ]`, which can receive 8 data bytes plus the amount of data bytes (9 elements). When reading a message from the message object it can also be transferred to the array `can_msg[ ]`.

Sending a message is made as follows:

- You configure a message object to send and define the identifier of the object (instruction **EN\_TRANSMIT**).
- Save the message in `can_msg[ ]`.
- Send the message (instruction **TRANSMIT**). The message in the array `can_msg[ ]` is transferred to the message object. As soon as the bus is ready, the message is sent (with the identifier of the message object).

Receiving a message is made as follows:

- You configure a message object to receive and define the identifier of the object (instruction **EN\_RECEIVE**).
- The controller monitors the CAN bus if there are incoming messages and saves messages with the right identifier in the message object.
- Transfer the message from the message object into the array `can_msg[ ]` (instruction **READ\_MSG**) and read out the corresponding identifier.

An arriving message overwrites the old data in the message object, which will be definitely lost. Therefore pay attention to reading out the data faster than you are receiving them. A data loss is indicated by a flag.

The message object 15 has an additional buffer, so that 2 messages can be stored there.

The allocation of an arriving message to a message object is automatically controlled by comparing its identifiers. The global mask (CAN registers 6...7 or 6...9) controls this comparison as follows:

- The identifier of the message is bit by bit compared to the identifier of the message object. If the relevant bits are identical, the message is transferred to the message object. Not relevant bits are not compared to each other, that is, the message is transferred to the object (if it depends on this bit).
- Relevant bits are set in the global mask.

### Bus termination (High speed only)

### Identifier

### Message objects

### Transferring messages

### Sending messages

### Receiving messages

### Assigning messages

**Global mask**

With the global mask a message object is used for receiving messages with **different identifiers (ID)**. The following example shows the assignment of the message IDs 1...4 to the message object IDs 1...4, when all bits of the global mask are set, except the two least-significant bits (if you have an 11-bit identifier it is `11111111100b`).

Message ID	ID of the message object			
	1 ...001b	2 ...010b	3 ...011b	4 ...100b
1 (...001b)	x	x	x	0
2 (...010b)	x	x	x	0
3 (...011b)	x	x	x	0
4 (...100b)	0	0	0	x

x: Message is admitted

0: Message is not admitted

In this example the comparison of bit 2 is responsible for the assignment of the messages, because the bits 3...10 of the compared identifiers are identical (= 0) and the bits 0 and 1 are not compared, because they are set to zero in the global mask (= not relevant).

**Setting the bus frequency**

The **CAN bus frequency** depends on the configuration of the controller.

The initialization with **INIT\_CAN** configures the controller automatically to a CAN bus frequency of 1 MHz. If the CAN bus is to operate with a different frequency, just use the instruction **SET\_CAN\_BAUDRATE**.

With low speed CAN the maximum bus frequency is 125kBit/s.

In some special cases it may be better to select configurations other than those set with **SET\_CAN\_BAUDRATE**. For this purpose specified registers have to be set with the instruction **Poke**. The structure of the register is described in the controller documentation.

**Enable Interrupt / Trigger Event**

A message object can be enabled to trigger an interrupt when a message arrives. The interrupt output of the CAN controller is connected to the event input of the processor. The processor reacts immediately to incoming messages without having to control the message input (polling).

You can enable the interrupts of several message objects. Which object has caused the interrupt can be seen in the interrupt register (`5Fh`): It contains the number of the message object that caused the interrupt. If the interrupt flag (new message flag) is reset in the message object, the interrupt register will be updated. If there is no interrupt the register is set to 0. If another interrupt occurs during working with the first interrupt its source will be shown in the interrupt register. An additional interrupt does not occur in this case.

**Module revisions**

The differences between the revisions is described below:

Revision	Output date	Previous changes
A1		First version
A2	09/2003	New printed circuit board layout, bus termination with DIP switches instead of jumpers.

**Bus frequency for special cases**



### Programming

The module Pro-CAN is easily programmed with **ADbasic** instructions.

The instructions for the following ranges are in the include file <ADwinPRO\_ALL.inc>:

Range	Instructions
Initialization of the CAN controller	<b>INIT_CAN</b>
Setting and reading of registers	<b>SET_REG, GET_REG</b>
Initialization of message objects	<b>EN_RECEIVE, EN_TRANSMIT</b>
Sending and receiving of data sets	<b>TRANSMIT</b> <b>READ_MSG, READ_MSG_Con</b>
Enabling interrupts	<b>EN_INTERRUPT</b>
Setting the Baud rate	<b>SET_CAN_BAUDRATE</b>

The instructions are described in the Pro software manual or the online help.



### 5.7.7 Pro-Fieldbus Modules

The fieldbus modules Pro-PROFI-DP-SL Rev. A and Pro-Inter-SL Rev. A provide a fieldbus interface with the functionality of a "slave". The modules have a DP-RAM (Dual Port - Random Access Memory) with a size of 2KiB. For the user the communication is defined as access to this DP-RAM, the bus-specific data exchange is realized with hardware. Therefore the communication is more or less independent of the fieldbus type.

A fieldbus module occupies 32 addresses in the module group EXT: The base address set with the DIP switch block and the next 31 addresses. Details about setting the DIP switch block and address numbers see page 11. By software, the module is addressed via the base address only.

In the following text the characteristics of the fieldbus modules is described. Later the special features of the fieldbusses are explained. The description is divided into the following paragraphs:

- Functions description of the fieldbus modules
- Data exchange by handshake
- Programming
- Specifications
- Pro-PROFI-DP-SL Rev. A
- Pro-Inter-SL Rev. A

#### Functions description of the fieldbus modules

After switching on the Pro system the fieldbus interface must be initialized. The module must not be accessed before the initialization. The initialization determines the size of the input and output areas and the behavior of the module. A second initialization is not possible. If the interface is not correctly parameterized the Pro system must be switched on and off.

Each module has a DP-RAM (Dual Port - Random Access Memory), which transfers data between the fieldbus and the program. Both, the program and the fieldbus have access to this memory. The memory is divided into 6 large areas and has a total size of 2KiB. The table shows the areas of the memory. Please take into account that the terms "input" and "output" are used as the fieldbus controller sees them.

Address Area	Content / Function
000h - 1FFh	Data input (of the fieldbus)
200h - 3FFh	Data output (of the fieldbus)
400h - 51Fh	Mailbox input (of the fieldbus)
520h - 63Fh	Mailbox output (of the fieldbus)
640h - 7BFh	Fieldbus-specific data
7C0h - 7FFh	Control register

Fig. 277 – Pro-Fieldbus-SL: Areas of the DP-RAM

#### Initialization

#### DP-RAM

#### Data input / Data output

#### Mailbox input and output

In this address area data for cyclic and acyclic data exchange is saved. The size of both areas is determined in the initialization phase. The data for the cyclic data exchange is located at the beginning of each area, the data for the acyclic data exchange follows directly. If the maximum memory size of 512 bytes is not obtained, the remaining area is not used.

The mailbox area is used for initialization of the fieldbus module. The mailbox area is the interface to the bus-specific part of the module. The initialization of

the module is made using the instruction `init_slave`, so that the user does not have to pay attention to how the area functions.

The control area consists of two registers, which enable the handshake to access the DP-RAM, and of registers, from which information about the module and its configuration can be read out. The content of the individual areas are shown in the table below. Important: Only experienced users may write values directly into the control area.

Area	Size (Byte)	Meaning
7C0h-7C1h	2	Version number of the bootloader
7C6h-7C9h	4	Serial number
7CAh-7CBh	2	Manufacturer
7CCh-7CDh	2	Identification of the field bus type: 0001h: Profibus 0010h: Interbus
7CEh-7CFh	2	Version number of the software
7D4h-7D5h	2	Watchdog counter (counter increments every ms)
7DAh-7DFh	6	Status of the LED, meaning depends on the field-bus: 1. Byte: LED bottom left 2. Byte: LED top left 3. Byte: LED top right 4. Byte: LED bottom right
7E0h-7E1h	2	Module type: 0101h = Slave
7E2h	1	Bit 0: Status of the inputs when the program stops: Bit = 0: Set inputs to 0. Bit = 1: Freeze inputs Bit 1: Status message: Changed output data Bit = 0: Message is disabled Bit = 1: Message is enabled (see 7E4H-7E5H)
7E3h	1	Bit 0 = 0: Bus is offline Bit 0 = 1: Bus is online Bit 1 = 0: Clear outputs, when bus is offline Bit 1 = 1: Freeze outputs when bus is offline
7E4h-7EBh	8	The bits in this area show if the data in the output area have changed. Each bit stands for 8 data bytes in the output area.
7EDh	1	Interrupt source
7EEh	1	Released interrupts
7F0h-7F1h	2	Size of the input area for cyclic data transfer (in bytes)
7F2h-7F3h	2	Size of the total input area in the DP-RAM (in bytes)
7F4h-7F5h	2	Size of the total input area (in bytes)
7F6h-7F7h	2	Size of the output area for cyclic data transfer (in bytes)
7F8h-7F9h	2	Size of the total output area in the DP-RAM (in bytes)
7FAh-7FBh	2	Size of the total output area (in bytes)
7FEh-7FFh	2	Handshake register

Fig. 278 – Pro-Fieldbus-SL: Control register

### Control register

### Data exchange by handshake

When the DP-RAM is accessed it must be assured that only one side has access to the memory. In order to ensure that this happens, there is a handshake process between the two sides fieldbus and program.

There is a separate handshake each for the input, output and control areas. Therefore, both sides may have access to the memory simultaneously, without disabling access for the other side.

After initializing the module and starting of the cyclic data transfer of the fieldbus, first the bus side has the right to access the DP-RAM.

The data, sent by the fieldbus master to the **ADwin** system (slave in the bus), is transferred by the fieldbus and is received and processed by the bus-specific electronic equipment of the **ADwin** module. The active data is written into the output area of the DP-RAM.

The program accesses the DP-RAM or parts of it at any time, (see figure at right). As soon as the fieldbus permits the access, the user reads out the active data from the output area of the DP-RAM and writes data into the input area of the DP-RAM.

As long as the user side has the access right, the fieldbus cannot access the DP-RAM. The Pro module continues to execute its tasks as fieldbus slave, that is the slave meets all requirements of the bus master. Data arriving from the fieldbus is buffered in the bus-specific electronic equipment of the module.

If the user has exchanged all data with the DP-RAM, he has to return the access right to the bus side. Now the electronic equipment of the module writes the buffered data into the output area of the DP-RAM and gets data from the input area of the DP-RAM. At the next bus cycle the bus master gets the input data and writes data into the output area.

fig. 279 explains the data flow in the fieldbus module.





Fig. 279 – Pro-Fieldbus-SL: Data flow in the module



### Programming

All fieldbus modules are easily programmed with the **ADbasic** instructions. Therefore the programs can be used for various fieldbus modules, without having to change them.

The following instructions can be found in the include file <ADwinPRO\_ALL.inc> :

Area	Instructions
Initialization	<b>INIT_SLAVE</b>
Access right to the DP-RAM (handshake)	<b>CHECK_ACCESS</b> <b>REQUEST_ACCESS</b> <b>REQUEST_RELEASE_ACCESS</b>
Writing to and reading out the memory areas	<b>CHANGED_DATA</b> <b>GET_PRO_BYTE</b> <b>SET_PRO_BYTE</b> <b>GET_READ_BUFFER</b> <b>SET_WRITE_BUFFER</b>

The instructions are described in the Pro Software manual or the online help.

### Initializing the fieldbus module

This program initializes a fieldbus module in the **LowInit:** section (see also page 166, Initialization). The initialization must be a low-priority process, because it takes some seconds; if it is a process with high priority, the PC interrupts the communication after a time (time-out).

```
#include ADwinProAll.inc
dim adr as long

lowinit:
adr = 1
REM Initialization of the anybus-module
par_1 = init_slave(adr,10,0,10,0,2,2,0)
```

After initialization the module has the following parameters:

- 10 bytes input data in the cyclic data exchange
- 0 byte input data in acyclic data exchange
- 10 bytes output data in the cyclic data exchange
- 0 byte output data in the acyclic data exchange
- **Changed\_data** function is enabled
- Outputs are frozen at bus OFF
- No interrupt

For more information see the Pro Software manual or the online help.



### Initialization

### 5.7.8 Pro-PROFI-DP-SL Rev. A

Please do note the general information about fieldbus modules in chapter 5.7.7 "Pro-Fieldbus Modules", page 166.

The fig. 280 shows the side-view (printed circuit board) and the front panel of the Pro-PROFI-DP-SL module.




Fig. 280 – Pro-PROFI-DP-SL: Printed circuit board and front panel

#### Pin assignment

fig. 281 shows the pin assignment of the 9-pin D-SUB female connector for the connection to the Profibus. The pin assignment is in agreement with the norm DIN E 19245, Part 3.





Fig. 281 – Pro-PROFI-DP-SL: Pin assignment

#### Profibus address

The Profibus address of the module is set using two switches at the front panel of the module. The flat end of the switch points to the set value. The lower switch ("x10") is for the tens place, the upper switch ("x1") for the units place of the address.

The address range is between 0 and 99. If for instance the lower switch is positioned on "7" (see graphic to the right) and the upper on "3", address 73 is set.



The address will only be set during the internal initializing of the slave module, e.g. after power-up. Changing the switch position during operation will have no effect on the module on the Profibus, only after system restart.

#### Bus termination

The Profibus has to be terminated at its physical beginning and end of its segments by an active terminator. The module has a termination, which can be switched on or off with a switch at the front panel (see graphic). Switched to the position "ON" means: the termination is active.



#### Status display

On the front panel of the PROFI-DP-SL module there are four LEDs. 3 of them show the status of the module, (see table). The graphic shows the position of the LED.



LED	Meaning
ON-L	On (green): The module is online Off (red): No meaning
OFF-L	On (green): The module is offline Off (red): No meaning
DIAG	Fieldbus diagnosis: A flash of 1 Hz (red): Input/output configuration does not match with the master configuration A flash of 4 Hz (red): Error occurred during initialization of the Profibus ASIC.

Fig. 282 – Pro-PROFI-DP-SL: Meaning of the status-LED

## Integration into the Profibus

The configuration of a Profibus is made using a configuration tool, which depends on the user and the selected master system. The tool gets its information about the slaves to be integrated from standardised files. This enables each master to access each slave. All files are in ASCII format and they are in agreement with the norm EN 50170. The file for the Pro-PROFI-DP-SL module will be delivered with the system and is called:

`hmsb1811.gsd` or `hms1003.gsd`

The following details apply for all configuration tools: For more details for the bus configuration, see the documentation of the configuration tool.

Copy the GSD file into the source code of the configuration tool. Include the slave (the module) into the configuration tool. Afterwards the bus could be structured as shown below:




Fig. 283 – Pro-PROFI-DP-SL: Bus layout in the configuration tool

The memory of a slave is divided into areas, the memory modules. Three different types are available: IN/OUT, INPUT and OUTPUT. Each memory determines an area which has a specified size in the input or output area; the sizes of 1, 2, 4, 8, 16, 32, 64 and 128 bytes are available.

A memory module IN/OUT of the size 4 bytes needs 4 bytes in the input area and 4 bytes in the output area.

The configuration of the memory size for the input and output area must be in accordance with the configuration of the module made during initialization. Therefore you have to add the memory sizes of all memory modules - separated in input and output areas - and compare the result with the configuration you made during initialization.

## GSD file

## Integrating the slave

## Configuring the slave

The memory size for the input and output data must be in the range of 0 ... 244 bytes. The total memory size of both areas must be in the range of 1 ... 416 bytes.

fig. 284 shows the possible configuration of a module (slave):




Fig. 284 – Pro-PROFI-DP-SL: Slave configuration

#### Example



If the module is initialized with 32 bytes input data and 32 bytes output data, the configuration tool can be configured as follows:

- IN/OUT (16 bytes)
- INPUT (16 bytes)
- OUTPUT (16 bytes)

The two areas with 32 bytes can also be combined differently. But it is important that the total of the bytes for the input and the total of the bytes for the output each match with the configuration made during initialization of the module. If not, the module cannot be part of the data exchange with the bus.

The module supports only the cyclic data exchange. Acyclic data cannot be transferred.

When the station address is set, indicate the value, which you have set with the address switches of the module. With another address the master cannot access the slave and therefore the module cannot exchange data with the bus.

#### Specifications

The module is in agreement with the European Standard EN 50170, Volume 2. This norm is provided by the Profibus user organization:

Profibus Nutzerorganisation e.V.  
Haid-und-Neu-Str. 7  
76131 Karlsruhe, Germany  
Phone: +49-72196-58590  
Fax : +49-72196-58589  
Order number: 0.042

#### Norm



The following Baud rates are supported:

9.6kBit/s	187.5kBit/s	3MBit/s
19.2kBit/s	500kBit/s	6MBit/s
93.75kBit/s	1.5MBit/s	12MBit/s

The following table shows which service the module provides and the description of the functions:

Service	Description of the functions
Cyclic Data Exchange	The module is part of the cyclic data exchange. The data coming from the master are accepted and the data requested by the master are transferred. The master controls this process.
Slave Diagnostic	The slave transmits - after request of the master - the standard diagnostic data, according to EN 50170.
Freez	If the slave gets a "freeze" message from the bus, it goes into the freeze mode. All input data are kept. This means that the data, which are presently in the input area are transferred via cyclic data exchange to the master. If this area is changed later, the data, being stored on the Profibus, will not be influenced. They will only change, if a new message arrives in the freeze mode from the master, or if the freeze mode is cancelled.
Unfreez	Cancels the freeze mode.
Sync	If the slave gets a "sync" message from the bus it goes into the sync mode. All output data are kept. This means that the data, which are presently in the output area are stable. If the master transmits other data via cyclic data exchange, they will not be transferred to the output area. This is only done, if a new sync message arrives from the bus and the sync mode will be cancelled.
Unsync	Cancels the sync mode.
Clear_Data	Sets all output data to 0. That means, all memory cells, which are located in the area of the output data, have the value 0 afterwards.

Fig. 285 – Pro-PROFI-DP-SL: Supported services

The following table shows the operating mode, the module supports and its behavior:

Operating mode	Behavior
Operate	The Profibus slave is part of the cyclic data exchange. Input data are transferred to the master via bus and output data are made ready for the master to transfer them.
Clear	The inputs are updated and the outputs are set to zero.
Stop	The slave is no longer part of the bus communication.

Fig. 286 – Pro-PROFI-DP-SL: Supported operating modes

### Supported Baud rates

### Supported services

### Operating modes

### 5.7.9 Pro-Inter-SL Rev. A

General information about this fieldbus module is given in chapter 5.7.7 "Pro-Fieldbus Modules", page 166.

fig. 287 shows the side-view (printed circuit board) and the front panel of the Pro-Inter-SL module.




Fig. 287 – Pro-INTER-SL: Printed circuit board and front panel

## Pin assignment

fig. 288 shows the pin assignment of the D-SUB female connectors for the connection of the Interbus (input and output).





Fig. 288 – Pro-INTER-SL: Pin assignment

## Status display

On the front panel of the Pro-INTER-SL module are 4 status LEDs, which inform about the module communication. Table 6 illustrates the meaning of the LEDs:



LED	Name	Meaning when the LED is active
1	RBDA	Interbus output is switched off.
2	TR	PCP communication is active.
3	CC	Physical connection to the master, master will not be initialized.
4	BA	Bus is active.

Fig. 289 – Pro-INTER-SL: Meaning of the status LED

## Integration into the Interbus

After having connected the bus (hardware), the master will be able to read the bus configuration. After reading the master has all necessary information about the connected slaves. For example the size of the input and output areas for cyclic data exchange and the size of the PCP communication. After reading the bus configuration the communication can be started immediately. Moreover, the master identifies the participants (DIO, PC, AIN, ...).

Depending on the configuration, the module can be a digital slave (ID 3) or a PCP participant (ID 243). As digital slave the module cannot exchange acyclical data with the bus master.

If during initialization of the fieldbus interface with **INIT\_SLAVE** an area for parameter data is indicated, then the module is a PCP participant. (The return parameters **Par\_in** and **Par\_out** are not equal to zero). If the return parameters are equal to zero the module is a digital slave. fig. 290 shows a bus layout with a module as PCP participant.




Fig. 290 – Pro-INTER-SL: Bus layout in the configuration tool

The Baud rate in the Interbus is 500 kBit/s, other transfer rates are not available. The module supports this Baud rate.

### Configuring the slave

When using an Interbus, an area for cyclic and acyclic data can be indicated during initialization of the fieldbus interface (see **INIT\_SLAVE**). In the Interbus area sizes are indicated in words (1 word = 2 bytes); thus an input and output area of this size is specified, because the structure of the Interbus requires equally large areas for the input and output data.

The size of the area for cyclic data can be in the range of 1 ... 10 words.

The standard size für the PCP channel in the Interbus is 32 words for either input or output. This size is recommended, but not absolutely required. For the Pro-INTER-SL module the size of the area can be in the range of 1 ... 200 words.

The parameter channel is considered in the protocol with 1 word. That means that 2 bytes from the acyclic data are transmitted each cycle. Therefore the (acyclic) transmission of the parameter data is slower than the transmission of the cyclic data. The time needed for transmitting the parameter data is evaluated by the product of the bus cycle time and the number of the words to be transmitted in the parameter data set.

**Baud rate**

**Input and output areas**

**PCP channel**

5.7.10 Pro-RSxxx Rev. A

The Pro-RSxxx module has 2 or 4 interfaces of the type RS-232, RS-422 or RS-485. The names for the module types are shown in the table below:

	RS-232	RS-422	RS-485
2 interfaces	Pro-RS232-2	Pro-RS422-2	Pro-RS485-2
4 interfaces	Pro-RS232-4	Pro-RS422-4	Pro-RS485-4

All modules of the RSxxx-y modules are equipped with the "Quad Universal Asynchronous Receiver/Transmitter" (UART) controller, type TL16C754 from Texas Instruments®. Functionality and programming of the interfaces are based on this controller.

The physical difference between the interface versions is their signal level, which is provided by appropriate drivers on the bus.

The Pro-RS-xxx-4 module with 4 serial interfaces requires 2 module addresses. Therefore the module address +1 is set additionally to the module's base address set manually. By software, the module is addressed via the base address only.

The description is divided into the following paragraphs:

- Hardware
- Interface parameters
- Module revisions
- Programming

Hardware

These are the front panels and pin assignments of the modules Pro-RS232-x, Pro-RS422-x and Pro-RS485-x.




Fig. 291 – Pro-RSxxx: Printed circuit board and front panels




Fig. 292 – Pro-RS-xxx: Pin assignments

### Interface parameters

Each interface has an input and an output FIFO with a length of 64 bytes each. The settings of the interface parameters are made separately for each channel, using the controller register. Below the settings are described more detailed:

- Handshake: The interface can be operated in 3 modes:
  1. Without handshake
  2. Software handshake
  3. Hardware handshake (RS232 only).  
When using the hardware handshake the signals RTS and CTS must be connected.
- Parity: In order to recognize an error or incorrect data during the transfer, a parity bit can be transferred at the same time. The parity can be even or odd or you can have no parity bit at all.
- Data bits: the active data to be transferred may be 5...8 bits long.
- Stop bits: The number of stop bits can be set to 1, 1½ or 2. Here the number of stop bits depends on the number of data bits:
  - 5 data bits: 1 or 1½ stop bits.
  - 6...8 data bits: 1 or 2 stop bits.
- Baud rate: The physical data are between 35 Baud and 2.304 MBaud; when using an RS-232 interface the maximum Baud rate is 115.2kBaude, according to the specification.

The Baud rates are derived from the clock rate of the module; the basic clock rate has a frequency of 2.304MHz. Based on this fact, every Baud rate is possible, which can be derived from an integer division of the basic frequency. The divisor can have values between **1...0FFFFh**. The following table shows some common Baud rates and their divisors.

### Handshake

### Parity

### Data bits

### Stop bits

### Baud rate

## Special features of RS485

Baud rate	Divisor		Baud rate	Divisor	
	dec.	hex.		dec.	hex.
2.304.000	1	0001h	19.200	120	0078h
1.152.000	2	0002h	9.600	240	00F0h
460.800	5	0005h	4.800	480	01E0h
230.400	10	000Ah	2.400	960	03C0h
115.200	20	0014h	1.200	1920	0780h
57.600	40	0028h	600	3840	0F00h
38.400	60	003Ch	300	7680	1E00h

Fig. 293 – Pro-RS-xxx: Baud rates

Contrary to the RS232 and RS422 interface, with RS485 more than 2 participants can communicate with each other. With an RS485 interface a bus is set up.

Consider the following:

- There is no handshake, because a handshake is only possible between two participants.
- The interface must know if it should write to the bus or get data from the bus (**RS485\_SEND**).

### Module revisions

The difference between the revisions is described below:

Revision	Release date	Previous changes
A1		First version
A2	09/2002	New printed circuit layout
A3	10/2003	Internal program optimization

### Programming

All RSxxx-y modules are equipped with the Quad Universal Asynchronous Receiver/Transmitter (UART), type TL16C754 from Texas Instruments®.

Functionality and programming of the interface depend on this controller. The modules are easily programmed by **ADbasic** instructions, which can be found in the include file <ADwinPRO\_ALL.inc>:

Area	Instructions
Initialization	<b>RS_INIT</b> , <b>rs_reset</b>
Receiving and transmitting of data	<b>read_fifo</b> , <b>write_fifo</b>
Configure RS485 channel	<b>rs485_send</b>
Write and read access to the controller register	<b>GET_RS</b> , <b>SET_RS</b>

The instructions are described in the Pro software manual or the online help.

## 5.7.11 Pro-LS-2 Rev. A

The module Pro-LS-2 Rev. A provides 2 LS-bus interfaces on 9-pin D-SUB connectors (female).




Fig. 294 – Pro-LS-2 Rev. A: PCB and front panel




Fig. 295 – Pro-LS-2 Rev. A: Pin assignment

The LS bus is a bi-directional serial bus with 5MHz clock rate. The bus is a in-house-design to access external modules. The first module available is HSM-24V which can process 24 Volt signals on 32 digital channels.

The bus is set up as line connection, i.e. the *ADwin* interface and up to 15 LS bus modules are connected to each other via two-way links. The last module of the LS bus must have the bus termination activated. The maximum bus length is 5m.

The LS bus modules are programmed with *ADbasic* instructions, which are sent from the LS bus interface of the *ADwin* system. The instructions are mostly specific for the module and are described in the manual of the LS bus module (or in the online help).

The following instructions are available:

Range	Instructions
Initialize a module on the LS-bus.	<b>LS_DIO_INIT</b>
Configure digital channels of module HSM-24V as inputs or outputs.	<b>LS_DIGPROG</b>
Query state of digital channels on module HSM-24V (only with 1 modul on LS-bus).	<b>LS_DIG_IO, LS_Digin_Long</b>
Output value	<b>LS_DIGout_Long</b>
Initialize the watchdog of the LS-bus.	<b>LS_WATCHDOG_INIT, LS_WATCHDOG_Reset</b>

## 6 Calibration

### 6.1 General information

The digital-to-analog (DAC) and analog-to-digital (ADC) converters of the **ADwin** systems are calibrated in factory. According to the regulations for measurement accuracy it is recommended to calibrate the systems in regular time intervals.



#### Qualified personnel

Please note: On several modules the input or output voltage range is adjustable via jumper or DIL switch. After every new setting you have to recalibrate the ADC/DAC, in order to assure correct measurement results.

Programming, start-up and operation, as well as the modification of program parameters must be performed only by appropriately qualified personnel.

*Qualified personnel are persons who, due to their education, experience and training as well as their knowledge of applicable technical standards, guidelines, accident prevention regulations and operating conditions, have been authorized by a quality assurance representative at the site to perform the necessary activities, while recognizing and avoiding any possible dangers.*

*(Definition of qualified personnel as per VDE 105 and ICE 364).*

#### Availability of the documents



This product documentation and all documents referred to, have always to be available and to be strictly observed. For damages caused by disregarding the information in this documentation or in all other additional documentations, no liability is assumed by the company *Jäger Computergesteuerte Messtechnik GmbH*, Lorsch, Germany.

#### Tools

The following tools are necessary to calibrate the system:

- a reference voltage source with an accuracy of:
  - 30µV for calibration of 16 bit converters
  - 100µV for calibration of 12 bit converters
- a digital multi meter with an accuracy of:
  - 10µV for calibration of 16 bit converters
  - 100µV for calibration of 12 bit converters
- connecting cables from the input/outputs to the reference voltage and to the measurement device
- adapter board with a connector according to DIN 41612 with 96 pins<sup>1</sup>
- insulated adjusting tools<sup>1</sup>

1. only for modules with trimmers for calibration



### 6.2 Calculation basis

The standard voltage range of the analog inputs/outputs of the **ADwin** systems is -10V ... +10V (bipolar 20 Volt).

The voltage ranges of the **ADwin-Pro** system can additionally be set to -5V...+5V (bipolar 10 Volt) and 0V...+10V (unipolar 10 Volt) by jumper.

The 65536 ( $2^{16}$ ) digits are allocated to the corresponding voltage ranges of the ADC and DAC in such a manner that the value for

- 0 (zero) digits corresponds to the maximum negative voltage.
- 65535 digits correspond to the maximum positive voltage.

The value for 65536 digits, exactly 10 Volt, is therefore just beyond the measurement range, therefore you get for the 16 bit AD or DA conversion a maximum voltage value of 9.999695 Volt, and for the 12 bit AD conversion a value of 9.995117 Volt.

In bipolar settings this results in a zero offset, called offset in the following text. The offset has the following value:

Offset $V_{OFF}$	with setting
-10V	bipolar $\pm 10$ Volt (-10V...+10V)
-5V	bipolar $\pm 5$ Volt (-5V...+5V)
0V	unipolar 10V (0V...+10V)

The value  $V_{LSB}$  defines the voltage, which corresponds to the least significant bit. The value in the standard setting is

- with 16 bit converters:  $20V \cdot 2^{-16} = 305.175\mu V$
- with 12 bit converters:  $20V \cdot 2^{-12} = 4.8828mV$
- Further values of  $V_{LSB}$  can be found in fig. 297 (page 185).

When using Pro-AIn modules with programmable gain arrays (PGA), you can amplify the input voltage by factors 2, 4 and 8. Thus, the measurement range gets smaller by the corresponding gain factor  $k_V$ .

Please pay attention to the fact that also the interference signals are amplified when using applications with  $k_V > 1$ . These can be reduced by programming digital filters in **ADbasic**.

In order to get the same allocation of bits during measurements with the 12 bit ADC as with a 16 bit ADC, the converted value is presented left-aligned in the lower word (16 bit) with the 12 bit ADC. The least 4 significant bits are always 0 (see fig. 296).

bit-No.	31...16	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
32 bit-Memory	0 (upper word)	12 bit value of the 12 bit-ADC in the lower word (left aligned)												0	0	0	0
		16 bit value of the 16 bit-ADC in the lower word															

Fig. 296 – Bit allocation of 12 bit-ADC and 16 bit-ADC

The 4096 digits of the 12 bit ADC are mapped to the 65535 digits of the 16 bit ADC. Therefore, 16 digits of the 16 bit ADC correspond to one digit of the 12 bit ADC. The following equations apply therefore for both ADC types.

Voltage range

Allocating digits to voltage

Zero offset

$V_{OFF}$

Least Significant bit  
 $V_{LSB}$

Gain  $k_V$

Allocating the bits

Explanation to fig. 296

**DAC**

For DAC use the formula:

$$U_{OUT} = \text{Digits} \cdot U_{LSB} + U_{OFF}$$

$$\text{Digits} = \frac{U_{OUT} - U_{OFF}}{U_{LSB}}$$

**ADC**

For ADC use the formula:

$$\text{Digits} = \frac{U_{IN} - U_{OFF}}{U_{LSB}}$$

$$U_{IN} = \frac{\text{Digits} \cdot U_{LSB} + U_{OFF}}{k_V}$$

**Tolerance range**

Slight variations regarding the calculated values may be within the tolerance range of the individual component. Two kinds of variations are possible (in LSB), which are indicated in your hardware manual.

**INL**

- The integral non-linearity (INL) defines the deviation from the ideal wave form covering the whole input voltage range.

**DNL**

- The differential non-linearity (DNL) defines the deviation from the ideal value of the quantization level.

### 6.3 Calibrating a module

At first define the voltage range by setting the jumpers when the system is switched off.

Calibration has to be made when the system reaches its operating temperature. 30 minutes after power-up of the system, the operating temperature is reached, provided the system has a (room) temperature of approx. 20...25°C before power-up.


Depending on the module you calibrate with one of the following methods:

- Calibration per Software
- Calibration with Trimmers

#### 6.3.1 Calibration per Software

Please note the general information in chapter 6.1.

Call the program `ADpro.exe` from the Windows start menu under "Programs\ADwin". The program requires Microsoft .NET Framework 2.0. The dialog window `Scan` opens.




Please note: The next step will stop all processes and reset all module settings!

Enter the data for the *ADwin* system to be calibrated. The button `Scan` starts a connection to the *ADwin* system and reads system information. The program `ADpro.exe` will initialize the *ADwin* system, i.e. it stops and deletes running processes.

If your **ADwin** system has booted successfully, the window "ADwin - ADpro" opens.

#### Initializing the hardware





## Calibration

In the window ADpro, click on the module to calibrate and select the menu entry Calibration in the Module menu.

If the Calibration entry is not displayed in the menu, the selected module is calibrated by trimmers, see the following chapter 6.3.2 "Calibration with Trimmers".

Connect the measurement device and the reference voltage source.

The individual calibration steps are described in the windows "AOUT Calibrate" or "AIN Calibrate". Please note that

- with the AIN modules the calibration of the ADC is effected via the input channel 1.
- with the AIN-F modules the connected channel is selected in the window "Input channel".

### 6.3.2 Calibration with Trimmers

Please note the general information in chapter 6.1.

Caution: Risk of electric shock.

**ADwin-Pro** systems have a power supply device, which gives access to high-voltage lines and connectors if the system is open. The ventilation slots are wide enough to pass through an alignment tool of 2.5 mm (=0.1inch).



Calibrate the system only when it is closed!

Do not pass any conductive objects through the ventilation slots!

If access to the trimmers is not easily possible, use an adapter board with a connector according to DIN 41612 with 96 pins. Please take into consideration that the DAC and ADC are rapidly cooling down: Finish the calibration after some minutes.

### Offset and Gain

Start **ADbasic** and boot your system.

Connect the measurement device and the reference voltage source.

In the annex of this chapter you will find the programs for easy and fast calibration. You will find:

Program start

Connection

Calibration programs

- The position of the offset and gain trimmers in the figures of your module description in this manual.
- The configurations in the following fig. 297, if you do not want to work with the calibration programs.
- Please pay also attention to the previous notes about INL and DNL.



Vol- tage	Digits dec. Digits hex.	Max. value 65535 FFFFh	Max. test value 64080 FA50h	Mean test value 32768 800h	Min. test value 1456 5B0h	Min. value 0 0h
-10V to +10V	16 bit U <sub>LSB</sub> : 305.1758μV	+ 9.9996948V	+ 9.5556641V	0V	- 9.5556641V	- 10V
	12 bit U <sub>LSB</sub> : 4.88281mV	+ 9.9951172V				
-5V to +5V	16 bit U <sub>LSB</sub> : 152.5879μV	+ 4.9998474V	+ 4.7778320V	0V	- 4.7778320V	- 5V
	12 bit U <sub>LSB</sub> : 2.44141mV	+ 4.9975586V				
0V to +10V	16 bit U <sub>LSB</sub> : 152.5879μV	+ 9.9998474V	+ 9.7778320V	+ 5V	+ 0.2221680V	0V
	12 bit U <sub>LSB</sub> : 2.44141mV	+ 9.9975586V				

Fig. 297 – Assignment of digits to voltage at the inputs/outputs  
dependent on the configuration of ADC and DAC

Depending on the module group, the trimmers have different effects. Please take into consideration that the calibration has absolutely to be made according to the order shown in the following section "Calibration with ADbasic Programs", even if you work with different test values.



## 6.4 Calibration with **ADbasic** Programs

In the annex of this chapter you will find **ADbasic** programs for fast and easy calibration of the different **ADwin-Pro** modules. Please proceed according to the following order:

### AOut-4/16, AOut-8/16

- AOut-4/16, AOut-8/16 (bipolar and unipolar)
  1. Calibrate Offset:
    - Enter the digital **min. test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
    - Set the voltage value with the offset trimmer for the relevant channel (BPO, UPO).
  2. Calibrate Gain:
    - Enter the digital **max. test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
    - Set the voltage value with the corresponding gain trimming potentiometer.
  3. Check:
    - Check all 3 test values from fig. 297.

### AIIn 8/16 Rev. A bipolar

- AIIn 8/16, bipolar
  1. Calibrate Offset:
    - Enter the digital **mean test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
    - Set the voltage value with the offset trimmer for the relevant channel (BPO).
  2. Calibrate Gain:
    - Enter the digital **max. test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
    - Set the voltage value with the corresponding gain trimming potentiometer.
  3. Check:
    - Check all 3 test values from fig. 297.

### AIIn 8/16 Rev. A unipolar

- AIIn 8/16, unipolar
  1. Calibrate Offset:
    - Enter the digital **min. test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
    - Set the voltage value with the offset trimmer for the relevant channel (UPO).
  2. Calibrate Gain:
    - Enter the digital **max. test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
    - Set the voltage value with the corresponding gain trimming potentiometer.
  3. Check:
    - Check all 3 test values from fig. 297.

## – AIn 8/12

### 1. Calibrate Offset:

- Enter the digital **min. test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
- Set the voltage value with the offset trimmer for the relevant channel.

### 2. Calibrate Gain:

- Enter the digital **max. test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
- Set the voltage value with the corresponding gain trimming potentiometer.

### 3. Check:

- Check all 3 test values from fig. 297.

## – AIn 32/12 (bipolar und unipolar)

### 1. Calibrate Offset:

- Enter the digital **min. test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
- Set the voltage value with the offset trimmer for the relevant channel (BPO, UPO).

### 2. Calibrate Gain:

- Enter the digital **max. test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
- Set the voltage value with the corresponding gain trimming potentiometer.

### 3. Check:

- Check all 3 test values from fig. 297.

## – AIn F 8/12, AIn F 4/12

### 1. Calibrate Offset:

- Enter the digital **mean test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
- Set the voltage value with the offset trimmer for the relevant channel.

### 2. Calibrate Gain:

- Enter the digital **max. test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
- Set the voltage value with the corresponding gain trimming potentiometer.

### 3. Check:

- Check all 3 test values from fig. 297.

## – AIn F 8/16, AIn F 4/16

### 1. Calibrate Offset:

- Enter the digital **mean test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
- Set the voltage value with the offset trimmer for the relevant channel.

### 2. Calibrate Gain:

- Enter the digital **max. test value** for **PAR\_8** in the parameter window and confirm with "Send" or by pressing [RETURN].
- Set the voltage value with the corresponding gain trimming potentiometer.

### 3. Check:

- Check all 3 test values from fig. 297.

## AIn 8/12

## AIn 32/12

## AIn F 8/12, AIn F 4/12

## AIn F 8/16, AIn F 4/16

## 6.5 Programs for calibration

You will find the **ADbasic** programs for calibration as source files in the directory <C:\ADwin\Tools\Calibration\...> with standard installation from the **ADwin** CDROM (beginning with version 3.00.30xx).

### 6.5.1 Pro AOut 4/16 und 8/16 (DAC)

```
'Process for the ADwin-Pro in order to
'output voltage with an AOUT module.
'Last modification on July 18, 2000 ur
'Usage of the variables:
'PAR_6 : module address          (1 to 255)
'PAR_7 : channel number         (1 to 8)
'PAR_8 : output value           (0 to 65535)

#include ADwinPro_All.inc

#####
INIT:
PROCESSDELAY=2000
IF (PAR_6=0) then PAR_6=1 'prevent module address 0
IF (PAR_7=0) then PAR_7=1 'prevent channel number 0
IF (PAR_8=0) then PAR_8=32768
Rem 64080 => +9.555664V (at a voltage range of +/- 10V)
Rem 32768 => 0V
Rem 1456 => -9.555664V

#####
EVENT:
DAC(PAR_6,PAR_7,PAR_8) 'output value
```



## 6.5.2 Pro AIn 8/16 Rev. A (ADC)

```
'Process for the ADwin-Pro in order to
'read voltage with an AIN-8/16 module.
'The mean value is calculated in FPAR_1.
'Last modification on August 08, 2000 ur
'Usage of the variables:
'PAR_1 : module address      (1 to 255)
'PAR_2 : channel number     (1 to 8)
'PAR_3 : read value         (0 bis 65535)
'FPAR_1: mean value

#INCLUDE ADwinPro_All.inc

' #####
INIT:
PROCESSDELAY=2000
IF (PAR_1=0) then PAR_1=1 'prevent module address 0
IF (PAR_2=0) then PAR_2=1 'prevent channel number 0 (not
                        'allowed
IF (PAR_3=0) then PAR_3=32768
Rem 64080 => +9.555664V (at a voltage range of +/- 10V)
Rem 32768 => 0V
Rem 1456 => -9.555664V

' #####
EVENT:
PAR_3=ADC16(PAR_1,PAR_2)'read value
FPAR_1=FPAR_1*0.95 + PAR_3*0.05'mean value
```

## 6.5.3 Pro AIn 8/12 (ADC), -Pro AIn 32/12 (ADC)

```
'Process for the ADwin-Pro in order to read a voltage
'with an AIN-8/12 or AIN-32/12 module.
'A mean value is calculated in FPAR_1.
'Last modification on August 08, 2000 ur
'Usage of the variables:
'PAR_1 : module address      (1 to 255)
'PAR_2 : channel number     (1 to 32)
'PAR_3 : read value         (0 to 65535)
'FPAR_1: mean value

#include ADwinPro_All.inc

#####
INIT:
PROCESSDELAY=2000
IF (PAR_1=0) then PAR_1=1 'prevent module address 0
IF (PAR_2=0) then PAR_2=1 'prevent channel number 0 (not
                        'allowed)
IF (PAR_3=0) then PAR_3=32768
'64080 => +9.555664V (at a voltage range of +/- 10V)
'32768 => 0V
'1456 => -9.555664V

#####
EVENT:
PAR_3=ADC(PAR_1,PAR_2) 'read value
FPAR_1=FPAR_1*0.95 + PAR_3*0.05'mean value
```

## 6.5.4 Pro AIn F-4/16 und 8/16 (ADC) , Pro AIn F-4/12 und 8/12 (ADC)

```
'Process for the ADwin-Pro in order to read a voltage
'with an AIN-F module.
'A mean value is calculated in FPAR_1
'Last modification on August 08, 2000 ur
'Usage of the variables:
'PAR_1 : module address      (1 to 255)
'PAR_2 : channel number     (1 to 8)
'PAR_3 : read value         (0 to 65535)
'FPAR_1: mean value

#INCLUDE ADwinPro_All.inc

'#####
INIT:
PROCESSDELAY=2000
IF (PAR_1=0) then PAR_1=1 'prevent module address 0
IF (PAR_2=0) then PAR_2=1 'prevent channel number 0 (not
                        'allowed)
IF (PAR_3=0) then PAR_3=32768
'64080 => +9.555664V (at a voltage range of +/- 10V)
'32768 => 0V
'1456 => -9.555664V

'#####
EVENT:
PAR_3=ADCF(PAR_1,PAR_2)'read value
FPAR_1=FPAR_1*0.95 + PAR_3*0.05'mean value
```

## 7 Accessories

### 7.1 LEMO Cable Sets for ADwin-Pro Systems

Pro-CS-1	4 cables with 200mm (7.8 inch) and 4 cables with 400mm (15.7 inch)
Pro-CS-2	4 cables with 400mm (15.7 inch) and 4 cables with 800mm (31.5 inch)
Pro-CS-3	4 cables with 1000mm (39.4 inch) and 4 cables with 1500mm (59 inch)
Pro-CS-4	4 cables with 5000mm (196.8 inch)
All cables with LEMO connectors on each end	

### 7.2 LEMO Adapter sets

Pro-AS-1	4 adapters: LEMO female connectors to BNC connectors (male)
Pro-AS-3	4 LEMO Y connector (male to double female)
Pro-AS-4	4 adapters: LEMO female connector to LEMO female connector
Pro-AS-5	4 terminators: 50 $\Omega$ , LEMO female connector
Pro-AS-6	4 cable adapters (length 4" / 10cm): LEMO female connector to BNC connector (male)

### 7.3 Reference addresses

#### 7.3.1 LEMO Connectors

Pro modules are equipped with the following LEMO connectors:

- Male connectors / female connectors of series 00 NIM-CAMAC, 1-pole
  - Cable connector: Type FFS
  - Built-in female connector: Type ERN
- Male connectors / female connectors of series 00 Multi-Contact, 2-pole
  - Cable connector: Type FGG
  - Built-in female connector: Type EGG
- Pt100 modules: Male connectors / female connectors of series 0B:
  - Cable connector: Type FGG
  - Built-in female connector: Type EGG

Manufacturer of LEMO connectors:

LEMO S.A.	Tel.: +41 21 695 16 00
Chemin de Champs-Courbes 28	Fax: +41 21 695 16 01
P.O. Box 194	E-Mail: <a href="mailto:info@lemo.com">info@lemo.com</a>
CH-1024 Ecublens, Switzerland	Internet: <a href="http://www.lemo.com">www.lemo.com</a>

### 7.3.2 Power Supply Pro-Mini

The plug connector for external power supply of the casing Pro-Mini is manufactured by Phoenix Contact GmbH:

Combicon plug component, pitch 5.0mm, Type MSTB 2,5/ 3-STF;  
order no. 1786844 (as of Dec. 2005)

Manufacturer of the connector:

Phoenix Contact GmbH & Co. KG  
Flachsmarktstraße 8  
D-32825 Blomberg

Tel.: +49 5235 300  
Fax: +49 5235 341 200  
E-Mail: [info@phoenixcontact.com](mailto:info@phoenixcontact.com)  
Internet: [www.phoenixcontact.com](http://www.phoenixcontact.com)

## Annex

### A.1 CAN bus Baud rates

Interfaces for CAN bus can use the following baud rates:

Available Baud rates [Bit/s]				
1000000.0000	888888.8889	800000.0000	727272.7273	666666.6667
615384.6154	571428.5714	533333.3333	500000.0000	470588.2353
444444.4444	421052.6316	400000.0000	380952.3810	363636.3636
347826.0870	333333.3333	320000.0000	307692.3077	296296.2963
285714.2857	266666.6667	250000.0000	242424.2424	235294.1176
222222.2222	210526.3158	205128.2051	200000.0000	190476.1905
181818.1818	177777.7778	173913.0435	166666.6667	160000.0000
156862.7451	153846.1538	148148.1481	145454.5455	142857.1429
140350.8772	133333.3333	126984.1270	125000.0000	123076.9231
121212.1212	117647.0588	115942.0290	114285.7143	111111.1111
106666.6667	105263.1579	103896.1039	102564.1026	100000.0000
98765.4321	95238.0952	94117.6471	90909.0909	88888.8889
87912.0879	86956.5217	84210.5263	83333.3333	81632.6531
80808.0808	80000.0000	78431.3725	76923.0769	76190.4762
74074.0741	72727.2727	71428.5714	70175.4386	69565.2174
68376.0684	67226.8908	66666.6667	66115.7025	64000.0000
63492.0635	62500.0000	61538.4615	60606.0606	60150.3759
59259.2593	58823.5294	57971.0145	57142.8571	55944.0559
55555.5556	54421.7687	53333.3333	52631.5789	52287.5817
51948.0519	51282.0513	50000.0000	49689.4410	49382.7160
48484.8485	47619.0476	47337.2781	47058.8235	46783.6257
45714.2857	45454.5455	44444.4444	43956.0440	43478.2609
42780.7487	42328.0423	42105.2632	41666.6667	41025.6410
40816.3265	40404.0404	40000.0000	39215.6863	38647.3430
38461.5385	38277.5120	38095.2381	37037.0370	36363.6364
36199.0950	35714.2857	35555.5556	35087.7193	34782.6087
34632.0346	34482.7586	34188.0342	33613.4454	33333.3333
33057.8512	32921.8107	32388.6640	32258.0645	32000.0000
31746.0317	31620.5534	31372.5490	31250.0000	30769.2308
30651.3410	30303.0303	30075.1880	29629.6296	29411.7647
29304.0293	29090.9091	28985.5072	28673.8351	28571.4286
28070.1754	27972.0280	27777.7778	27681.6609	27586.2069
27210.8844	27027.0270	26936.0269	26755.8528	26666.6667
26315.7895	26143.7908	25974.0260	25806.4516	25641.0256
25396.8254	25078.3699	25000.0000	24844.7205	24767.8019
24691.3580	24615.3846	24390.2439	24242.4242	24024.0240
23809.5238	23668.6391	23529.4118	23460.4106	23391.8129
23255.8140	23188.4058	22988.5057	22857.1429	22792.0228
22727.2727	22408.9636	22222.2222	22160.6648	22038.5675
21978.0220	21739.1304	21680.2168	21621.6216	21505.3763
21390.3743	21333.3333	21276.5957	21220.1592	21164.0212
21052.6316	20833.3333	20779.2208	20671.8346	20512.8205
20460.3581	20408.1633	20202.0202	20050.1253	20000.0000
19851.1166	19753.0864	19704.4335	19656.0197	19607.8431

Available Baud rates [Bit/s]				
19512.1951	19323.6715	19230.7692	19138.7560	19047.6190
18912.5296	18867.9245	18823.5294	18648.0186	18604.6512
18518.5185	18433.1797	18390.8046	18306.6362	18181.8182
18140.5896	18099.5475	18018.0180	17857.1429	17777.7778
17738.3592	17582.4176	17543.8596	17429.1939	17391.3043
17316.0173	17241.3793	17204.3011	17094.0171	17021.2766
16949.1525	16913.3192	16842.1053	16806.7227	16771.4885
16666.6667	16632.0166	16563.1470	16528.9256	16460.9053
16393.4426	16326.5306	16260.1626	16227.1805	16194.3320
16161.6162	16129.0323	16000.0000	15873.0159	15810.2767
15779.0927	15686.2745	15625.0000	15594.5419	15503.8760
15473.8878	15444.0154	15384.6154	15325.6705	15238.0952
15180.2657	15151.5152	15122.8733	15094.3396	15065.9134
15037.5940	15009.3809	14842.3006	14814.8148	14705.8824
14652.0147	14571.9490	14545.4545	14519.0563	14492.7536
14414.4144	14336.9176	14311.2701	14285.7143	14260.2496
14184.3972	14109.3474	14035.0877	13986.0140	13937.2822
13913.0435	13888.8889	13840.8304	13793.1034	13722.1269
13675.2137	13605.4422	13582.3430	13559.3220	13513.5135
13468.0135	13445.3782	13377.9264	13333.3333	13289.0365
13223.1405	13157.8947	13136.2890	13114.7541	13093.2897
13071.8954	13008.1301	12987.0130	12903.2258	12882.4477
12820.5128	12800.0000	12759.1707	12718.6010	12698.4127
12578.6164	12558.8697	12539.1850	12500.0000	12422.3602
12403.1008	12383.9009	12345.6790	12326.6564	12307.6923
12288.7865	12195.1220	12158.0547	12121.2121	12066.3650
12030.0752	12012.0120	11994.0030	11922.5037	11904.7619
11851.8519	11834.3195	11764.7059	11730.2053	11695.9064
11661.8076	11627.9070	11611.0305	11594.2029	11544.0115
11494.2529	11477.7618	11428.5714	11396.0114	11379.8009
11363.6364	11347.5177	11299.4350	11220.1964	11204.4818
11188.8112	11111.1111	11080.3324	11034.4828	11019.2837
10989.0110	10943.9124	10928.9617	10884.3537	10869.5652
10840.1084	10810.8108	10796.2213	10781.6712	10752.6882
10695.1872	10666.6667	10638.2979	10610.0796	10582.0106
10540.1845	10526.3158	10457.5163	10430.2477	10416.6667
10389.6104	10335.9173	10322.5806	10296.0103	10269.5764
10256.4103	10230.1790	10204.0816	10101.0101	10088.2724
10062.8931	10025.0627	10012.5156	10000.0000	9937.8882
9925.5583	9876.5432	9852.2167	9828.0098	9803.9216
9791.9217	9768.0098	9756.0976	9696.9697	9685.2300
9661.8357	9615.3846	9603.8415	9569.3780	9523.8095
9456.2648	9433.9623	9411.7647	9400.7051	9367.6815
9356.7251	9324.0093	9302.3256	9291.5215	9259.2593
9227.2203	9216.5899	9195.4023	9153.3181	9142.8571
9090.9091	9070.2948	9049.7738	9039.5480	9009.0090
8958.5666	8928.5714	8918.6176	8888.8889	8879.0233
8869.1796	8859.3577	8771.9298	8743.1694	8714.5969
8695.6522	8658.0087	8648.6486	8620.6897	8602.1505

Available Baud rates [Bit/s]				
8592.9108	8556.1497	8547.0085	8510.6383	8483.5631
8474.5763	8465.6085	8456.6596	8421.0526	8403.3613
8385.7442	8333.3333	8281.5735	8264.4628	8255.9340
8230.4527	8205.1282	8196.7213	8163.2653	8130.0813
8113.5903	8105.3698	8097.1660	8088.9788	8080.8081
8064.5161	8000.0000	7976.0718	7944.3893	7936.5079
7905.1383	7843.1373	7812.5000	7804.8780	7797.2710
7774.5384	7751.9380	7736.9439	7729.4686	7714.5612
7692.3077	7662.8352	7655.5024	7619.0476	7590.1328
7575.7576	7561.4367	7547.1698	7532.9567	7518.7970
7469.6545	7441.8605	7421.1503	7407.4074	7400.5550
7386.8883	7352.9412	7326.0073	7285.9745	7272.7273
7259.5281	7246.3768	7187.7808	7168.4588	7142.8571
7136.4853	7130.1248	7111.1111	7098.4916	7092.1986
7054.6737	7017.5439	6993.0070	6956.5217	6944.4444
6926.4069	6902.5022	6896.5517	6861.0635	6820.1194
6808.5106	6802.7211	6791.1715	6779.6610	6734.0067
6688.9632	6683.3751	6666.6667	6611.5702	6578.9474
6568.1445	6562.7564	6557.3770	6535.9477	6530.6122
6493.5065	6456.8200	6451.6129	6441.2238	6410.2564
6400.0000	6379.5853	6349.2063	6324.1107	6289.3082
6274.5098	6269.5925	6250.0000	6245.1210	6211.1801
6172.8395	6163.3282	6153.8462	6144.3932	6102.2121
6060.6061	6046.8632	6037.7358	5997.0015	5961.2519
5952.3810	5925.9259	5895.3574	5865.1026	5847.9532
5818.1818	5797.1014	5772.0058	5747.1264	5714.2857
5702.0670	5681.8182	5649.7175	5614.0351	5610.0982
5555.5556	5521.0490	5517.2414	5464.4809	5434.7826
5423.7288	5376.3441	5333.3333	5291.0053	5245.9016
5208.3333	5161.2903	5079.3651	5000.0000	

## A.2 Alphabetic List of Modules

Carrier module Pro-MB-8 (-D) .....	158
Pro-Aln-16/14-C Rev. A .....	34
Pro-Aln-32/12 Rev. A .....	28
Pro-Aln-32/12 Rev. B .....	31
Pro-Aln-32/14 Rev. A .....	36
Pro-Aln-32/16 Rev. B .....	45
Pro-Aln-32/16 Rev. C .....	47
Pro-Aln-8/12 Rev. A .....	21
Pro-Aln-8/12 Rev. B .....	24
Pro-Aln-8/14 Rev. A .....	26
Pro-Aln-8/16 Rev. A .....	38
Pro-Aln-8/16 Rev. B .....	41
Pro-Aln-8/16 Rev. C .....	43
Pro-Aln-F-4/12 Rev. A .....	49
Pro-Aln-F-4/14 Rev. B .....	54
Pro-Aln-F-4/16 Rev. A .....	58
Pro-Aln-F-8/12 Rev. A .....	51



Pro-Aln-F-8/14 Rev. B .....	56
Pro-Aln-F-8/16 Rev. A. ....	60
Pro-AO-16/8-12 Rev. A. ....	75
Pro-AOut-4/16 Rev. A. ....	63
Pro-AOut-4/16 Rev. B, Pro-AOut-8/16 Rev. B .....	68
Pro-AOut-4/16 Rev. C. ....	71
Pro-AOut-8/16 Rev. A. ....	65
Pro-AOut-8/16 Rev. C. ....	73
Pro-Boot .....	17
Pro-CAN Rev. A .....	160
Pro-CNT-16/16 Rev. A .....	100
Pro-CNT-16/16-I Rev. A .....	102
Pro-CNT-16/32 Rev. A .....	104
Pro-CNT-16/32-I Rev. A .....	106
Pro-CNT-8/32 Rev. A .....	96
Pro-CNT-8/32-I Rev. A .....	98
Pro-CNT-PW4 Rev. A .....	109
Pro-CNT-PW4-I Rev. A .....	111
Pro-CNT-VR2PW2(-I) Rev. A .....	108
Pro-CNT-VR4 (-L) Rev. A .....	90
Pro-CNT-VR4(-L)-I Rev. A .....	93
Pro-CO4-D Rev. A .....	118
Pro-CO4-I Rev. A .....	116
Pro-CO4-T Rev. A .....	113
Pro-Comp-16 Rev. A. ....	128
Pro-CPU-T10-ENET .....	16
Pro-CPU-T9 .....	13
Pro-CPU-T9-ENET / -USB .....	14
Pro-DIO-32 Rev. A .....	80
Pro-DIO-32 Rev. B .....	82
Pro-Inter-SL Rev. A. ....	174
Pro-LPSH-4-FI Rev. A, Pro-LPSH-8-FI Rev. A .....	157
Pro-LS-2 Rev. A .....	179
Pro-OPT-16 Rev. A. ....	84
Pro-PROFI-DP-SL Rev. A. ....	170
Pro-PT100-4 Rev. A, Pro-PT100-8 Rev. A .....	152
Pro-PWM-4 Rev. A .....	122
Pro-PWM-4-I Rev. A .....	124
Pro-REL-16 Rev. A, Rev. B .....	86
Pro-RSxxx Rev. A .....	176
Pro-Storage Rev. A. ....	130
Pro-TC-4 Rev. A, Pro-TC-8 Rev. A, Pro-TC-16 Rev. A .....	147
Pro-TC-8 ISO Rev. A .....	150
Pro-TRA-16 Rev. A, Rev. B .....	88